Bluetooth°Speaker



TM-836 User Manual The TM-836 Bluetooth speaker can operate in 2 different modes. Bluetooth mode overrides all other modes. To switch to other modes when connected via Bluetooth you must press the play/ stop button on your device.

Mode 1: Bluetooth* mode
PAIRING INSTRUCTIONS: Turn your TM-836 speaker on. You will hear a beep.
The light will blink alternately blue and red. This indicates that the TM-836 is
ready to pair.

TO PAIR TO AN ANDROID PHONE

1. Open: Settings
2. Open:wireless and network
3. Open: Bluetooth mode on if it is off.
5. Touch: Search for devices.
6. Touch and Hold: TM-836
7. Touch: Connect

TO PAIR TO A MAC OS COMPUTER
1 Open: System Preferences
2 Open: Bluetooth function
3 Click: the +to add a Bluetooth device.
4 Select:TM-836
5 Click: Continue - The computer will pair the device.
1nput: the password is 0000 (if necessary)

Mode 2: Connect directly with supplied cable to the audio device Plug the single end of the 2-in-1 cable (mini USB plug) into the TM-836 speaker. The dual end of the 2-in-1 cable has a 3.5mm headphone plug that can insert into any device with a corresponding 3.5 mm jack. The audio signal will transmit through this connection.

USB to 3.5mm 2 in 1 cable(INCLUDED)



WHAT THE BUTTONS DO:

On / Off button
This button turns the TM-836 on and off. Do not leave the TM-836 on if not use.

Pause / Play To pause or play audio when in *Bluetooth* mode. Press and hold this button for switching to Line-in mode.

Press and hold to increase(+) or lower(-) volume in all modes.

Press + once to play next tracks. Press - once to play last song.



Bluetooth Speaker



WHAT THE LIGHTS MEAN.

WHAT THE LIGHTS MEAN.
LED Flash Rapidly: Bluetooth* function is available and ready to
be paired
LED Flash Slowly: Paired and playing music
LED Flash every 30s and have beep sound: low battery indication
LED keeps lighting when connecting the charging port: charging

LOW BATTERY WARNING
In Bluetooth mode -- "beep" sound warning in every 30s In MP3
mode -- "red" led flashing

CHARGING YOUR TM-836

CHARGING YOUR TM-836

1. Connect the mirco USB cable to the speaker to charge
2. Connect the USB plug on any USB adaptor(not included). This
can be the USB port on a computer, wall adapter(not included) or
car charger (not included).

3. Once connected the TM-836, charging will be started
automatically.

4. To charge the device fully, it takes approximately 2 hours.

5. Partial charging will not affect the life of the battery.

CHARGING WHILE PALYING

You can charge the TM-836 and play audio at the same time

CARE OF YOUR TM-836
Do not let the TM-836 comes in contact with water.
Do not leave it in direct sunlight or under high temperature.
Clean with dry soft cloth.
Do not use harsh chemicals to clean.
Do not drop or place heavy objects on the TM-836.
Never try to repair or open you TM-836 yourself.

Information about products that generate electrical noise
The bluetooth's peaker complies with FCC and Industry Canada RF radiation
exposure limits set forth for general population. The system must not be
colocated or operating in conjunction with any other antennas
or transmitters.
This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

U.S.A. only
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, this is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by one or more of the following measures:

Re-orient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment to an outlet on a different circuit than the one to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipmen