
User's Menual

Model Number: BTS-09

Bathroom Bluetooth Speaker



Transmit music to your bathroom with the BETRUE's Bathroom Bluetooth Speaker. Splashes proof design allows for all-round bathroom usage. The vacuum cupule design makes hanging in the bathroom wall quick and easy.

Important

Don'ts

- Do not place naked flames, such as lighted candles on or near the product.
- Do not place objects filled with liquids, such as vases on or near the product.
- Do not use or store this product in a place where it is subject to direct sunlight, heat, excessive dust or vibration.
- Do not keep or store this product in wet conditions for long period.
- Do not clean this product with water or other liquids.
- Do not block or cover the slots and holes in the product.
- Do not push foreign objects into the slots or holes in the product.
- Do not attempt to open this product yourself. There are no user serviceable parts inside.
- Do not allow children access to plastic bags.

Safety Instructions

- Before using this product, read and follow all warnings and instructions.
- This product is not intended for use by young children. Young children should be properly supervised.
- This product is intended for household use only and not for commercial or industrial use.
- Do not expose to dripping or splashing.
- No naked flame sources, such as lighted candles, should be placed on the product.
- Ventilation should not be impeded by covering ventilation openings with items such as newspapers, table cloths, curtains and the like.
- Make sure the unit is adjusted to a stable position. Damage caused by using this
 product in an unstable position or by failure to follow any other warning or
 precaution contained within this user manual will not be covered by warranty.

We, suggests retaining the packaging in case for future transport of the product.

Warning



- Never remove the casing of this apparatus.
- Never place this apparatus on the other electrical equipment.

Notice

- If at any time in the future you should need to dispose of this product please note that: All batteries and accumulators need to be removed from this product (Removal of Waste Batteries and Accumulators).
- Always bring your product to a professional to remove the built-in battery.

Caution for Splashproof

This unit has been constructed to resist mild steam and light splashes from the shower or bath only. It should never be operated under running water and under no circumstances it should never be fully immersed in water.

This unit has rubber seals to minimize the risk of moisture getting inside. However, do not immerse it in water since permanent damage to the electrical and mechanical parts will result.


FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Outlook And Control



| 1 | ී Button | 7 | >Button |
|---|--|----|-------------------|
| 2 | Mode / Charging LED | 8 | Speaker |
| 3 | ▶ ∥ Button | 9 | Cupule Lock |
| 4 | <button< td=""><td>10</td><td>Vacuum Cupule</td></button<> | 10 | Vacuum Cupule |
| 5 | Button | 11 | Mini USB socket |
| 6 | MIC Hole | 12 | Rubber Seal Cover |

Charging The Bluetooth Speaker

- 1. Open the rubber seal cover (8).
- 2. Connect the Bluetooth Speaker's Mini USB socket (11) with the Computer's USB port through USB cable.
- 3. The Charging LED (2) will turn ON in red light; the rechargeable battery is in charging.
- 4. The Charging LED (2) red light will turn OFF when the rechargeable battery is fully charged.
- 5. Disconnect the USB cable, and close the Rubber Seal Cover (12) when it is done.

Bluetooth Speaker Pairing / Reconnecting

- Press and hold the button (1) for 2 3 seconds, a tone sound then message "It is paring wait for device connecting" will announce from speaker and the Mode LED (2) will blinking in blue, the device is turned ON and goes into reconnect / searching mode for pair depend on status;
- 2. The Mode LED (2) blinking in blue every 2 seconds once if it is in reconnect mode. Or, the Mode LED (2) fast blinking in blue half seconds once, in search mode if for first time pairing. If not, press and hold ► button for 2 − 3 seconds to switch into searching mode for new device's paring.
- 3. Now, turn ON the Bluetooth function on your mobile phone, search for device name "BTS09" and select it to pair.
- 4. If pairing is successful, a tone sound then message "Paired" will announce from speaker and the Mode LED (2) light will switch to slow blink in blue (every 4 seconds once).
- 5. The Bluetooth Speaker will be reconnecting automatically if your mobile phone has been paired. (Depend on the of mobile phone's type and configuration, manual reconnection may require on some devices)
- 6. Press and hold the **b** button (1) for 2 3 seconds, a tone sound will announce and Bluetooth speaker turned to OFF when you not use it.

Note: During in searching / pairing mode, the Bluetooth Speaker will power OFF automatically in 8 minutes if no device is connected and idle.

Bluetooth Speaker Control Function

- 1. In playing music, press ► button (3) to pause music, press it once again to play.
- 2. Pressing or press and hold the > button (7) to increases the volume level.
- 3. Pressing or press and hold the \leq button (4) to decreases the volume level.
- 4. When maximum or minimum volume is reached, a tone sound will be heard.
- 5. Press the > button (7) to play next music file.
- 6. Press the ≤ button (4) to play previous music file.

Hand Free Function

- 1. When there is an incoming call;
- 2. The ringing sound will up and the playing music will pause automatically.

- 3. Press f button (5) to pick up the call if you want.
- 4. Now you have hand free function with the Bluetooth speaker.
- 5. Press Γ button (5) again to hand up the call when finished. And,
- 6. The paused music will start to play automatically.

Tip: speak to the MIC hole (6) direct with distance in 30 cm to get the best speakerphone performance when necessary.

Redial For Last Call function

- To redial for last called number by the Bluetooth Speaker, even it is in music playing mode.
- 2. Press twice the **C** button (5) to enter into redial function, the playing will pause and switch to hand free function for redial.
- 3. Press the f button (5) again to hang up the redial call.

Low Power Reminder And Auto Sleep

- 1. The Bluetooth Speaker will send tone sound once in very few seconds, when you heard this tone sound, please connect the device to the USB power for charging if you still want to use the device.
- 2. If not, the Bluetooth Speaker will power Off to sleep mode when the battery is keeping low energy level in minutes.

Reset The Bluetooth Speaker

- 1. In some circumstances the device's function may hanging and need to reset. To reset the Bluetooth speaker;
- 2. Press and hold the < button (4) and > button (7) at the same time. The device is reset and will turn Off and turn On automatically.

Important: Do not reset the device if it is proper working.

Splashproof Handling

- 1. The Bluetooth Speaker can handle a brief jet of water on its surface (IPX4 water resistant). However, it should never be operated under running water and under no circumstance it should never be fully immersed in water. Before use the Shower Bluetooth speaker in bathroom, mare sure that the splashproof Rubber Seal Cover (12) it tighten closed at the right position.
- 2. After used in bathroom, always wipe the outside of the cabinet thoroughly if it becomes wet with moisture or water splashes. This will help to prevent the internal parts of the unit from entry of water and possible moisture damage.

Trouble Shooting

| No power | • | Check battery is it charged with enough energy. |
|----------|---|---|
| | • | Check whether the device is in power OFF mode. |

| D19 09 03c1 Wallaci V1:0_W D3021_130990_10 | | | | |
|--|---|--|--|--|
| No sound | Check whether volume level is in lower position on your speaker and mobile phone or PC/Mac. Make sure that your Bluetooth device is within the effective operation range. Check whether the Bluetooth device is paired. Check whether the Bluetooth device show connected. Check if you have selected the correct audio source. | | | |
| Speaker no response | Reset the Bluetooth speaker. | | | |

Specification

| Dimension (main Unit) | 84 mm (H) x 84 mm (W) 44x mm (D) (Approximate) | | |
|-------------------------|--|----------------------------|--|
| Weight (main unit only) | 86g (Approximate) | | |
| | Specification | V2.1 + EDR | |
| Bluetooth | Supported Profile | A2DP (V1.2), AVRCP (V1.0), | |
| Bidetootii | | HFP/HSP (V1.5) | |
| | Connection Distance | In 10 meters (open area) | |
| | Lithium 3.7V, 300mAh | | |
| Built-In Battery | Playing Time: 1.5 ~ 3 Hours depend on music and volume | | |
| | level) | | |
| Power Input | PC's USB port Power or DC 5V, 500mA | | |
| | Output Power | RMS 1.5W at 4 Ohm | |
| Audio | | Max. 2W | |
| | Frequency Responses | 100Hz to 20,000Hz | |
| Operating Temperature | 0 to 40℃ | | |

Disclamer

Updates to Firmware and/or hardware components are made regularly. Therefore some of the instruction, specifications and pictures in this documentation may differ slightly from your particular situation. All items described in this guide for illustration purposes only and may not apply to particular situation. No legal right or entitlements may be obtained from the description made in this manual

Recycling



If at any time in the future you should need to dispose of this product, please note that: Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or Retailer for recycling advice. (Waste Electrical and Electronic Equipment Directive)