
- Z-folding (Z形摺紙)

- Double printing (雙面印刷)



50mm

teen

Emily & Meritt For PB Teen THE BUNNY SPEAKER **USER MANUAL**



Table of contents 1 Introduction-2 Packge includes······2 3 Product diagram 2 4 How to use 4.1 General function ······ 3 4.2 Pairing to mobile phone ······· 4 4.3 Charging your speaker 5 Technology specification ······ 7 FCC Statement ----- 8

Congratulations, and thank you for choosing the Bluetooth Wirless Speaker. This manual will help you operate the Bluetooth Wirless Speaker, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Bluetooth Wirless

Safety Rules

Speaker.

1.Introduction

- Please follow the rules depicted in this manual closely to ensure your safety.
 Before using this Bluetooth speaker, we would strongly encourage you to read through this user manual
- Be more wary of any edges, uneven surfaces, metal parts, accessories and its packaging so as to prevent any possible injury or damage.
- Do not modify, repair or dismantle this Bluetooth speaker. Doing so may result in fires, electric shocks, complete breakdown of this Bluetooth speaker, etc. All of which, are not covered under
- Do not use any diluents or volatile liquid to clean the Bluetooth speaker.

2.Package includes



1X User Manual

3.Product diagram Left

1X USB Charge

Right

1X Audio Cable

4. How to use 4.1.General Functions Desired Result

	Turn on & Enter the pairing mode	to "ON" to turn speaker on. (Blue LED quickly flash alternately with two beep tone voice).
	Pairing	You should use a Bluetooth function mobile phone or oth Bluetooth Master Device and to perform pairing action (detail refer to the chapter about pairing)
	Play / Pause	Press we to play when the device is pausing and press to pause when the device is playing.
	Turn off	Switch the ON/OFF button to "OFF" to turn speaker off.

Required Action

Switch the ON/OFF button

Low battery (The LED flash) warning Plug the charger to ⊖⊕⊕ port Charging (Red LED is on) Answer / End Press nto answer phone call.

Reject phone call

4.2.Pairing to mobile phone or other device

SKU No. 9160875 / 9134334

To use your Bluetooth Speaker, you must first pair your speaker with a phone or a computer. Once your Bluetooth Speaker is paired to a specific mobile phone, they will remain paired and automatically recognize each other whenever they are within range.

Pairing to a phone and Entertainment:

- Turn on your phone and ensure its Bluetooth
- . Turn on the speaker go to the pairing mode.
- · Search your Bluetooth devices on your phone by following the phone's instructions. Refer to your phone's user manual for more
- After a few seconds the phone will list the "PB Bunny" as a discover device. Select it and follow your phone instruction to select this pairing
- · Your phone will confirm the pairing, and then press Yes/Ok.
- · Finally, the paring is sucessful.
- · You can play music; watch TV/movie and play games with your phone, then you can hear all the sound or music from the speaker.

Pairing to a computer and Entertainment:

- · If there is no Bluetooth function supported by your computer, a Bluetooth adapter is necessary. Fix the adapter with your computer and ensure its Bluetooth function is
- Turn on the speaker go to the pairing mode.
- Open the Bluetooth software installed on your computer, and selects "Search your Bluetooth devices" function. Refer to user manual of the Bluetooth software for more information.
- · After a few seconds the "PB Bunny" will list in Bluetooth software of your computer as a discover device. Select this icon and click right button of mouse to select "pairing" item. then select "connect with audio device" with
- · Open your media player soft to play music, watch TV/move and play game, then all the sound will be playback on your speaker

4.3.Charging your speaker

The speaker is convenient to connect to AC charger or a USB charger with Mini DC 2.0 port marked with ⊕ ⊕ ⊕ . Make sure that your speaker is full charged for at least 6 hours. before initial use. Insert one terminal of your charger to AC main or USB port of PC and other terminal to DC 2.0 jack⊖ ⊕. While charging, the red LED light stays lit. When charging is completed, the LED turns off.



You must select a qualified charger from a regular manufacturer.

• You must charge the Bluetooth Speaker if it

5.Technical specification

Parameter	Value
Bluetooth Specification	3.0
Bluetooth Profile	A2DP, AVRCP, HFP, HSP, GAVDP, IOP
RF Range	≤10m
Frequency Response	160Hz - 20KHz

Parameter Value Loudspeaker 3 W Signal-To-Noise 75 dB Distortion ≤1.0% Playback Time 3 - 5 hours 1 - 2 hours **Charging Time** Dimension (L×W×H) 67mm× 29mm ×140mm Weight 95 g

6.FAQ

- 1. Why is there no power even when the Speaker is power on?
- Ans: Ensure the battery is being charged up to 6 hours for first time using. The LED is red when it starts charging.
- 2. There is no sound when playback. Ans: Check the connection between speaker with phone or computer, if the connection is not established, please connect again. Make sure the speaker is paired and connected with your target phone or other master device.

FCC statement

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to NOTE: Inis equipment has been tested and found to properly with the initial for a Class. These limits are distinct to Part 15 of the FCC Rules. These limits are desired provide reasonable protection against harmful interference in a residential installation. This equipment generates, use and can radiate radio frequency energy and, if no installed and used in accordance with own installations, may cause sarmful interference to radio communications, may cause sarmful interference to radio communications.

However, there is no guarantee that interference will not However in particular installation. If this equipment does naticular installation. If this equipment does cause harmful interference to radio or television to which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and
- · Connect the equipment into an outlet on a circuit different
- from that to which the receiver is connected.

 Consult the dealer or an experienced radio/TV technician

Back

Front