# HYPE® QUICK START GUIDE

# H Y P ■® QUICK START GUIDE

# H Y P E® QUICK START GUIDE

# HYPE® QUICK START GUIDE

# TRUE WIRELESS STEREO EARBUDS TRUE WIRELESS STEREO EARBUDS TRUE WIRELESS STEREO EARBUDS TRUE WIRELESS STEREO EARBUDS TRUE WIRELESS STEREO EARBUDS

# USING THE PORTABLE CHARGING CASE

We recommend that you keep the earbuds in the portable charge case when not in use. While on-the-go, the case doubles as a charging solution for the earbuds. Simply put the earbuds into the charging case. Press the button on the charaina case to turn on the case. And the earbuds will beain to charge, a full charge of the earbuds takes 1.5 hours.



Connect the Micro USB cable to the charging port on case. A full charge of the case battery takes up 2 hours. When the case is charging, the LED light flashes red. The red light will turn to blue when fully charged.





Your earbuds come pre-paired. If they lose connection, please follow the below steps to reconnect.

Press and hold multifunction buttons on both earbuds to power on both earbuds, then wait till the indicator lights flash red and blue on both earbuds.

# H Y P E® QUICK START GUIDE



The two earbuds will pair to each other automatically. The indicator lights of both earbuds will flash blue three times to indicate they are paired successfully.

 Press and hold the button on Right or Left earbud for 3 second to turn earbuds on/off.



Turn on Bluetooth on your To turn OFF press and phone or tablet. Choose hold the multifunction "HY-T2W". Enter "0000" if button on either asked. You're paired! Both earbud until the LED earbuds flash blue every 6 flashes red for three seconds.



# H Y P ■ QUICK START GUIDE

### USING EARBUDS FOR DIFFERENT DEVICES

The earbuds can be paired to different devices. For example, you can use one earbud with a smart phone and the other earbud for a tablet.



Turn on one earbud by press and hold the multifunction button for 3 seconds. The earbud flash red and blue. Leave the other earbud turned off.



Select "HY-T2W" from the Bluetooth menu of your first device. Enter PIN code "0000" if asked. This earbud is ready to use.



To pair the other earbud. make sure vour other wireless device is nearby. Same pairing operation as the first earbud. Choose "HY-T2W". Enter "0000" if asked.

# HYPE® QUICK START GUIDE

# H Y P ■ QUICK START GUIDE

PHONE CALL CONTROLS (using as pair)

to redial last call made.

controlled by the master earbud only.

### HY P ■® QUICK START GUIDE

# HYPE® QUICK START GUIDE

# HYPE® QUICK START GUIDE

accordance with the instructions, may cause

harmful interference to radio communications.

However, there is no guarantee that interference will

not occur in a particular installation. If this

equipment does cause harmful interference to radio or television reception, which can be determined by

# HYPE® QUICK START GUIDE

# H Y P ■® QUICK START GUIDE

# MUSIC CONTROLS (using as pair) Press the button on Right or Left earbud once to pause/play your music.

- Double press the button on Left earbud to decrease the volume.
- Double press the button on Right earbud to increase the volume.
- Triple press the button on Left earbud to skip backward.
- Triple press the button on Right earbud to skip forward.
- Press and hold the button on Right earbud for 1 second to use Siri / Google Assistant.

NOTE: When answering calls, the call can be heard and

# CONNECTION LOST?



• Press and hold the button on Right or Left earbud for If paired two earbuds don't work, turn off the 1 second to reject a call. earbud and reconnect earbuds as a pair. Press and hold the button on Left earbud for 1 second

- Make sure your earbuds are within range of vour smart device.
  - If you hear a long beep, you need to recharge your earbuds. Connection may be lost due to low battery.

### FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

# TRUE WIRELESS STEREO EARBUDS TRUE WIRELESS TRUE W

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in

FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

### turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2AANZT2W BT ID: D044460

### WARRANTY

This product is covered by a 3 month limited manufacturer's warranty. Contact us if you have any problems at support@dalusa.com.

### WARNING

Keep away from water and moisture. Keep away from heat sources. Do not disassemble.





