

P1

Welcome

Thanks for choosing this laser presenter. It gives you remote control of your onscreen presentations with a range of up to 35 feet which is a prefect idea for a large conference room. This presenter supports the most common presentation tools including Page Up, Page Down, Start & Exit slideshow, Screen black. It also has a laser pointer that helps you focus in on your key messages. Just plug and play, no software is required. It allows you to control your presentation with one touch easily in the palm of your hand, and enjoy freedom of movement as you present.

Be sure to carefully read this User's Guide first for the proper use of this product and keep it for future reference.

©2012 All rights reserved.

IMPORTANT SAFETY AND HEALTH INFORMATION

CAUTION LASER RADIATION-DO NOT STARE INTO BEAM
MAX OUTPUT:1mW WAVE LENGTH:650±20nm CLASS II LASER PRODUCT.
This product complies with 21 CFR.

Package contents

- Wireless 2.4GHz Laser Presenter x 1
- User's Manual x 1
- Cable x 1
- Warranty Card x 1

Minimum System Requirements

- Windows® 8/8SE / 2000 / ME / XP / Vista / 7 / 8 or Above, Mac OS X® v.10.4 (or later)
- IBM or PC Compatible or Notebook with USB port

Product Features

Trouble Shooting


Question	Possible cause	How to resolve
Need to install software for first use of this product?		No, this is a plug and play device.
Need to link ID before first use?		No need
Possible to use 2 or more of this product in a room at the same time?		Yes
Remote control malfunction	Interfered by other RF signal	To Implement ID Link (see Switching Channels)
Laser pointer and remote control both malfunction	Put batteries in wrong direction or run out of battery power	Check the batteries

P2

Getting Started

STEP 1 Pull out the receiver

Take USB receiver plug it to PC USB port (product will auto link).



STEP 2 Connecting the Receiver

Take USB receiver plug it to PC USB port (product will auto link).



STEP 3 Open the Powerpoint file and test the key functions

Open the Powerpoint file and test the key functions



Countdown timer setting

Take out USB receiver and press laser button to awake LCD display

(Display will show the data when last time you plugged in the USB receiver and cut off the power, for example 06:00)

Press S, the ":" of 06:00 will blink

Press page up and page down to adjust the time (for example 09:00)

Press S again to confirm. The ":" will stop blinking.

Press "start" and the timer will start to count down (08:59, 08:58, 08:57.....)

The timer will automatically vibrate for 10 seconds at 10:00, 05:00, 02:00 and 00:00.

You can press laser button to stop the vibration.

During the counting down, long pressing S will delete the time setting and it will show 01:00 as default. You can press "pause" to pause the counting down.

Trouble Shooting

Question

Possible cause

How to resolve

Need to install software for first use of this product?

No, this is a plug and play device.

Need to link ID before first use?

No need

Possible to use 2 or more of this product in a room at the same time?

Yes

Remote control malfunction

Interfered by other RF signal

To Implement ID Link (see Switching Channels)

Laser pointer and remote control both malfunction

Put batteries in wrong direction or run out of battery power

Check the batteries

P3

Switching Channels

Plug receiver to your PC USB port Within the 20-second stand-by time, press **▲** and **▼** simultaneously 2 seconds until the red LED of Status indicating becomes blinking for 2 times, the ID link has been successfully done.



Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow

Page UP

Page DOWN

Laser button

Countdown timer setting

Battery cover

Receiver: Plug it to USB port

Start & Exit slideshow