HANDS FREE CALLING

- 1. Press the function button to recieve and end calls.
- 2. Long press function button to reject the call
- 3. Press function button twice to use the redial function, you will hear a tone and the last number be redailed.



APPEL MAINS LIBRES

- Appuyez sur la touche d'appel pour accepter et terminer
- Appuyez longuement sur la touche appel pour rejeter l'appel.
- Appuyez sur la touche Appel de nouveau pour raccrocher lorsque l'appel est terminé.
- 4. Appuyez sur la touche Appel deux fois pour entrer dans la fonction rappeler, la musique se mettra en pause et l'appareil passera en fonction main libre pour rappeler.



TROUBLE SHOOTING

Recharge your headphones using the micro USB cable. If the problem persists try using another micro USB cable.



No response from the unit

- Ensure your Bluetooth device supports an A2DP, AVRCP, HFP, or HSP profile.
- Check if both devices are paired and connected to each other.
- Restart the device and try to reconnect.



RÉSOLUTION DES PROBLÈMES

Rechargez votre casque avec le câble micro USB. Si le problème persiste, essayez d'utiliser un autre câble micro USB.



Pas de réponse du système d'enceinte

- Assurez-vous que l'appareil Bluetooth soutien un profil A2DP, AVRCP, HEP, HSP,
- Vérifiez que les deux appareils sont couplés et connectés l'un à l'autre.
- Redémarrez l'appareil et essayez de reconnecter.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged

to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

CHARGING

- 1. Begin by connecting the provided micro USB cable to the headphones and power source
- 2. Charge the device until the red LED indicator turns off.
- 3. Always disconnect the cable when charging is finished

Note: It will take approximately 2 hour to achieve a full charge.



CHARGEMENT

- 1. Commencez en connectant le câble micro USB fourni sur casque et la source d'alimentation
- 2. Chargez l'appareil jusqu'à ce que l'indicateur DEL s'éteigne.
- 3 . Déconnectez toujours le câble lorsque le chargement est terminé.

Remarque: cela prend environ 1 heure pour recharger complètement la batterie.



Bluetooth CONNECTION

- 1. Power the headphones on. The earbuds will automatically enter pairing mode when powered on.
- Turn on your device's Bluetooth. From the Bluetooth menu select the "SOHO" earbuds.
- When paired successfully the device will make a tone to confirm the connection has been made
- 4. Remember to turn the headphones off after each use

Note: The headphones will automatically connect to previously paired



CONNEXION Bluetooth

- Allumez le casque. Casque entrera automatiquement en mode de couplage lorsqu'il sera allumé.
- 2. Allumez votre appareil Bluetooth, dans le menu Bluetooth, sélectionnez "SOHO".
- 3. Une fois correctement couplé, l'appareil émettra une tonalité pour confirmer que la connexion a été effectuée.
- 4. Après chaque utilisation, n'oubliez pas d'éteindre casque.

Remarque: L'appareil se connectera automatiquement aux appareils auxquelsil a déjà été connecté.

SPECIFICATIONS

Model No: HP6508 Working Distance: Approx. 33ft Playback Time: 2.5 Hours Charge Time: 2 Hours Speaker Output Power: 10 mW

Frequency: 20 Hz - 20 kHz Profile: DSP / HSP / HFP / A2DP/ AVRCP

FUNCTION PANELS

Function Button 0 Press for hands-free functions & pause / play Volume /Track Control -+ong press to increase / decrease vol. nort press to select next and last track Micro USB Port Used to charge the device **Auxiliary Port** 0 or playing aud uxiliary cable

SPÉCIFICATIONS

Numéro de modèle: HP6508 SOHO Distance de Travail: Approx. 33ft Temps de Lecture: 2.5 Heures Temps de Charge: 2 Heures Haut-parleur Puissance de sortie: 10 mW Gamme de fréquences : 20 Hz - 20 kHz Profil: DSP / HSP / HFP / A2DP/ AVRCP

PANNEAUX FONCTIONNELS

Bouton de Fonctionnels éteindre et allumer le casque Appuyez sur pour les fonctions et pause / play mains-libres 0 Son et suivi de commande Appuyez et maintenez pour tourner le volumede haut en bas Appuyez sur pour sélectionner la piste suivante et dernière Port Micro USB r la casque Auxiliaire Pour la lecture audio avec un câble auxiliaire 0

EN