Wireless Bluetooth Speaker

User's Guide for Model ISB225B

Important Safety Instructions

- Heed all Warnings. Follow all instructions. Do not use this apparatus near Clean only with a dry cloth.

- Do not use this apparatus near water.

 Clean only with a dry cloth.

 Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

 Do not install near any heat sources such as radiators, heat registers, stowes, or other apparatus (including amplifiers) that produce heat.

 Do not defeat the sately purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding open than the provided plug does not provide the provided plug does not into you with the provided plug does not fit into you with a constant and external row red of the provider plug does not fit into you with constant and external row red paparatus.

 Only use attachments/accessories specified by the manufacturer.

 Unplug this paparatus during lightning storms or when unused for long periods of time.

 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been changed in any way, such as power-supply cord or plug is damaged, liquid has been spilled or object have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

 Use only with a cart, stand, tripod bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/ apparatus combination to avoid injury from tip-over.



FCC Warnings

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Bate. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or elevision reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver is

Additional Warnings and Precautions

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

AVIS: AFIN DE PRÉVENIR LES CHOCS ÉLÉCTRIQUES, FAITES CORRESPONDRE LA FICHE BLANCHE DE LA PRISE À LA FENTE LARGE, INSÉREZ TOTALEMENT.

- WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain, moisture, dripping, or splashing.

 AVIS: Pour réduire le risque d'incendie ou de choe électrique, n'exposez pas cet appareil à la phise ou l'Immittée ou ant éclaboussures.

 CAUTION: Use of controls or adjustments or performance of procedures other than those specified may result in haradous radiation exposure.

 AVIS: L'utilization de commande ou! L'exécution de procédures autres que celles spécifiées ici peneum abouitr à une exposition de ser adatations dangereusse.

 WARNING: Changes or modifications to this unit not expressié approved by the party responsible for compliance could woit the user's authority to operate the equipment.

 AVIS: Des changements ou des modifications sur ce produit non expressiément approuvés par la parine responsible de la conformitée peut anumelre le droit de l'utilisaueur d'utiliser cet équipment.

 WARNING: Do not place this unit directly onto furniture surfaces with any type of soft, prouse, or enseither finità, de set hay ny ribber compound made with oils, the fect could cause marks or statisting between the unit and the surface to reduce the risk of damage and/or statisting.

 AVIS: Ne placer pas cette muité duréctement sur des surfaces de meubles dont la finition sevrait douce, poruse ou sensible. Car comme tout composé cauntchone a base d'huiles, les plects pourreinet laiser des frares ou des taches à l'entrôtion its sont posis. Nous recommandons à utiliter une protection comme un linge ou un morceau de verre entre l'unité et la surface pour réduire le risque de dégit et ou de tache.

 WARNING: Use of this unit near fluorescent lighting may causs interference regarding use of the emote. If the unit is dhapsing erraite behavior move away from any fluorescent lighting, as it may be the cause.
- Tefficite. It is unit sourgement of the bethe cause.

 AVIS. I. utilisation de cette unitie en présence de lumières fluorescentes peut causer des interférences lors de l'utilisation de la télécommande. En cas de dysfonctionnement, éteignez les sources de lumière fluorescentes, car celles-ci pourraient en ére la cause.

 CAUTION: Danger el explosion if battery is incorrectly replaced. Replace only with the same or oruivalent type.

- Sourcis in luminer juniores comes, cut recues-ve pourtuent en ore ut cause.

 CAUTION: Danger of explosion is thettery is incorrectly replaced. Replace only with the same or
 equivalent type.

 AVIS: Un danger of explosion est présent lorsque les piles sont remplacées de manière incorrecte.

 Remplaces seulement les piles par des piles de pué equivalent.

 WARNING: There is a danger of explosion il you attempt to change standard Alkaline batteries in the
 unit. Only use rechangeable NMH batteries.

 AVIS: Changer de piles aiclaines dans l'unité peut causer une explosion. Utilises seulement des
 piles rechangeables NMH.

 AVIS: Les piles boutous de la télécommande contiennent du mercure. Ne les jetez pas à la corbeille,
 recycle-sie ou disposez-les comme des déchets dangereux.

 VARNING: Limbina batteries, like all'erchangeable batteries, are recyclable and should be recycled

 or disposed of in normal household waste. Comact your local government for disposa of recycling

 practices in your aex. They should never be incinerated since they might explode.

 AVIS: Les piles Lithium ion, comme toutes les autres piles rechargeables, sont recyclables et doivent
 érre deies avec vos déchens ménagers. Constacte vour beaufosphiles pour bonier des conseils sur les moyers de disposition et de recycling dans votre région. N'incinèrez pas vos piles, car celle-cipenvent exploser.

- led Muyers are unspossion or us. Crystoge.

 WARNING: Shock hazard Do Not Open.

 AVIS Risque de choe dectrique ne pas ouvrir

 Caution and marking information is located at the rear or bottom of the apparatus.

 Attention of et amazunga des information est stine sur le paneau arrière ou inférieur de l'unité.

 Objects filled with liquids, such as vases, shall not be placed on the apparatus.

 Mains plug is used as disconnect device avues, ne doivent pas éres placés sur l'appareil.

 Mains plug is used as disconnect device and it should remain readily openable during intended use. In order to disconnect the apparaits from the mains completely, the mains plug should be disconnected form the mains socket outlet completely.

- La prise du secteur est utilisé pour déconnector le système. La prise du secteur ne doit pas être obstruée ou doit être facilement accessible pendant son utilisation. Pour être complétement déconnecté de l'alimentation d'eurée, la prise doit être débrauchée du secteur. Le plant de l'alimentation d'eurée, la prise doit être débrauchée du secteur. Le plant de loit entre plant en écroire par été ne services betau che su sousible, fitse or the lâte. Les plant en échore par été nesposées à de forre évaleur, rel qu' à la lumière du soleil, au feu ou autre se choixe de semblable. Keep neu and une des batteries suns print children. He battery compartment does not close securely, stop using the product and keep it ways from children. He battery compartment does not close securely, stop using the product and keep it ways from children. Gardee les piles eneuve et d'occionné na partir des enfants. Si le compartiment de la batterie ne pas fermer correctement, cessor d'utiliser le produit et garder loin des refants. Il ryou think lattrices might have been swallowed or placed inside any part of the body, sech immediate medical attention.
- immediate medical attention.

 Yo vass pensez que les hatteries peuvent avoir été avalé ou placé à l'intérieur d'une partie du corps, consulter immédiatement un médecin.

 Do not mis old and new batteries.

 Ne pas nélanger vieille et anouvelles batteries.

 Completely replace all old batteries with new ones.

 Remplacer complétement toutes les piles par des neuves.

 Do not mis allatine, standard (carbon-zine), or rechargeable (ni-cad, ni-mh, etc) batteries.

 We médiange pas des piles acultanes, standard (carbon-zine) on rechargeables (Ni-Cd, Ni-MH,



WARNING: To reduce the risk of electric shock, do not remove cover (or back). No user-serviceable parts inside. Refer servicing to qualified service personnel.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol indicates that this product incorporates double insulation between hazardous mains voltage and user accessible parts.

FEATURES & CONTROLS


FEATURES

- Supports Bluetooth
- Wireless range: 60 feet
- Supports automatic device pairing
- LED light effects
- Digital volume control
- Play/pause button
- Micro-USB port for battery recharge
- Aux in (3.5mm audio input)
- LED charge indicator
- DC battery power: built-in rechargeable lithium ion battery
- Battery life: approx. 5.5 hours at 50% volume


INCLUDES

Micro-USB to USB cable

Side



Front





POWER & CHARGING

Requires a Micro-USB to USB cable (included).

1. Using a Micro-USB to USB cable (included), connect the speaker to a powered on computer or USB wall adaptor. The unit will now charge. Note: The computer must not be in sleep mode.

When the battery is charging, the Charging Indicator on the front of the unit will display solid red.

When the battery is fully charged, the Charging Indicator will turn off. When the battery is low on power, the Charging Indicator will flash red.



BLUETOOTH

Pairing to a Device and Playing Audio

- Power on the unit by sliding the $\bf Power \, Switch$ to the $\bf ON$ position. The Pairing Indicator on the front of the unit will slowly flash blue.
- Press and hold the Pair/Play/Pause button to begin pairing. The Pairing Indicator will begin flashing quickly. When pairing, remain within
- Using the controls on your Bluetooth device, scan for and select ISB225 in your Bluetooth settings to pair. If your device requests a password, enter the default password 0000
 - Refer to the user's manual for your specific device for instructions on pairing and connecting Bluetooth devices.
- When successfully paired, the Pairing Indicator will switch to solid blue and an audible chime will sound through the speaker.
- Use the controls on the connected device to select an audio track.
- Audio played through the connected Bluetooth device will now be heard through the speaker. Use controls on the unit or your device to play, pause, and change the volume.

After initial pairing, the unit will stay paired unless unpaired manually by the user or erased due to a reset of the device. If your device should become unpaired or you find it is unable to connect, repeat the above steps.

AUX IN

Using Aux In (3.5mm Audio Input)

Requires a 3.5mm audio cable (not included).

- Connect a 3.5mm audio cable to the Aux In on the unit and the audio output/headphone jack on a media player.
- Power on the unit by sliding the **Power Switch** to the **ON** position. The unit will automatically detect the input and switch to Aux In Mode. The Blue Pairing Indicator on the front of the unit will switch to solid green.
- Use the controls on the connected device to select and play audio.



LIGHTS

- To turn on the lights, press the **Lights** button. The lights will automatically begin cycling through colors.
- To pause the lights, press the Lights button once. Press again to cycle through the colors.
- To turn the lights off, press and hold the **Lights** button.

Note: The lights can be on even if the main Power Switch is in the off position. Use the Lights button to power the lights on and off.

INTERNATIONAL SUPPORT

To download this User's Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at: www.iLiveElectronics.com

Para descargar este Manual del Usuario en inglés, español y francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en: www.iLiveElectronics.com

Pour télécharger ce guide de l'utilisateur en anglais, espagnol ou français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur: www.iLiveElectronics.com

For Warranty Information and the most up-to-date version of this User's Guide, go to www.iLiveElectronics.com

Customer Service: 1-888-999-4215 | Email Support: prodinfo@dpiinc.com | Email Parts: partsinfo@dpiinc.com

Copyright © 2015 Digital Products International (DPI, Inc.) All other trademarks appearing herein are the property of their respective owners. Specifications are subject to change without notice.



