


Intelligent smartphone controlled plane

1.


Preparations for the maiden flight

1. Plug in the charging cable and turn on the SmartPlane using the switch on the underside.
2. Activate Bluetooth in the smartphone settings and download the SmartPlane app from the App Store.
3. Open the app. The app automatically prepares the SmartPlane for its first flight, and then connects to the plane. This process takes up to 12 minutes. The SmartPlane is ready for take-off!

UP ↑




DOWN ↓




LEFT ↙



RIGHT ↘



TOUCH & GO!




Pre and post-flight procedure

2.

Controlling the SmartPlane

TobyRich GmbH declares that this product: complies with the essential requirements of §3 and the other relevant provisions of the FTEG (Article 3 of the R&TTE Directive).

CE



—

FCC

The Declaration of conformity and further information can be found at: www.tobyrich.com

1. Turn on the SmartPlane using the switch at the bottom.
2. Open the SmartPlane app.
3. Hold the smartphone 5 cm away from the aeroplane. By sliding the throttle up, the airplane gains speed, and with a downward movement, flying speed is reduced. The altitude of the SmartPlane is regulated by the speed.

Speed/altitude: The sliding throttle in the app, located on the bottom half of the screen, is controlled with one thumb. By sliding the throttle up, the airframe gains speed, and with a downward movement, flying speed is reduced. The altitude of the SmartPlane is regulated by the speed.

Turning flight: By tilting the smartphone to the left or right, turning flight of the SmartPlane is initiated.

When you're done:

4. Close the app and turn off the SmartPlane after you are done flying.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: 2ABDG-SPBL

2. For a controlled start, the SmartPlane should be held firmly in one hand, with the smartphone in the other. The pilot gives approximately 40% thrust and throws the aeroplane gently forwards, in order to then, through light course correction, assume stable flight.

phone: +49 (0)421 218 64044 | email: info@tobyrich.com

TobyRich GmbH | Am Fallturm 1 | 28359 Bremen | Germany

TobyRich

