Quick Start Guide

Your device offers a quick and simple way to connect, navigate, discover and enjoy online digital entertainment instantly in your home.

WHATS IN THE BOX

- Device
- 2 AAA batteries

GET STARTED IN TWO EASY STEPS

- Install batteries
- Pair to your Host

INSTALLING BATTERIES

- 1. Remove the back cover of your device
- 2. Install the 2 AAA batteries included with your device in the back compartment and replace the cover.

PAIRING THE DEVICE

You must first pair your new device to your Host before using. Prior to pairing it, remember to insert the included batteries into your device. Choose the applicable pairing instructions from the options below.

A) REPLACEMENT DEVICE

- 1. Restart your Host by unplugging the USB cable and then plugging it back. After Home screen completes loading, the Host will show a pairing screen.
- 2. Press and hold the Home button on your new device for 5-10 seconds to enter discoverable mode. Your new device should automatically pair with your Host. You will see an on-screen message when it has successfully paired.

B) ADDITIONAL DEVICE

- 1. On your new device, press and hold the Home button for 5 seconds to enter discoverable mode. Your device will remain in this mode for 5 minutes.
- 2. You must now use your existing device for the remaining steps.

On your existing device, press the Home button to go to the Home screen on the Host.

- 3. Navigate to the Settings menu, and scroll right to the Controllers option. Press the select button on your device.
- 4. Select the Device's option and then select 'add new device'.
- 5. The Host will search for discoverable devices and display them in a list.
- 6. Select your new device from the list. You will see an on-screen message when it has been successfully paired.

TIPS

- if the new device does not connect, make sure that the batteries are properly installed.
- If the new device does not appear in the list of 'devices to pair', then press the Home button on the new device for 5 seconds to enter the discoverable mode.
- Always replace dead batteries with new 1.5V alkaline or 1.2V NiMH rechargeable batteries.

IMPORTANT PRODUCT INFORMATION

For safety, compliance, recycling, and other important information regarding your device, please refer to the Legal & Compliance section on the Settings menu of your Host or visit [website].

Your Device is covered by a 90-day Limited Warranty. Details are available at [website].