


INSTRUCTION MANUAL

Bluetooth Speaker **BTS662**



Safety Warnings

- Read all the instructions carefully before using the unit and keep them for future reference.
- Retain the manual. If you pass the unit onto a third party make sure to include this manual. Check that the voltage marked on the rating label matches your mains
- voltage
- The marking information is located at the bottom of apparatus.
- The product complies with the requirement of the 1999/5/EC directive. **Damage**

- Please inspect the unit for damage after unpacking.
- Do not continue to operate the unit if you are in any doubt about it working normally, or if it is damaged in any way - switch off, withdraw the mains plug and consult your dealer.

Location of Unit

- The unit must be placed on a flat stable surface and should not be subjected to vibrations
- Do not place the unit on sloped or unstable surfaces as the unit may fall off or tip over.
- The mains socket must be located near the unit and should be easily accessible

Temperature

- Avoid extreme degrees of temperature, either hot or cold. Place the unit well away from heat sources such as radiators or gas/electric fires. Avoid exposure to direct sunlight and other sources of heat.

Naked Flames

- Never place any type of candle or naked flame on the top of or near

Moisture

- To reduce the risk of fire, electric shock or product damage, do not expose this unit to rain, moisture, dripping or splashing. No objects filled with liquids, such as vases, should be placed on the unit.
- If you spill any liquid into the unit, it can cause serious damages Switch it off at the mains immediately. Withdraw the mains plug and consult your dealer.

Ventilation

- To prevent the risk of electric shock or fire hazard due to overheating, ensure that curtains and other materials do not obstruct the ventilation vents
- A minimum distance of 5cm around the unit should be maintained to allow for sufficient ventilation.
- Do not install or place this unit in a bookcase, built-in cabinet or in another confined space. Ensure the unit is well ventilated.

Safety

- Always disconnect the unit from the mains supply before connecting/ disconnecting other devices or moving the unit.
- Unplug the unit from the mains socket before a lightning storm.
- In the interests of safety and to avoid unnecessary energy consumption, never leave the unit switched on while unattended for long periods of time, e.g. overnight, while on holiday or while out of the house. Switch it off and disconnect the mains plug from the mains socket.

Mains Adapter Cable

- Make sure the unit or the unit stand is not resting on top of the mains adapter cable, as the weight of the unit may damage the cable and create a safety hazard.
- Where the plug of the Direct Plug-in Adapter coupler is used as the disconnect device, the disconnect device shall remain readily operable.

Mains Adapter

- The mains adapter will continue to draw electricity from the mains supply when plugged in the mains socket. In the interests of safety and to avoid unnecessary energy consumption, never leave the adapter plugged in the mains socket while unattended for long periods of time. Disconnect the adapter from the power supply.

Interference

- Do not place the unit on or near appliances which may cause electromagnetic interference. If you do, it may adversely affect the operating performance of the unit, and cause a distorted picture or sound.

Batteries

- Batteries used in the remote control for this unit are easily swallowed by young children and this is dangerous.
- Keep loose batteries away from young children and make sure that the battery holder tray is secure in the remote control. Seek medical advice if you believe a cell has been swallowed.
- Please dispose of batteries correctly by following the guidance in this manual
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

Supervision

- Children should be supervised to ensure that they do not play with the
- Never let anyone especially children push anything into the holes, slots or any other openings in the case - this could result in a fatal electric shock.





The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the unit's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the manual accompanying

Service

- To reduce the risk of electric shock, do not remove screws. The unit does not contain any user-serviceable parts. Please leave all maintenance work to qualified personnel.
- Do not open any fixed covers as this may expose dangerous voltages. Maintenance

- Ensure the unit is fully unplugged from the power supply before

- cleaning. - Do not use any type of abrasive pad or abrasive cleaning solutions as
- these may damage the unit's surface.
- Do not use liquids to clean the unit.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equip-

INDUSTRY CANADA

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut

fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le

Pack Contents

Make sure all of the following contents are included. - Main Unit

- Speakers
- Main Adaptor
- Audio Cable
- Instruction Manual
- Speaker connect line & Volume control knob or Switch on/off

Connection

Caution: Please turn off all the equipment power before connecting.


Connecting the Speakers

Connect the speakers to the UNIT socket using the supplied speaker connect line. Insert the R / L speaker cable input sockets on the speaker

Rotate the volume knob until you hear a click, switch on or off this unit.

Notes for connenction


- 1. Listen at a moderate volume. The higher decibel ranges are offered for those that may have already experienced some hearing loss.
- 2. Set your volume control at a low setting before connection the unit.



Connect an external audio device


The unit have 2 sets external audio input sockets, you can listen to an external audio device through this unit, connect the LINE INPUT sockets on this unit to the output sockets on external audio device.

Refer to the manual accompanying external devices for more information.



Connecting the AC/DC Power Cord

1. After you made all necessary connections, insert the AC/DC power plug into a wall outlet, and your system is ready to use.



- 1. Be sure to unplug the power cord from the outlet when going away or when the system is not in use for an extended period of time
- 2. If no source is played/no operation within 15 minutes, the unit switches to ECO power standby mode.

Play with Bluetooth device

Pair the Bluetooth-enabled devices

To connect your Bluetooth device to the unit, you need to pair the device to the unit. Pairing needs only to be done once.

- The operational range between this unit and a Bluetooth device is
- approximately 10 meters. Before you connect a Bluetooth device to this unit, familiarize yourself with the Bluetooth capabilties of the device.
- Compatibility with all Bluetooth devices is not guaranteed.
- Any obstacle between this unit and a Bluetooth device can reduce the operational range
- Keep this unit away from any other electronic device that may cause
- 1. Turn on the Bluetooth function on your device.
- 2. Search for other Bluetooth device with your device.
- 3. Select "BTS662" in the pairing list.
- 4. Enter default password "0000", or other Bluetooth devices not need to enter password, pairing directly.

LED flash light:

If no connection the Bluetooth device, the LED light flash once per 1 second. Connection already, the white light LED bright.

Note:

- The device will also be disconnected when the device is moved beyond the operational range.
- If you want to reconnect the device to the unit, place it within the
 - operational range. The device will be connected the Bluetooth device pairing already, and also enter pairing mode, other Bluetooth device can be searching for
 - connection or pairing. When the unit disconnected the Bluetooth device, it will enter pairing mode automatically, other Bluetooth device can be searching for

Listen to music from Bluetooth device

If the connected Bluetooth device supports Advanced Audio Distribution Profile (A2DP), you can listen to the music stored on the device through the unit.

1. Pair the device with the unit.

connection or pairing.

Start play music via device.

Note:

If connected other devices and Bluetooth listen to music, the files within Bluetooth device playback advanced.

Specifications

Main adaptor

: QX30W150200FG (for German) Model No.

QX30W150200FB (for UK) QX30W150200FU (for USA)

Vendor : STOS Input : AC 100-240V 50-60Hz 0.8A

: DC 15V == 2A Output General

Power Consumption : ???W

: 10W x 2 +25W RMS **Output Power** : Ф175 ×198 mm **Dimensions** Ф40 × 95 mm

Note: Design and specifications are subject to change without prior notice.

If you are having a problem with your unit, check this list for a possible

Troubleshooting

solution before calling for service.

If you cannot solve the problem from the hints given here, or the unit has been physically damaged, call a qualified person, such as your dealer, for

No power - Ensure that the AC adapter is connected securely.

- Ensure that there is power at the AC Mains.

No sound

No response from the unit

- Adjust the volume. - Speaker connections is incorrect.
- Disconnect and reconnect the AC adapter, then turn on the unit again



The symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the

For more information about where you can drop off your waste for recycling, please contact your local authority, or where you purchased your product.

Notes for battery disposal The batteries used with this product contain chemicals that are harmful to the environment. To preserve our environment, dispose of used batteries according to your local laws or regulations. Do not dispose of batteries with normal household waste.

For more information, please contact the local authority or your retailer where you purchased the product.

