

BV170

Notes

- ◆ Please use and store this product at room temperature
- ◆ Do not expose this product to rain or wet conditions
- Do not throw and drop this product to avoid product damage
 Do not self-dismantling, repair and transform the product
 Do not use chemical solvent cleaning the product

- ◆ Please don't arbitrarily discarded or placed the lithium battery in the fire in order to avoid the risk of explosion
- ◆ Long time high volume may cause hearing impairment ,please adjust the volume appropriately when listening, especially for long time listening.
- 1. Note: Improper battery replacement may cause explosion, only replace with same or equivalent battery.

 2. Don't expose the battery to sunlight, fire or excessive heat.

What's in box?

- © Speaker 1pc
- © Rope 1pc
- O USB charging /data cable 1pc
- O User manual /warranty card 1pc

Features


- O Playback music via Bluetooth connection
- O Playback music from the micro SD card
- O With card reader function
- © Support Bluetooth one button reconnection
- © Support mp3, WMA, WAV format audio files playback

Product Parameters

Shell paramers	
External Interface	Micro USB port, Micro SD card slot
Product Specification	W78*D78*H40(mm)
Speaker Net Weight	162g (Including battery inside)
Basic Parameters	
Product type	Bluetooth Speaker
Speaker driver	1.5 inch inside magnetic trumpet
Volume control way	Buttons
Bluetooth Version	Bluetooth 4.2+EDR
Storage type	Max.32GB micro SD card
Power supply	Built-In 600mAh rechargeable lithum batter
Technology Parameters	
Output power	3W THD=10%
Frequency Response	80Hz-18KHz
USB	USB2.0 compatible with USB 1.1
Charging time	Over DC 5V=1A takes around 2 hours
Playing time	Over 4 hours with Mid-volume
Functions	
File formats	Mp3,WMA,WAV
Micro SD playback	Support
Bluetooth Playback	Support
Card reader	Support

Buttons Instruction

Previous /VOL-: Press to previous song, press and hold to decrease the volume.



Next /VOL+: Press to next volume, press and hold to increase the volume.

Power button: Press and hold 2 seconds to power on/off Fast press 2 times to exchange different modes, Short press to play or pause.

USB port: Connect by USB cable to charge

Reset Hole: Press with steel sticker to restart the speaker when halted.

Micro SD card slot: Insert micro SD card to play music stored in micro SD card or connect computer to copy or delect files from micro SD card.



This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for

could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the Instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different
- from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

 The device has been evaluated to meet general RF exposure requirement. The device c an be used in portable exposure condition without restriction.

PCC ID: 2ABNJ-BV170

Warranty Card

Please fill up this "warranty card" after purchasing this product

Date of purchase:

Address:

Authorized dealer stamp: