USER'S MANUAL - ROGUE SPEAKER 04/27/14

FRONT SIDE BACK SIDE 3.750" 3.750" 95.250 mm 95.250 mm Rogue Bluetooth Speaker Instructions: 3: Phone Pairing: **CUT LINE** To ensure life of the product and personal safety, To answer calls while in pairing mode, tap the top please review all instructions prior to use. button once. To return to music, tap top button again. 1: Charging the Speaker: 4: Audio cable connect: Plug the supplied USB connector into your Bluetooth Plug the 3.5mm audio cable into your device's input jack Speaker's Charge Port (fig. 1). The LED indicator will The micro USB should then be plugged into the Rogue Bluetooth Speaker Audio Port (see fig. 1). To return to turn red when speaker is charging. Light will turn off when charging is complete. Bluetooth pairing, remove cable from speaker. Charge Port & Audio Port fig. 1 fig.3 **FOLD LINE** 194.386 mm 2: Bluetooth Pairing: **5:** Caution and Safety Press and hold the Top Button (fig. 2) for 3 seconds. The - Do not immerse in water or expose to moisture, excessive sunlight or heat LED indicator will flash blue when ready to pair. Follow - Store in a cool, dry place the prompted instructions on your device to complete pairing. To pause and play music, tap the Top Button. To - Do not expose to flame control volume, use the volume controls on your paired - Avoid excessive impact - Discontinue use if the speaker is damaged device. - Do not attempt to disassemble, modify or repair Made in China Top Button fig.2

CUT LINE

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.