



## 15 Problems and Solutions

PROBLEM	CAUSE	SOLUTION
Controller doesn't work.	Power switch is "OFF". Insert batteries into Controller improperly. Batteries lack of power.	Turn the power switch to "ON". Confirm batteries are inserted correctly Change new batteries instead.
Can not control the Quad-copter.	Power switch is "OFF".     You play the Quad-copter in strong winds weather.	Turn the power switch to "ON". Do not play in big windy place, it would make it out of control.
Quad-copter can not rise.	Main rotor blades rotate too slowly.     Doesn't fully charge the battery.	Pull up the throttle stick.     Fully charge Quad-copter battery.
Quad-copter land too fast.	Pull down the throttle stick too fast.	Skwly pull down the throttle stick till Quad-copter landing smoothly.

## 16. Caution

- 1. The control distance will be shorter when battery is weak.
  2. The Quad-copter would not fly enough high, when lack of battery.
  3. If the rotor become damaged or broken, do not fly, otherwise, it will lead to injury.
  4. If you don't use for a long time, remove all batteries out from the controller, in order
- 4. If you don't use for a long time, remove all batteries out from the controller, in order to avoid the battery leakage to large the product.
  5. Don't drop the Quast-copter from high position or crash, to avoid damage in 5. The biggest control radius of the Quast-copter is 30 meters, please uses in 30 meters area, otherwise it will be out of control when it everstep this area.
  7. Rechargeable batteries are only to be charged under adult supervision.

- Netherlageabne districts as only on or claringte unions also subservision.
   Batteria types of batteries or new and used batteries are not to be mixed.
   Satteries are to be inserted with the environment to to be mixed.
   D. Exhausted batteries are to be removered to the toy.
   The supply terminals are not to be short-circuited.
   The Supply terminals are not to be short-circuited. -6-

## 17.FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Backward welter

(Right welter)

0:0

hed, it may appears deviation, please re-start

**@**i@

0.0

0.0

-4-

- . Connect the equipment into an outlet on a circuit different from that
- to which the receiver is connected.

  Consult the dealer or an experienced radio/TV technician for help. Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
  This device complies with part 15 of the FCC Rules. Operation is
- subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition

-7-