Cisco Digital Transport Adapter HDA-RF2.2 Remote Control



The Keys Including:

1. DTA Power
2. TV Power
3. Exit
4. Info
5. 0-9 Digits
6. Enter
7. Volume +/-
8. Channel +/-
9. Last
10. Mute
11. Page+/-
12. Menu
13. Right Arrow
14. Left Arrow
15. PROG

Welcome

The Cisco Digital Transport Adapter (DTA) remote controls your Cisco DTA and the volume and power on many connected TVs. Use the instructions in this guide to set up and use your Cisco DTA remote.

Important Information About Your Remote

The remote control is initially programmed for DTA only.

If you want to program a TV into the remote. you need to go to Program The Remote to control your TV.

Batteries

Use two AAA batteries. Check the diagram inside the battery compartment to ensure the batteries inserted in the correct direction.

Note: Batteries must be replaced within two minutes of removal to retain programmed TV code.

⚠ Caution: This remote control should be kept out of reachof the children under the age of 6.

Program the Remote to Control Your TV

Program the remote control for TV following these steps:

1. Turn on your TV.
2. Press and hold "PROG" key for three seconds or until the LED turns on then press "TV" key (the LED will blink once and stay on).
3. Find the four digit device code for your TV brand. Press and release the four numeric keys.
4. If the device is valid, the LED will blink two times and the device code will be retained. If the device code is invalid, the LED will blink three times, either input another code or cancel the remote Programming by pressing the "TV" key.

Automatic Code Search

If the device code for your TV brand can't be found in the list, please try to search the device code database following these steps:

1. Turn on TV device manually.
2. Press and hold "PROG" key for three seconds or until the LED turns on.
3. Press "CH+" key to enter the automatic code search mode. The remote will transmit the TV power code every 1.5 seconds and the LED will blink at the same time. When you see the TV device is powered off, the remote has found a valid group device code.
4. Press "TV" key to store the code and to exit the search mode.

Pairing between Remote Control and Target Device (DTA)

Your remote control can be paired with the DTA,allowing you to place the DTA out of the line of sight (behind your TV,for example)

1. Turn on the target (DTA) device.
2. Press and hold "PROG" key for three seconds or until the LED turns on, then press "INFO" key.
3. The LED on the remote control blinks slowly to indicates the device is In pairing mode.
4. The DTA will prompt the user, via a message on the TV to enter a unique four digit number.
5. If the three digits entered are correct, the target(DTA)will prompt the user that pairing is successful.
6. If the three digits entered are incorrect, the target (DTA) will prompt the user that pairing fails and to try again until the correct code is entered.

Unpairing Scenario

Once paired with the target (DTA), the remote can be unpaired using the following sequence:

1. Press and hold "PROG" key for three seconds or until the LED turns on.
2. Press <9> <8> <7>, the LED will blink two times quickly to show the procedure is successful.

Switching between DTA and TV mode for Volume/ Mute Control

To control DTA Volume and Mute, use the following steps:

1. Press and hold "PROG" key for three seconds or until the LED turns on.
2. Press "VOL-" key.

To control TV Volume and Mute, use the following steps:

1. Press and hold "PROG" key for three seconds or until the LED turns on.
2. Press "VOL+" key.

Default state: the remote is initially assigned to control DTA Volume and Mute.

Trouble Shooting

If there is no response when you press any key on the remote control, please check the the following items before calling for service.

Check the Batteries

Are the batteries inserted correctly? Are the batteries drained? You may try to replace the batteries with the new ones.

Check the DTA

Is the DTA connected to the input of the TV? Is the DTA connected to the cable wall outlet? Is the DTA power cord connected to the power outlet?

Check the TV

Is the TV power cord connected to the power outlet? Is the TV tuned to the correct channel to work with the DTA?

Check the TV Code List

Is your TV's brand included in the code list? Sometimes there is more than one code for a TV's brand, please try to use different codes.
If you can't find your TV's brand in the list or you can't program your remote manually, you should perform the following steps:
-Run Auto Search Mode.

TV Brand and Code List

888	0471 0701
A. R. Systems	0061 0601 0861 0661 0751
Accent	0021 0061 0861
Acer	2961 3281
Acoustic arch	2911
Acura	0021
Adcom	1061
Addison	0931 0201
ADL	2181
Admiral	0171 0231 0821 0471
Advent	1901
Adyson	0081
AEA	0061 0861
AEG	0861 1031 1951
Affinity	4071 0881
Agashi	0471 0081
AGB	1611
Aiko	0021 0061 0861 0641 0041 0711 0121 0231 0011 0471 0081
Aim	0061 0121 0701 0861 1521 0341 1701 1301
Airis	3221
Aiwa	0981 2341 1981
Akai	0021 0231 0341 0861 0061 0641 2431 0711 1481 0011 0041 0351 1241 2641 0121 1521 0701 1421 1351 1611 1341 0991 0771 0081 1091 0471 0281 0651 1031 2341 0761 1151 2271 2351

Akashi	1631 0021
Akiba	0351 0481 0751 0061 0861
Akira	0821
Akito	0061 0861
Akura	0061 0351 0471 0861 1271 0701 0021 0481 1351
Alaron	0081
Alba	0021 0061 0861 0051 1351 0351 0821 1371 0641 1271 0621 0081 0431 0231 0811 2341 0731 2351
Alfide	1241
Alkos	0041
All-Tel	1881
Allorgan	0081
Allstar	0061 0861
Ambassador	0271
Amplivision	0081 1371 0531
Amstrad	0021 0271 0061 1611 0471 0671 0641 0351 0701 0711 0861 1151
Anam	0061 0861 0021 0501 1871
Anam National	0061 0861 0501
Andersson	1951
Anglo	0021 0471
Anitech	0021 0471 0061 0861 0481 0191
Ansonic	1371 0061 0861 0021 1271 0661 0231 0191 0891 0461 0431 1621
AOC	0021 0101 0171 0201 0281
Aolingpike	0471 0701
Apex	1631 4771 0791 0041 1961 0881
Apollo	0761
Arc en Ciel	0211
Arcam	0081
Ardem	1221 1351 0061 0861
Ario	5101 0281 4401 0881
Aristona	0861 0061
Arthur Martin	0231
ASA	1621 0181 0581 0111
Asambal	0861
Asberg	0061 0861 0191
[illegible]	0021
Astra	0061 0861
Asuka	0351 0081 0471 0481
Asus	1021 3621
ATD	1301
Atlantic	0061 0861 0081 0531 0461
Atori	0021
Auchan	0231
Audiosonic	0021 0061 0661 1721 0211 0861 1351 1341 0081 1371 0561 0471 0351 1221
Audioton	0081 1221 1371 0471
Audioworld	1301
Aumark	0101
Autovox	0081 0431
AVP	2341
AWA	0021 0031 0051 0661 0701 0061 0861 1031 0081 0201 0471 3021
Axxent	0021
Axxon	1351
B&D	2181
Baier	1901
Baihe	0021 0471 0701
Baile	0001 0021 0661 1211
Baird	0211 2651 0301 0121 0131 0081 0341 2091
Bang & Olufsen	0951
BaoHuaShi	0471 0701
Baosheng	0021
Barco	0231
Basic Line	0021 0661 0061 0351 0231 1271 0861 0481 0081 0751 0341
Bastide	0081
Bauer	1701 0021
Baur	0021 0061 0231 0011 0861 1981
Bazin	0081
Beaumark	0281
Beijing	0001 0021 0341 0371 0471 0661 0701 0801 1211 0041

Beko	1371 1351 0041 1221 1341 0061 0821 0861 1031 1821
Belson	2071 2711
Bennett	0861 0061
BenQ	2511
Beon	0061 0861 0821
Berthen	1271
Best	0561 1371
Bestar	0061 0861 1371 0661
Bestar Daewoo	0661
Binatone	0081
Black Diamond	1001 1721 0861 0041 1521 1951
Black Panther	0191
Black Star	0431
Black Strip	0041
Blackway	0481 0351
Blaupunkt	0011 0551 0401 0331 0751 0261 0051
Blue Sky	0061 0351 0861 1271 1351 0811 1341 2411 0481 0751 2341 2071 1821 2971
Blue Star	0481
Bondstec	0431
Boots	0021 0081
Bosch	0401 0531
BPL	0061 0481 3111 0861 0341 2551 2691 2791 3131
Brandt	0211 1061 0441 0491 2651 0961 2981
BrandtElectrique	0491 0441
Brinkmann	0061 0861 1271 0821 1221
Brionvega	0061 0671 0861
Britannia	0081
Brother	0471
Bruns	1221
Brokssonic	4841 4391 4071 4441
BSR	0231
BTC	0351
Bush	0021 1001 0051 0861 0061 1201 3231 0351 1351 0481 1271 0621 0231 0641 0661 1301 0471 0811 0341 0081 2521 2341 1591 2271
Caihong	0021
Caishi	1631
Canton	0351
Capsonic	0471
Carad	1011 0061 0861 1271
Carena	0751 0061 0861
Carrefour	0051 0111 0061 0861
Carver	0261
Cascade	0021 0061 0861
Casio	0061 0861 0231
Cathay	0061 0861
CCE	0061 0081 0861 2641
CE	0861
Celestial	1711 1721 0041
Centrex	1631
Centrum	0861
Centurion	0061 0861
Century	0431
CGE	0141 0251 0431 0821 1371 0231
Changcheng	0001 0021 0471 0661 0701 1211
Changlei	0021 2641 0661
Changfeng	0471 0701 1521
Changhai	0021 2641
Changhong	0041 1721 0021 0471
Chengdu	0021
Ching Tai	0021
Chun Yun	0021
Chunfeng	0021 0471
Chung Hsin	0201 0051
ChungFeng	0701
Chunsun	0021
Ciil	0311
Cimline	0021 0351
Cinema	1241
Cinex	1151 0861
Citizen	0101
City	0021
Clarivox	0061 0821 0861 0111 0191
Clatronic	0061 0431 1371 0641 1351 0351 0471 0861 0081 0021 0191 0531 1151 1031 1951
Clayton	0861
CMS	0081
CMS Ightec	0081

Cobolt	1631
Coby	0281 2801 3871 3881
Combitech	2341
Concorde	0021
Condor	0531 0061 1371 0861 0081 0021 0481 0191 0431 0821 0891 0231 0471
Conia	1531 0041 2711 1721
Conrac	1821
Conrad	0061 0861
Conrowa	0021 0471 0701 1301 1521 0261
Contec	0021 0081 0051 0031 0471 0061 0861
Continental Edison	0211 0491 0811
Cosmel	0021 0561 0061 0861
Crosley	0141 0431 0251 0231
Crown	0021 1331 0061 1371 1221 0861 0821 0811 1351 1031 1241 1341 0341 0931
Crown Mustang	1241
CS Electronics	0081 0351 0431
CTC	0431
CTX	2511
Curtis	1981 3631
Curtis Mathes	0101 0171 0241
Curtis Young	1981
Cybertron	0351
Cytronix	2321
D-Vision	0061 0861
Daewoo	1111 1711 0661 2411 0861 0061 0021 0351 0081 0281 0261 2341 1931 0201 3361 1901 1881 1241
Dainichi	0351 0081
Daitsu	0411
Danichi	0351
Dansai	0061 0861 0471 0041 0021 0051 0081 0541
Dansette	0701
Dantax	1371 1221 1351 1031 1341 2341
Datsura	0341
Dawa	0021 0061 0861
Daytek	1301 2101 3021 1241
Dayton	0021 2101
Daytron	0021 0061 0061 0861
Dayu	0661 1111
de Graaf	0341 1071 0231
DEC	1661 1131
Decca	0061 1121 1611 0861 1081 2341
Deitron	0061 0861 0661 0351
Dell	2281
Denko	0471
Denver	0061 0861 1031 2061 1181
DER	0301
Desmet	0531 0061 0861 0021
Diamant	0061 0861
Diamond	0471 1101 0021 1731 0081 0641 1631 1121
Digatron	0061 0861
Digihome	1951
Digiline	0061 0861 0181 1271
DigiLogic	0061 0861
Digitex	1721
Digitor	0061 0861 1941 1871
Digivision	0231
DigiX	1931
DiK	0061 0861
Dixi	0021 0061 0861 0431 0081
DL	1631 0061 1281 1881
DMTECH	3411 2251
Domeos	1271
Domland	0691
Dongda	0021
Donghai	0021
Dream Vision	2481
DSE	1941 1171 0861 1721
DTS	0021
Dual	0861 0081 2651 0061 0661 0601 0691 0031 1091 1951
Dual Tec	0081
Dumont	0111 1621 0191 0081 0121
Dunai	0231

Durabrand	0061 0281 0861
Dux	0061 0861
DVX	1631
Dynatron	0061 0861
Dynex	4061 4071 4641
e:max	1031
Easy Living	2271
Ecco	1581 1301
ECE	0061 0861
Edison-Minerva	0811
Elbe	0461 0721 0671 1371 0231 0061 0861 0351 0011 0891 1011 0081 1611
Elbe-Sharp	1611
Elcit	0431 1611 0191 0231
Elekta	0021 0061 0861 0471 0481
Element	0281 2801 4401 0911
Elfunk	0341 0861
ELG	0061 0861
Elin	0061 0081 0861 0181 1621 0231 0021
Elite	0351 0061 0531 0861
Elman	0191
Elta	0021 0471 0081
Emco	0431
Emerson	0271 0281 1351 0431 0061 0861 0641 0111 0481 0531 0231 2411 1221 1371 0541 1271 4671 4021 4071 4521 4661 4721 4201 4421 4461 4651 4431 4031 4441 4681 4631 4701 4711 4341 4561 4311 4471 4481 4201 4571 4601 4351 4721 4741 4821 4841 4861 4871 4881 4911 4941 0591
Emperor	0481
Enzer	1521
Erac	2071
Erres	0061 0861
ESC	0061 0861 0081
Estele	0231
eTEC	4641 3641 0881
Ether	0021
Etron	0001 0021 0061 0861 0231 1721
Eurofeel	0471 0081
EuroLine	0061
Euroman	0471 0061 0861 0081 1371
Europa	0061 0861
Europhon	0061 1611 0191 0231 0081 0861 0431
Evesham	2271
Excel	0061 0861
Expert	0461 0231
Exquisit	0061 0861 0431
Fagor	0061 0861
FairTec	2071
Family Life	0061 0861
Feilang	0021
Feilu	0021
Feiyan	0471 0701
Feiyue	0021
Fenner	0661 0021
Ferguson	0061 0131 0211 1061 0491 0441 2651 0961 0301 0861 0041 0931 1621 0201 0231 0731 3211 2341
Fidelity	0231 0081 0861 0061 0641 0701 0301 0471 2341
Filsai	0081
Finlandia	0341 0581 0231 0121 0491 2651 0091
Finlux	0061 0181 0111 1621 0121 0861 1351 0581 0891 1611 0081 0231 1341 0191 1091 0841 0771 0761 0821 1031 1821
Firstar	0021
Firstline	0021 0061 0861 0081 0661 0431 1271 0541 1351 0231 2411 0191 0891 0121 0341 2071 1821 2971 1951
Fisher	1621 0081 0051 0341 1371 0941 0091 0231 0121

Flatdisplays	2701
Flint	0061 0751 0861 1011 0121 0351 0471
FNR	0191
Fonda	0751
Force	1951
Forgestone	0301
Formenti	0061 0231 0531 0861 1221 0081
Formenti-Phoenix	0081 0531
Fortress	0171
Fraba	0061 0861 1371
Friac	0021 0061 0191 1371 0861 1011
Frontech	0231 0431 0471 0081 0021
Fujimaro	1881
Fujitsu	1261 0121 0191 1061 0001 0231 0021 0601 0061 0861 0461
Fujitsu General	0021 0081 0231
Fujitsu Siemens	2321 2271 3001 1951 1821
Funai	1271 0471 0701
Furi	0471 0701
Furichi	1631
Futronic	0471 1661 1631
Future	0061
G-Luxon	3221
Galaxi	0191 0061 0861 0231
Galaxis	1371 0821 0061 0191 0861
Galeria	0021
Gateway	2511
GBC	0231 0021 0661 0351
GE(General Electronic)	2651 0281 0481 0261 0421 0211 0441 1061 1311 4201
Geant Casino	0231
GEC	0061 0231 0121 0081 1611 0861
Geloso	0021 0431 0231 0661
General	0211 0491
General Tehnic	0021
Genesis	0021 0061 0861
Genexxa	0231 0351 0061 0861 0701 0021
Gericom	1881 2321 2181 1931
Gevalt	2071
Giant	0081
Gintai	1391
Goldfunk	1271
Goldhand	0081
Goldline	0561
GoldStar	0001 0061 0021 0281 1371 0651 0081 0431 0861 0231 0211 1031 0071 1351 1341 0751
Gooding	0811
Goodmans	1111 0051 2271 0061 0121 0861 0081 1351 2651 1271 0641 2411 0661 0471 1611 0021 0811 0041 0771 0961 0441 0351 2341 0891 1211 2521 1931 1281 3021
Gorenje	1371
GPM	0351
GPX	0291 4661
Gradiente	0931 0261 0061 0861
Graetz	0231 1351 0641 0061 0341 0861 1951
Gran Prix	1151
Granada	0061 0091 0121 0861 0341 0371 0081 1611 0201 0051 0761 0441 0961 0231 0361 2651
Grandin	0061 0481 0861 0021 0231 1011 1351 1341 1271 0661 0531 0351 0751 1881 2071 1931 2101 3031
Gronic	0191 0081 0231
Grundig	0011 0021 0051 0061 0111 0281 0721 0731 0811 0041 0861 1241 1281 1371 1471 1301 0891 2341 2351 2651 2071 3021 3441
Grunkel	1951
H&B	1821
Haaz	1301
Haier	1301 0471 1601 4981 4921

Haihong	0021
Haiyan	0471 0701
Halifax	0471 0081
Hallmark	0281
Hammerstein	0471 0101
Hampton	0081
Hanimex	0351 2341
Hankook	0281
Hannspree	3911 0921
Hanseatic	0061 0531 0861 0231 1211 0481 0691 1111 1371 0021 0081 0651 1351 1821 1221
Hantarex	0021 1611 0061 0861 0191 2951 3141
Hantor	0061 0861
Harsper	1881
Harwa	1581 2091
Harwood	0021 0701 0061 0861 0811
Hauppauge	0061 0861
Havermy	0171
HCM	0021 0481 0701 0061 0861 0081 0351 0821 0471
Hedzon	0861 0061
Hema	0081 0021
Hicon	3191
Hifivox	0211
Higashi	0081
Highline	0471 0061 0861
Hikona	0351
Himitsu	1601
Hinari	0021 0341 0051 0061 0861 0351 0231 0621 0731 0081 0471 2341
Hisawa	0481 0351 0751 1011 2341 1351
HISense	2971 0341 0021 0041 1521 0261 1631 0861 0471
Hitachi	0361 0021 0051 0071 0201 0761 0231 2651 0081 0211 0321 0281 1611 0121 0781 0861 0061 0041 1111 1281 0261 0181 0841 0771 2451 1951 1911 4271 4021 4241 4161 4551 4541 4301 4311 4921 4931
Hitachi Fujian	0201 0361
Hiteker	0411
Hitsu	0021 1011 0751 0351
HMV	0301
Hoher	1351 0861 1881 1951
Home Electronics	1031
Honeywell	0471
Hongmei	0021 0171 0471
Hongyan	0471 0701
Hornyphon	0061 0861
Hoshai	0351 0751 0481
Hua Tun	0021
Huafa	0021
Huanghaimei	0021
Huanghe	0021
Huanglong	0021
Huangshan	0021 0471 0701
Huanyu	0081 0661 0471
Huaqiang	0471 0701
Huari	0471 0701
Hugoson	1961 2181
Hygashi	0081
Hyper	0021 0081 0431
Hypersonic	0231
Hypson	0061 0471 0861 0481 1351 1341 0081 0751 2341 1271 1221
Hyundai	0061 1881 3201 0861 1301 1631 1521 2751 2241 1901 3361 3031 3311
Iberia	0061 0861
ICE	0081 0471 0061 0641 0021 0861 0351
Ices	0351 0081
Ict	0061 0861
Igo	0931
IISonic	3021
Iiyama	2151 1201
Imperial	0061 0141 0231 0431 1371 0821 0251 0861 0891
Imperial Crown	0001 0021 0471 0661 0701 1211
Indiana	0061 0861
InFocus	2021 1881
Ingelen	0231 0811 1011 1351

Ingersoll	0021
Inno Hit	0021 0121 1611 0061 0861 0351 0081 0431 0191 0481 1951
Innova	0061
Innovation	0861 0061
Innowert	1881 2321
inotech	1581 1721
Interactive	0061 0861 0401 0231 1371 0211 0891
Interbuy	0021 0061 0471 0431 0861
Interfunk	0061 0231 0861 0431 0401 1371 0211 0551
Internal	0061 0861 0661 2411
International	0081
Intervision	0061 0481 0081 0191 0751 0471 0641 0651 0861 1221 1371 0691 0811 0351 0231 0431 0021
Insignia	4061 4411 4621 4071 4491 4681 4371 4961 3891 4641 4991
Irradio	0021 0061 0861 0351 0431 0641
IRT	1301
Isukai	0351 0061 0861 0481 0751
iSymphony	0411
ITC	0081 0531
ITS	0061 0641 0351 0481 0471 0081 0021 0861
ITT	0231 0771 0761 0301 0581 0341 1011
ITT Nokia	0231 0761 0771 0581 0341 1031 1011 1091
ITV	0471 0061 0861 0431 0661
JDV	0861
Jean	0051 1391 0021
JEC	0041
Jialicai	0021 0471 0701
Jinfeng	0341 0371
Jinque	0021 0471 0701
Jinta	0021 0471 0701
Jinxing	0021 0471 1301 0041
JMB	0061 0861 1111 0661 0731 2341
JNC	3411 1901
Jocel	1331
Jubilee	0861
Juhua	0471 0701
JVC	0051 0171 0301 0351 0641 0821 0041 1031 0501 0931 1261 1451
Kaige	0021 0471 0701
Kaisui	0021 0351 0481 0061 0081 0861 0751
Kambrook	0651
Kamp	0081
Kanghua	2551
Kangli	0001 0021 0471 0661 1211
Kangyi	0021 0471 0701
Kapsch	0231 0461 1621
Karcher	0061 0861 1371 1011 0231 0481 0191 0471 1591 1351 1031
Kathrein	0861 0061
Kawa	0641
Kawasho	0081
KB Aristocrat	0231
Kendo	0061 1011 0671 0861 0231 1371 0651 0891 0191 0431 1151 1221
Kennedy	0231 0721
Kennex	0861
Kenwood	0181
KIC	0081 2641
Kingsley	0081
Kiota	0001
Kioto	0861 1301
Kiss	1681
Kiton	0861 0061 1271
KLL	0061
Kneissel	0061 0461 1371 1011 0891 0661 0861 0721 0671 2341
Kobra	3191
Kolin	0201 0051
Kolster	0061 0861 0191 0431 0351
Kongque	0021 0471
Konichi	0021

Konka	0061 0861 0641 1351 0821 0351 1121 1281 1531 1601 2711 1661
Kontakt	0811
Korpel	0061 0861
Korting	1371 0531
Kosmos	0061 0861
Kotron	0701 0471
Koyoda	0021
KTV	0081 5101
Kuaile	0021 0471 0701
Kuba	0231
Kuba Electronic	0231
Kulun	0021
Kunlun	0341 0371 0471 0661 1211
Kyoshu	0701 0821 0471
Kyoto	0231 0081
L&S Electronic	1881 1351
LaSAT	1221 1371
Lavis	0861 0061 0231
Leader	0021
Lecson	0061 0861
Legend	0021 0561
Lemair	0891
Lenco	0061 1391 0021 0231 0061 0661 1621 1281
Lenoir	0021
Lesa	0431
Levis Austria	0061 0861
Lexsor	2091
Leyco	0061 0471 0121 0861
LG	0001 0021 0061 0081 0101 0201 0211 0231 0281 0431 0651 0861 1031 1301 1341 1351 1371 1761 0081 2071 2801
Liesenk & Tter	0061 0401 0861
Liesenkotter	0061 0401 0331 0861
Lifetec	0061 0021 0861 0661 1271 0351 0471 1261 2271 1351
Lloyd's	0001 0021
Local Calcutta TV	0861 0751 0341
Local Chennai TV	0641 0861 0471 0991 0751 2821 0021
Local Delhi TV	0041 3231 0861 0751
Lodos	0861 1951
Loewe	1641 0061 0861 1371 0671 1611
Logik	0001 0031 0101 1301 1581 0021 0301 0471 0641 1931 2181 0861
Logix	1271 0861
Longjiang	0471 0701
Luker	0861
Luma	0061 0231 0891 0861 0661 0071 0671 0461
Lumatron	0061 0861 0671 0231 0461 0081 0471 0131
Lux May	0061 0021 0861
Luxor	0321 1951 0771 0841 0341 0231 0581 0761 0861 0081 1091
LXI	0281 4201 0041 4251 4081
Madison	0061 0861
MAG	4401
Magnadyne	0191 0431 1611 0231
Magnafon	0191 1611 0081 0131
Magnavox	0061 0861 0051 1301 1631 5101 4661
Magnum	1151 1351 0061 0861 1341
Mandor	0471
Manesth	0061 0081 0861 0471 0531 0041 0231
Manhattan	0061 1901 0861 1271 0411 0231 1591
Marantz	0061 0861 0701 3311 5101 4081
Mark	0061 0861 0081 0661 0021 1351 1341
Master's	0861 0061
Masuda	0351 0641 0021 0471 0061 0081 0861
Matsui	0021 0061 0031 0861 0041 0811 0051 0121 0271 0341 0621 0081 0641 0731 0711 1611 0751 0231 0091 0011 0441 1351 2341
Matsushita	0501
Matsuviama	1281
Maxam	0471
Maxdorf	1581
Maxim	0861
MCE	0021
ME	0861

Mediator	0061 0861
Medion	0061 1271 1351 0861 1821 1301 2521 2271 1931 2341
Megas	1011
Megatron	0281
MEI	0861 0061
Meile	0471 0701
Melectronic	0021 0581 0061 1621 0211 2651 0231 0431 0181 0081 0491 0661 0771 0841 0891 0861 1111 0011 1211 1351
Memorex	0021 0281 0861 0501 0101 4071 4661
Memphis	0561 0121 0021
Mercury	0001 0061 0021 1301 0471 0861 2641
Merritt	0231
Metronic	1061
Metz	0681 0741 1511 0631 1951 0011 0061 0861 1281 1271 3321
MGA	0281 0061 0861 0351 1621 5101
Micromaxx	0061 0861 1271 0891 1821
Microstar	1821
MicroTEK	1721
Midland	4201 4251
Mikomi	1951
Minato	0061 0861
Minerva	0111 0811 0011 1611 0201
Minoka	0701 0061 0861
Mirror	2521
Mistral Electronics	0301
Mitsubishi	0201 0171 0061 0281 0051 0301 0011 0861 0341
Mitsuri General	0231
Mivar	1611 1371 1141 0081
Monaco	0021
Morgan's	0061 0861
Motorola	0171 4401
Moxell	4401
MTC	0101 1371 0061 0231 0081 5101
MTlogic	1351 0861
Mudan	0021 0341 0371 0471 0701
Multibroadcast	0301
Multistandard	0191
Multitec	0061 0861 1221 1271
Multitech	0021 0191 0231 1221 0061 0081 1371 0001 0431 0471
Murphy	1621 0081 0121 0231
Musikland	0061 0351 0431 0861
MyCom	3021 0281
Myryad	0861 0061
NAD	0241 0281 0231 0041
Naiko	0061 0861 1031
Nakimura	0661 0061 0861
Nanbao	0021 0471 0701
Nansheng	0471 0701
Naonis	0231
Narita	0861
NAT	0371
National	0371 0341 0041
naxa	0901 3651
NEC	0021 0031 0051 0061 0081 0261 0291 0471 0521 0661 0701 0751 0861 0041 0931 1211 1281 1561 2481 5101 4081
Neckermann	0061 0011 1371 0861 1981 0551 0231 0401 0821 0431 0081 0891 0531
NEI	0061 0561 0861 0641 0231
Neovia	1881 3411 3001 2071 1901 3021 3041 2951
Nesco	0431 2341
Netsat	0061 0861
Network	0561
Neufunk	0061 0021 0861 1011 0351 0481 1351
New Tech	0061 0021 0861 2651 0081
New World	0351
Newave	0021 1391 0281 0171
Nfren	1681
Nicamagic	0081
Nikkai	0121 0041 0351 0061 0061 0001 0471 0561 0021 0051
Nikkei	1351
Nikko	0281 5101
Nippon	0751
Nishi	0801
Nobliko	0191 0111 0081

Nogamatic	0211
Nokia	0231 0761 0771 1031 0841 1091 0341 0661 0581 0531 1011 0211
Norcent	1631 2981
Nordic	0081
Nordmende	0211 1351 1631 0491 2651 0961 0011 0061 0861 0441 0231 2271
Norfolk	0231
Normerel	0061 0861
Novak	0061 0861
Novatronic	0061 0181 0661 0861
Novita	3041
NU-TEC	0751 1301 1721 0061 0861
Nurnberg	0231
Oceanic	0231 0341 0761 0771
Odeon	0471
Okano	1371 0061 0861 0471 0121 0021
Olidata	3021
Omega	0471
Omni	1631 1301
Onida	0861 0931
Onwa	0641 0991 0351 0711 0191
Opera	0061 0861
Optimus	0501 0241
Optoma	3911 3951
Optonica	0171
Orbit	0061 0861
ORcom	3071
Orion	0061 0271 0731 0621 0861 2351 1351 0531 0541 0031 1611 0021 0191 0471 0701 2341 1931 2091 4071 4661
Orline	0061 0351 0861
Ormond	1271 0861 0061
Orsowe	1611
Osaki	0121 0351 0081 0471 0701 0061 0661 0621 0861
Osio	0061 0861
Oso	0351
Osume	0121 0051 0351 0061 0861
Otto Versand	0051 1981 0061 0081 0531 2651 0171 0861 0231 0011 0211 0371 0431 0021 0481 1611
Pace	2341
Pacific	0061 0861 1351 0731
Pael	0081
Palladium	1371 0061 0821 0861 0891 1351 0011 1981 0551 0431 0401 0231 0081
Palsonic	0471 0701 1581 0061 1601 0081 0651 0351 1301 0861 0001 0821 2761 1591 2091
Panama	0021 0081 0471 0061 0861 0431
Panashiba	0001
Panasonic	0001 0061 0101 0201 0231 0281 0341 0371 0631 0041 0861 0501 1611 1861 2361 2551 1491 1651
Panavision	0061 0891 0861
Panda	0021 0341 0371 0471 0701 0041 1301
Papouw	0061 0861
Pathe Cinema	0231 0081 0531 1371
Pathe Marconi	0211
Pausa	0021
Pegasus	0031
Peng Sheng	1631
Penney	0101 0281 4201 0041 5101 4251 4081
Perdio	0531 0121 0231 0061 0081 0481 0861
Perfekt	0061 0861
Philco	0251 0141 0821 0431 0061 0861 0231 1371 0281 0781 5101
Philex	0301 0231
Philharmonic	0081
Philips	0021 0061 0151 0551 0201 0281 0011 0201 0201 0331 0391 0661 0861 1081 1391 1571 2511 2651 3451 3541 3901 3941 3431 5001 2011 5021 4161
Phocus	0861 1351
Phoenix	0061 0861 1371 1221 0231 0121 0081 0531
Phonola	0061 0861 0301 0081
Pilot	0861 0061 1331 5101

Pioneer	1551 0031 0241 0061 0211 0261 0231 0861 0491 1371 2651 1221
Pionier	1371 1221
Planar	0971 1051 1101
Plantron	0061 0861 0471 0021
Playsonic	1351 0061 0081 0341 1341
Policom	0191 0211 0231 0111 0141 0251 0011
Polytron	0481
Polaroid	4331 4401 0061 4451 4491 2091 4531 2711 4801 4951 0041
Poppy	0021
Portland	0661 2411
Powerpoint	0811 0061 0861 1301 2711
Prandoni-Prince	0431 1611 0231
Precision	0081
Premier	0021 0471
President	1631
Prima	0021 0471 0701 2001
Princess	1301
Prinston	0861
Prinz	0121 0231 0321
Profex	0021 0231
Profi	0021
Proline	0061 0541 0861 1061 1111 0891 0121 3021
Proscan	3791 5011 0571 3981 4201 4251
Prosonic	0061 0861 1371 0661 0641 1271 1351 0081
Protech	0021 0061 0861 0191 0081 0431 0471 0561 0821 1271 0481 0231 1221
Proton	0001 0281 0021 0101 5011
Proview	4401
Provision	0861 0061 1351
PVision	2071 1901
Pye	0061 0861 0661 0701
Pyle	0291
Pymi	0021
Qingdao	0341 0371 0471 0701
Quadral	0351
Quasar	0431 0501 1881 0021 1231
Quelle	0031 0061 1981 0111 0141 1621 0231 0701 0211 0011 0051 0081 0431 0401 0251 0331 0181 1271 0861 0551 0471 0581 0021
Questa	0051
R-Line	0061 0861 0231
Radialva	0211 0351 0231 0061 0861 0491 0561
Radiola	0061 0861 0081
Radiomarelli	1611 0431 0061 0861
RadioShack	0061 0861 0281 4201 5101 4251
Radiotone	0021 0061 0861 1371 0821 0701 1151 1271 0471
Rank	0111
Rank Arena	0051 0991 1521 1251
RBM	0111
RCA	1061 0101 0171 0281 0961 0441 0411 2651 0241 1521 4201 4251 4261 4211 4581 4131 4021 4221 4231 4171 4501 4611 4281 4291 4311 4321 4591 4831 4851 4891 4901 3981 4081
Realistic	0281 5101
Recor	0061 0821 0861
Rectiligne	0061 0861
Rediffusion	0231 0051 0581
Redstar	0061 0861
Reflex	0061 0861 1271
[illegible]	1001 1201 1211 2101 2171 2321
Reoc	1351 1111 2411
Revox	0061 0861 1371
Rex	0231 0461 0471 0891 0431
RFT	1371 0121 0471 0061 0861 1221
Rhapsody	0081
Ricoh	0061 0861
Rinex	1581 0821
Roadstar	0021 0861 0351 0471 0821 0061 1351 1271 0481 2341 2061 2521
Rodex	0061 0861
Rover	0051 1911
Rowa	0061 0471 1301 0021 0081 1331 1281 0861
Royal Lux	1371 0701 0441

Rokopa	0061 0061
Runco	5101 0501 1181 1191
Saba	0211 1061 0231 0491 0961 0441 2651 1611 0851 0501 1351
Sagem	1011 0751 0481 1771 0411 3351
Saige	0021
Saisho	0021 0031 1611 0271 0471 0081 0231
Saivod	0061 0861 1951 1271 1331
Sakai	0231
Sakyno	0751
Salora	0231 0321 1611 0341 0771 0861
Salsa	0441
Sambers	0191 1611
Sampo	0021 0051 0171 0281 0501 1391 5101 1521
Samsung	0121 0281 1281 0041 2671 4021 4131 4141 4151 4161 4171 4181 4191 0021 0061 0081 0101 0171 0231 0341 0371 0471 0801 0861 1061 1371 2641 1501 0411 3661 3821 3841 3861 5021
Sandra	0081
Sanjiar	0471 0701
Sansui	0061 0861 1421 1301 0641 1411 1871 2821 0991 0751 1941 1521 2071 4071
Santon	0021
Sanyo	0341 1391 0931 0051 0091 1371 0121 1621 0081 0941 0701 0021 0041 0231 0061 0201 0861 1221 0261 3811 0281 3921 4071
Sanyuan	0021 0171
Save	0061 0861
Saville	2341
SBR	0061 0861 0301
Sceptre	3971 4771 5111 1921 1981
Schaub Lorenz	0231 1351 1031 1221 0661 2071
Schneider	0061 0861 0351 0431 0641 1271 0691 0601 0461 2651 0081 0231 1151 1351 2411 2541 0111
Scotch	0281
Scotland	0231
Scott	2061 0281 4661
Sears	0281 4201 0041 4661 4251
Seaway	1111
Seelver	0861 0061
SEG	0051 0061 0081 0861 0471 1271 0811 0021 0231 1111 0191 0431 0671 1951 0351 2411 1351
SEI	0191 0271 1611 1981 0231 0061 0861
Seiki	1981 0911
Sei-Sinudyne	0191 1611 1981 0061 0861
Seitech	2181
Seleco	0231 0461 0671 0891 0641 0051 0471 0581 0721 3911
Sencora	0021
Sentra	0041 0351 0021
Serino	1011 0751 0081 0171
Shancha	0471 0701
Shanghai	0021 0341 0371 0471 2341 0701
Sharp	4001 4421 4031 4011 4441 4051 0051 0071 0301 0331 0451 1611 0931 1151 1951 0021 0001 0551 0281 5031 4161
Shen Ying	0021
Shencai	0021 0471 0701
Sheng Chai	0021
Sheng Chia	0021 0471
Shenyang	0021 0471 1521
Sherwood	0021
Shintoshi	0061 0861
Shivaki	0061 0861 0731 0661 0081
Show	0821 0021 0121
Siarem	0191 1611 0231
Siemens	0061 0011 0551 0401 0331 0861 0231
Siera	0061 0861 1281
Siesta	1371
Sigmac	0041

Silo	0041 1041
Silva	0061 0861 0081 0231 1151
Silva Schneider	0861
Silver	0051 0061 0751 0861 1341 0231
SilverCrest	0861 0061
Singer	0021 2431 0061 0861 0191 0431 0721 0441 0231
Sinotec	1581
Sinudyne	0191 0271 1611 0231 1981 0061 0861 2341
Sky	0061 0481 1931 0281 0861 3071
Skymaster	0181
Skysonic	1521
Skyworth	0061 0861 0021 0471 1301 1411 1521
Sliding	1881 1931 2101 3031 1681
SLX	1271
Smaragd	0811
Soemtron	1881 2321
Sogera	0531
Solavox	0231 0121 0061 0861
Sonawa	0351
Sonber	0191
Songba	0021
Soniko	0061 0861
Soniq	3191
Sonitron	0341 1371 0081
Sonneclair	0061 0861
Sonoko	0021 0061 0861 0471 0481 0081
Sonolor	0231 0141 1981 0461
Sontec	0061 0861 1371 0021
Sony	0031 0051 0061 0141 0171 0191 0261 0611 0861 0501 1981 4381 4751 4761 4781 4791 4811 0161 0221 0381 0421 0521 0831 2591 2541 5041 5051 5061 5071 5081 5091
Sound & Vision	0191 0351 0661 0061 0861
Soundesign	0281 4461
Soundwave	0061 0821 0861 0531 1341
Sowa	0101 0371 0051 0281
Soyea	1581
Spectra	0021
Spectroniq	4401 0281
Ssangyong	0021
Staksonic	0021
Standard	0021 0061 0081 0861 0351 0531 0661
Starlite	0021 0231 0061 0861 0471 0701
Stenway	0481 0351
Stern	0231 0461 0471 0891 0721
Stevison	0861
Strato	0061 0861 0471 0021
Strong	1951 0861 0061 2701
Stylandia	0081
SunBrite	0221 0381 1981
Sunic Line	0061 0861
Sunkai	0541 0021 0751 0351 1611 0061 0811 1881
Sunstar	0641 0061 0861 0021 0471
Sunwatt	0751
Sunwood	0061 0861 0021
Superla	1611 0081
Supersonic	0341 0861 1301 0471 1701 0751
SuperTech	0021 0081 0061 0861 0351
Supra	0281 0661 0021
Susumu	0351 0441 0491
Sutron	0021
SVA	1281 1881 1631
Svasa	1701
Swissline	0431
Swisstec	3071 1931
Sydney	0081
Sylvania	4021 4071 4681 4511 4381 4361 4691 4821 0591 1071 1431 2011 2141 2161 2561 2571 2131 2631 3581 3741 5101 4671
Symphonic	0831
Synco	0051 0101 0171 0281
Sysline	0061 0861
Sytong	0081
T+A	0741
Tacico	0281 0021
Tai Yi	0021
Taishan	0021 0661
Tandberg	0631 0891 0211 0561 0671 0231
Tandy	0351 0121 0171 0081 0231 0431
Targa	2071
Tashiko	0051 1391 0081 0501 0261 0231
Tatung	0861 0021 0051 0061 0121 1611 0101 0081 0031 2341 2511 2271 2071

TCL	1411 0861 0701 1301 3851 1131 1161
TCM	1351 1821
Teac	0021 1301 0061 0471 0481 0861 0701 0821 0751 1331 1271 0081 1391 2411 0281 0261 1351 1951 1541
TEC	0081 0431 0021 0441 0561 0461 0061 0861 0231
Tech Line	0061 0861 1271 1951
Tech Lux	2061
Techica	0351
Technema	0531
Technica	0861
Technics	0501
TechniSat	0861 0061 0231 0411
Technisson	1351
Technol Ace	4661
Technosonic	0061 0861
Techwood	1951
Tecnimagen	0861
Teco	0021 0051 0171 0281 0351 0471 0031 4401 1361
Tedelex	0081 1301 1031 0061 0821 0021 2431 0341 1631 1281 0861
Teiron	0021
Tek	1661
Teknika	0101 4661
Tele System	1901
Teleavia	0211 2651 0491
Telecor	0061 0861 0231 0351 0081 0461 0691
Telefunken	1061 0141 0961 0211 1281 0441 1301 2651 1331 0851 1721 2551 1531 3071 1631 0491 0251 0131 0061 0861 1221 1351 0581 0041 1381
Telefusion	0061 0861
Telegazi	0061 0231 0461 0351 0471 0861
Telemeister	0531 0061 0861
Telesonic	0061 0861
Telestar	0021 0061 0861 0701
Teletech	0021 0061 0861 1271 0431 0561
Teleton	0051 0081 0231 0461
Televideon	0531 0231 0081
Teleview	0061 0861
Telexa	0191
Tempest	0021 0061 0861 0471
Tennessee	0061 0861
Tensai	1621 0351 0531 0061 0861 0081 0021 0181 0661 0641 0651 0431 1341 0231
Tenson	0531 0021
Tesla	0061
Tevion	0861 2711 2271 2321 0061 0041 1151 1821 1271 1881 1351
Texet	0081 0351 0661 0021
Texla	1631
Thomson	0061 0211 0441 0491 0531 0861 0961 1061 0081 2651
Thorn	0041 0201 0301 0061 0211 0121 0131 0361 0141 2651 1621 0231 1981 0251 0861 0011 0031 0441 0051 0091 0661 0111
Thorn-Ferguson	1621 0201 2651 0211 0301 0231 0441 0861 0131 0041
Tiane	0171
Tiny	2091
Tiny Digital	1201
TMK	0271 0281
Tobishi	0351
Tobo	0021 0471 0701
Tokai	0121 0061 0861 0561 1271 0231 0081 0661 0021
Tokaido	0861
Tokyo	0081 0041 2641
Tomashi	0481 0351
Tongguang	0471 0701
Tongtel	1631 1281
Topline	0861 1271
Toshiba	0011 0021 0041 0051 0061 0081 0101 0111 0171 0181 0211 0471 0701 0411 0501 1301 1351 1441 1781 1951 2021 0341 2341 2481 0861 2351 3671 2801 3821 4151 3921 3931

Towada	0191 0081
Toyoda	0021 0641 0471
Trakton	0021 0471 0081
Trans Continens	1271 0081 0861 0061 1221
TRANScontinents	0861 2101 3031 1881
Transonic	0061 1301 0861 1331 0751 1281 0471 0821 0021
Transtec	0081
Triad	0061 0861 0351
Trident	1611 0081
Tristar	0471 0351 0301
Triumph	0271 1611 0581 0861 0061
Tsoschi	0481
Tunex	0021
TVS	4071
TVTEXT-95	0861
Uher	0531 0061 0861 0661 0821 1221 1371 0461 0771
Ultravox	0191 0661 0431 0081 0231 0061 0861
Unic Line	0061 0861 0761 0751
United	1351 0061 1341 0861 2341 1281
Universal	1351 0061 0861
Universum	0061 0581 0141 0181 1621 0011 0471 0761 1371 0431 0841 0771 0551 0821 0031 0051 0111 0231 0861 0891 0401 0331 1981 1271 0081 0211 0671 0561 0271 1091 0021 0251 0261 1951 0411
Univox	0061 0861 0561 0231
Upstar	0281 1171
Utax	0231
V7 Videoseven	1541 0281 1031 3021 2181
Vector Research	5101
Vestel	0061 0231 0081 0861 1271 1951
Vexa	0021 0061 0861
Victor	0931 0051 0501
Vidao	5101 4021
Videocon	0041 3161 0471 2641
Videologic	0351 0081
Videologique	0081 0351
Videosat	0481
VideoSystem	0061 0861
Videotechnic	0081 0531 0661
Videoton	0231
Vidikron	0191
Vidtech	0051 0281
Viewpia	1901
ViewSonic	1541 2941 0861
Viore	3961 3991 0411
Viper	0561
Visiola	0081
Vision	0061 0531 0471 0861 0081
Vistar	0231
Vizio	2511 4091 4101 0281 4121 4111 1401 3791
Vortec	0061 0861
Voxson	0231 0281 0061 0861 0821
Waltham	0081 0821 0491 0061 0861 1271 0201 0231 0731
Wards	0281 5101 4661
Warumaia	0661 1211
Watson	0061 0861 0531 2271 0231 0021 1271 0351 0691 2341 3021 3071 0401
Watt Radio	0191 0231 0081
Waycon	0041
Wega	0051 0061 0861
Wegavox	0021 0061 0861
Weipai	0021
Welltech	1351
Weltblick	0061 0861 0531 0081
Weltstar	0861
Westinghouse	4101 4771 4971 2411 1981 0911 3651 4071
Weston	0061 0861
Wharfedale	0061 1871 0861 2551
White Westinghouse	0061 0531 0081 0861 0561 2411
Windsor	1271 0861

Windy Sam	0861
Wintel	1351
World-of-Vision	1931 1961 1881 1351 2321 1911 2181
Worldview	0751 0091
X-View	2071
Xenius	1111 1211
Xiahua	0021 0471 0701 1301 1581 1601
Xianghai	0021
Xiangyang	0471 0701
Xihu	0471 0701
Xinaghai	0791
Xingfu	0021
Xinghai	0471
Xingyu	0021
Xinsida	2641
Xlogic	1301 1631
Xoro	2091 2181
Xrypton	0061 0861
Yamaha	0591 2451 5101
Yamishi	0481 0751 0351 0061 0861 0081
Yingge	0021
Yokan	0061 0861
Yoko	0061 0081 0471 0861 0351 0021 1371 0341 0431
Yonggu	0021
Yorx	0351
Yousida	0021
Yuhang	0021
Zanussi	0231 0081
Zenith	0281 2411 4201 4071 5101
Zenor	0341
Zhuhai	0021 0661
Zonda	1301 1601
ZX	2341

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TVtechnician for help.

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAUTION: Exposure to Radio Frequency Radiation.
Antenna shall be mounted in such a manner to minimize the potential for human contact during normal operation.
The antenna should not be contacted during operation to avoid the possibility of exceeding the FCC radio frequency exposure limit.

Handling Disposable Batteries

This product may contain disposable batteries. Heed the following warning and follow the Battery Safety and Battery Disposal instructions below.

Battery Safety

- Insert batteries correctly. There may be a risk of explosion if the batteries are incorrectly inserted.
- Do not attempt to recharge 'disposable' or 'non-reusable batteries.
- Please follow instructions provided for charging 'rechargeable' batteries.
- Replace batteries with the same or equivalent type that we recommend.
- Do not expose batteries to excessive heat (such as sunlight or fire).
- Do not expose batteries to temperatures above 100°C (212°F).

⚠ **Warning**: There is danger of explosion if the battery is mishandled or incorrectly replaced. Replace only with the same type of battery. Do not crush, puncture, dispose of in fire, short the external contacts, or expose to water or other liquids. Dispose of the battery in accordance with local regulations and instructions from your service provider.

Battery Disposal

The batteries may contain substances that could be harmful to the environment. Recycle or dispose of batteries in accordance with the battery manufacturer's instructions and local/national disposal and recycling regulations.

The batteries may contain perchlorate, a known hazardous substance, so special handling and disposal of this product might be necessary. For more information about perchlorate and best management practices for perchlorate-containing subsances see www.dtsc.ca.gov/hazardouswaste/perchlorate

Disclaimer

Cisco system ,Inc.
5030 Sugarloaf Parkway,
P.O.BOX 465447
Lawrenceville,GA 30044
678-277-1120
800-722-2009
www.cisco.com

March 2012
Part Number 4042218 Rev 04