





材质：128g双铜板纸
说明书尺寸：540 X 100mm

<p>Use the included USB cable to charge your headphone. Make sure they are fully charged before first use.</p> <p>Pairing</p>  <p>Blue & Red lights rapidly flash — Pairing Blue light flashes slowly — Pairing successful</p> <p>Hearing Safety Do not turn the volume so high that you're unable to hear your surroundings.</p> <p>* Siri is supported when connected to an iOS or macOS device.</p>	<p>SPECIFICATIONS</p> <p>BT version: 4.2 Frequency range: 2.402GHz-2.480GHz Loudspeaker size: 40mm Transmission range: up to 10m(33') Power: lithium battery 300mAh</p> <p>OPERATION INSTRUCTION</p> <p>Song playing/ calling</p>  <p>+ 1 click: volume up Press and hold: track forward - 1 click: volume down Press and hold: track backward O 1 click: play/pause music; answer/hang up call 2 clicks: activate Siri/other voice control software P Press and hold: power on/off</p>	<p>TROUBLESHOOT PROBLEMS</p> <table border="1"> <thead> <tr> <th>Problems</th> <th>Solution</th> </tr> </thead> <tbody> <tr> <td>Connection problems</td> <td>1. Check whether the device is compatible with the headset 2. Check whether the battery level is low and need charge. 3. Check whether you've already enabled the wireless equipment or restart the device. 4. Check your mobile device's wireless menu and delete/forget the headset, reconnect the headset to your wireless device.</td> </tr> <tr> <td>Low or distorted sound</td> <td>1. Check the device volume, adjust to the moderate volume 2. Low battery, Please charge the battery</td> </tr> <tr> <td>Cracking noise</td> <td>1. Ensure the headset and the connected device are within range (up to 10meters or 30 feet) 2. Check whether there are obstacles between the headset and the connected device</td> </tr> <tr> <td>LED is not working</td> <td>1. Low battery, Please charge the battery and try again. 2. Restart the headset</td> </tr> </tbody> </table>	Problems	Solution	Connection problems	1. Check whether the device is compatible with the headset 2. Check whether the battery level is low and need charge. 3. Check whether you've already enabled the wireless equipment or restart the device. 4. Check your mobile device's wireless menu and delete/forget the headset, reconnect the headset to your wireless device.	Low or distorted sound	1. Check the device volume, adjust to the moderate volume 2. Low battery, Please charge the battery	Cracking noise	1. Ensure the headset and the connected device are within range (up to 10meters or 30 feet) 2. Check whether there are obstacles between the headset and the connected device	LED is not working	1. Low battery, Please charge the battery and try again. 2. Restart the headset	<p>FCC information</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna. --Increase the separation between the equipment and receiver. --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. --Consult the dealer or an experienced radio/TV technician for help.</p> <p>MINISO</p> <p>USER MANUAL 使用說明書</p> <p>WIRELESS HEADPHONES 經典時尚折疊頭戴式藍牙耳機</p> <p>MODEL: M10</p> <p>CE Rohs www.miniso.jp Designed by Japan, Made in China 株式会社名創優品産業 〒104-0061 東京都中央区銀座3-10-7 銀座京橋大廈7階 MINISO CORPORATION CO., LTD. 3-10-7 GINZA, CHUO-KU, TOKYO 1040011, JAPAN</p> <p>MINISO JAPAN</p> <p>使用產品前請仔細閱讀本使用說明書，並請妥善保管。 PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT AND KEEP IT IN A SAFE PLACE.</p>
Problems	Solution												
Connection problems	1. Check whether the device is compatible with the headset 2. Check whether the battery level is low and need charge. 3. Check whether you've already enabled the wireless equipment or restart the device. 4. Check your mobile device's wireless menu and delete/forget the headset, reconnect the headset to your wireless device.												
Low or distorted sound	1. Check the device volume, adjust to the moderate volume 2. Low battery, Please charge the battery												
Cracking noise	1. Ensure the headset and the connected device are within range (up to 10meters or 30 feet) 2. Check whether there are obstacles between the headset and the connected device												
LED is not working	1. Low battery, Please charge the battery and try again. 2. Restart the headset												

<p>產品指圖</p> <p>給耳機充電</p>  <p>1~2h 紅色LED閃爍 — 配對中 紅色LED常亮 藍色LED慢閃 — 配對成功</p> <p>* 不含此配件 請使用提供的USB線進行充電，第1次使用時請確保充滿電</p>	<p>配對藍牙設備</p>  <p>功能操作介紹</p> <p>音樂和通話操作</p>  <p>+ 按一下: 增加音量 長按: 下一曲 - 按一下: 減少音量 長按: 上一曲 O 按一下: 播放/暫停音樂; 接聽/掛斷來電 按兩下: 啟動 Siri 或其他聲控軟體 P 長按: 開機/關機</p> <p>聽力安全 請勿將音量調得太高，從而無法聽到周圍的聲音</p>	<p>產品參數</p> <p>藍牙版本: 4.2 頻率範圍: 2.402GHz-2.480GHz 喇叭: 40mm 傳輸距離: ≤10米 電池: 300mAh迴圈充電鋰電池</p> <p>所有配件</p> <p>1. 藍牙耳機 2. USB充電線 3. 使用說明書</p>	<p>故障排除</p> <table border="1"> <thead> <tr> <th>問題</th> <th>解決方案</th> </tr> </thead> <tbody> <tr> <td>連接配對不成功</td> <td>1. 請檢查設備與產品是否相容 2. 請檢查是否耳機電池電量不足，需要充電 3. 請檢查您是否啟用設備無線功能，或重新開機 4. 請清空您的設備中的配對資訊，並重新進行搜索配對</td> </tr> <tr> <td>聲音小或失真</td> <td>1. 請檢測藍牙設備音量，調節其音量至適中 2. 電池電量低，請充電</td> </tr> <tr> <td>音樂出現斷音</td> <td>1. 請確保藍牙耳機與設備的有效連接距離為10米 2. 請檢查藍牙耳機與設備之間是否有障礙物</td> </tr> <tr> <td>藍牙狀態指示燈不亮</td> <td>1. 電池電量不足，請充滿再試 2. 請重新開機</td> </tr> </tbody> </table>	問題	解決方案	連接配對不成功	1. 請檢查設備與產品是否相容 2. 請檢查是否耳機電池電量不足，需要充電 3. 請檢查您是否啟用設備無線功能，或重新開機 4. 請清空您的設備中的配對資訊，並重新進行搜索配對	聲音小或失真	1. 請檢測藍牙設備音量，調節其音量至適中 2. 電池電量低，請充電	音樂出現斷音	1. 請確保藍牙耳機與設備的有效連接距離為10米 2. 請檢查藍牙耳機與設備之間是否有障礙物	藍牙狀態指示燈不亮	1. 電池電量不足，請充滿再試 2. 請重新開機	<p>Thank you for purchasing the wireless stereo headset. We hope you will enjoy it! Perhaps there are some differences between the photo and actual product, so the detail information is subject to actual product.</p> <p>CAUTIONS</p> <ol style="list-style-type: none"> Before charging, please check whether the charger can meet the requirements (proposed output voltage is DC5V, output current : 50mA-500mA), high charging voltage will damage the product. Connect the headset with the USB port on your PC (or any available USB port with DC5V) by the micro-USB cable. The built-in rechargeable battery, cannot be removed, so as not to damage the product. Do not throw away or put it into the fire to avoid danger! Warning: Please use the approved charger, using other types of chargers may be a violation of equipment approval and cause danger. Fully charge the headset before using for the first time, in order to maximize the battery life. In addition, in order to extend the battery life, it is recommended to charge the product once every month. Please store this product and operate it under normal temperature. Do not expose this product to rain or moisture. 	<p>7. Handle with care to avoid product damage. Do not attempt to disassemble, repair and modify the product. 8. Prolonged use of headset may cause hearing damage. Please pay attention to reduce the volume. 9. Do not use the headset during driving to avoid traffic accidents. 10. Children should not play with the product.</p> <p>PRODUCT</p> <p>Charging headphones</p>  <p>1~2h Flashing red Steady red on Steady blue on * Accessories not included.</p>
問題	解決方案														
連接配對不成功	1. 請檢查設備與產品是否相容 2. 請檢查是否耳機電池電量不足，需要充電 3. 請檢查您是否啟用設備無線功能，或重新開機 4. 請清空您的設備中的配對資訊，並重新進行搜索配對														
聲音小或失真	1. 請檢測藍牙設備音量，調節其音量至適中 2. 電池電量低，請充電														
音樂出現斷音	1. 請確保藍牙耳機與設備的有效連接距離為10米 2. 請檢查藍牙耳機與設備之間是否有障礙物														
藍牙狀態指示燈不亮	1. 電池電量不足，請充滿再試 2. 請重新開機														