Product Manual



1.Charging

- UPING U1 has built-in lithium polymer battery. Please charge before use or when the battery runs out.
- Connect the charging port with the corresponding USB devices (such as computers, USB to DC plug) via the charging cable.
- The indicator flashes rapidly during charging, and stops flashing when charging is complete.
- ${\scriptstyle \Box}$ The smart functions of the penis cup (such as vibration, insertion detection, etc.) can't be used during charging

2.On / Off

- In shutdown mode, press the function button for 3 seconds, the indicator flashes rapidly and the device turns on.
- In boot mode, press the function button for 3 seconds, the light goes off and the device
- In boot mode, press the function key to switch between different vibration modes.

3.Download APP

- Most functions of UPING U1 is controlled via smartphone APP, please download the APP from $\underline{www.1024online.com}.$

4.Bluetooth connection

- Click the Bluetooth icon in the APP settings interface on the phone, and follow the prompts to boot UPING U1.
- During the process, U1 indicator flashes quickly, and flashes slowly when connection completed. Meanwhile, the phone APP prompts a successful connection.

5.Control

- In "Play" interface, you can control several modes via the APP.
- In "Play with Partner" interface, you can invite a partner for remote control.

6.Cleaning and maintenance

- 2) Squeeze the outer wall of the soft rubber near the cup opening, and pull out the soft rubber slowly.
- 3) Put the thumbs into the vagina, squeeze the outer wall with the palms and other fingers, stretch the vagina opening, and pull
- 4) Rinse the inner and outer walls with water, removing the semen, lubricants and other liquids.
- 5) Wipe the inner and outer walls with an absorbent towel, leaving no water, and then restore the entire soft rubber.
- 6) Place the soft rubber into the cup, with the clitoris aligning the direction of the
- 7) Place the penis cup back in the package box and keep it in a cool place.

FCC Certification Requirements Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to

expressly approved by the party responsible for compilance could void the user's authority to operate the equipment.
This device compiles with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

 Consult the dealer or an experienced radio/TV technician for help.

Specifications

External material: ABS

Warranty Description

The warranty period is one year from the date of purchase.

Any quality problems caused by manufacturing or material defects are covered by the warranty. If you have any such quality problems within the warranty period, please contact us. We will replace the product for free.

Warranty covers the parts affecting the functions of the product, but does not include wear and tear caused by long-term use, misuse, negligence and accidents. Any damages caused by opening or decomposing the product (including accessories) are not covered in the warranty.

Product warranty requires reasonable proof of the warranty requires reasonable proof of the warranty period, including invoices provided by the dealers or Product Manual attached in the product package. Please properly save the original invoice or other related documents within the warranty period. To apply the warranty, please visit the customer service page on the official website or call the customer service staff.

Disclaimer

1024 and its retailers disclaims any legal liability arising from using the product.