ENGLISH

Thank you for choosing our product.
Please read this manual and safety instruction before usage.
Please keep the manual for future reference.



- A perfect combination of Bluetooth speaker and candle lamp.
 Playing music from Bluetooth enabled devices, like smart phones, tablet and
- computer.

 You can blow to turn off the light.
 App control all functions -- play music turn or/off the speaker automatically, change the light color.

Item No. H0042
 Speaker power: 3W
 Frequency range: 70HZ – 18KHZ
 SNR: -755B
 Speaker size: 40mm
 Materiat: ABS +PC
 Weight: 200g


Specifications


- ed, it can work up to 4 hours to play music,

Components and Accessories

· Speaker x 1 • USB cable x 1

Illustration





2

Charging

1

- Please make sure that the product is fully charged before first use.
 Connect the USB cable with the product and power supply for charging (choice of power from USB or connect with AC adapter to power from AC
- (choice of power from USB or connect with AC adapter to power from AC supply).

 The indicator will flash with white when charging. The first indicator lighting means the battery is charged to 0–25% of its full capacity. The second indicator lighting, 25%–50% battery capacity is charged. The third indicator lighting, 50%–75% battery capacity is charged. The fourth indicator lighting, 50%–75% battery capacity is charged. The fourth indicator lighting, 50%–50% of battery capacity remains. The second indicator lighting, 25%–50% of battery capacity remains. The third indicator lighting, 50%–75% of battery capacity remains. The third indicator lighting, 50%–75% of battery capacity remains. The fourth indicator lighting, the battery is full.

Play music

Play music from Bluetooth enabled devices, like smart phones, computer and etc.

• Press and hold the power button for 2 seconds to turn on the unit and the power button for 2 seconds to turn on the unit and the power button for 2 seconds to turn on the unit and the power button for 2 seconds to turn on the unit and the power button for 2 seconds to turn on the unit and the power button for 2 seconds to turn on the unit and the power button for 2 seconds to turn on the unit and the power button for 2 seconds to turn on the unit and the power button for 2 seconds to turn on the unit and the power button for 2 seconds to turn on the unit and the power button for 2 seconds to turn on the unit and the power button for 2 seconds to turn on the unit and the power button for 2 seconds to turn on the unit and the unit an

- and etc.

 Press and hold the power button for 2 seconds to turn on the unit and enter Bluetooth mode indicator flashing with white light.

 Search "emoi Candle Lamp Speaker" on your devices' Bluetooth list, and select it to pair with the speaker. When paired successfully, there is a sound prompt and the mode indicator will stay white.

 After paired, please select and play songs from the Bluetooth enabled device, any songs of your choice.

Hands-free calling

- Short press the hands free button to answer the call when a beep is heard.
 Long press the hands free button to reject the call, a beep will prompt.
 If your want to end the talk during the call, short press the hands free button, a beep will prompt.

Normal light

- Press the lighting button for 1.5 seconds to get soft light with low intensity.
 Short press the lighting button for the second time to increase the light intensity.
 Short press the lighting button for the third time to enter candle light mode.
 Short press the lighting button for the third time to enter candle light.

Color light

- When the lamp is turned off, long press the lighting button for 3 seconds to enter color-light mode, the light will be red. Or you can press the button for 1.5 seconds to enter color-light mode when the white light is on.

 Short press the lighting button to change the light color. The alternative light color is red, orange, yellow, green, blue and purple and breathing light mode (light changes slowly and automatically).

 Long press the lighting button for 1 second to quit color-light mode.

Blow function

- When the light is on, blow into the hole near the candle to turn off the light, blow again to turn on the light within 5 minutes.
- again to turn on the light within 5 minutes.

 Blow to turn on/off the light if Bluetooth is activated.

 If Bluetooth or the light is turned off, blow function is not available.

Automatic power off

If Bluetooth is disconnected and the light is turned off for 15 minutes, the product will power off automatically to save energy.

3

4

Restart

If crash or other abnormal occurs, put the paperclip or the like into the hole marked with "R", then press the reset button to restart the product.

APPl smart phone user can download emoi smart APP from APP Store, Android user can download and install the app from emoi official website (http://www.emoi.com/support/). You can also search "emoi smart" APP in Google Play Store to download.

ENGLISH

Safety Information

- Safety Information

 Please read and follow these instructions, beware all warnings, and keep this document for future reference.

 Set up your product in accordance with product manual, and place your product in a stable locations so it will not fall and cause product damage or bodily harm.

 Do not use your product near water, including diriging or splashing sources (e.g. Do not use your product near heat services (e.g., including stable).

 Do not use your product near heat sources (e.g., including stable), and including directions of the production of the product has been exposed to water, rain, liquid or moisture, the product has been exposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to water, rain, liquid or moisture, the product has been deposed to the product has b

- Please use the product in specime vorticity.
 Place the product in a proper place to avoid injury to children.
 Place the product in a proper place to avoid injury to children.
 Please do not disassemble and make any modifications to the product, this may lead to electric shock, for or electric leakage.
 Use the product in an environment within the temperature of 0 °C 40 °C.
 This is not toy, children under 8 are forbidden to use.

Cleaning

- Do not clean when the product is charging, clean with soft and dry cloth.
 Do not use solvents, chemicals or sprays.
 Do not allow liquids to spill or objects to drop into any openings.

Power Supply Warning

• Caution electric shock/fire hazard! The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

Caution

1

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

Battery information and disposal guidelines at product end

of life

If the product use a non-serviceable, rechargeable battery, which should last the duration of a product awarranty period under normal use. Please do not attempt to change the battery ourself. If the battery has died, you should follow the disposal instructions in the documentation that accompanies your product. Also consult local laws and regulations for the proper disposal of batteries and electronic devices in your youth of the proper disposal of batteries and electronic devices in your your product (and its battery) in a waste bin for electronic devices.

Squip product (and its battery) in a waste bin for electronic devices.

Caulion: There is a risk of explosion, fire or chemical burns if tailery is replaced by an incorrect type, multilated, or exposed to conducting materials, liquid, fire or heat (54°C or 130°F). Do not use or recharge a damaged rechargeable battery. Do no use or charge a battery if it appears to be leaking, discolored, deformed or in any way abnormal. Do not leave a battery discharged or unused for extended periods of time. Do not mix battery types. When a battery is misused, it may epidode or leak, causing burns and personal injury. If a battery leaks, use normal precaution and discard it immediately following the local laws and regulations in your area. Keep all batteries out of the reach of children.

China 3C Caution

China 3C Caution

- There will be a risk of explosion if the battery is changed improperly.

 Change the battery with the same type or same capacity.

 Same the battery with the same type or same capacity, open fire or store in other over heated places.

over heated places.

FCC Statement

* This equipment has been tested and found to comply with the limits for a Class B digits device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the accouraged to try to correct the interference by one or more of the following measures:

- user is encouraged a vy to correct are measures:

 Roorient or relocate the receiving antenna.

 Increase the separation between the equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

 Consult the dealer or an experienced radio/TV technician for help.

2

FCC Radiation Exposure Statement

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

 This device may not cause harmful interference, and

 This device must accept any interference received, including interference that may cause undesired operation.

FCC Caution

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Canada Statement

Lethaua Statement
This device complies with Industry Canada RSS-210. Operation is subject to the following two conditions; (1) this device may not cause interference, and (2) this device of the device. The device may not cause interference, and (2) this device of the device. The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Information to Consumers in Application of EU WEEE Directive 96/2002

Directive 96/2002

This product is subject to European Union regulations that promote the re-use and recycling of used electrical and electronic equipment. This re-use and recycling of used electrical and electronic equipment. This contain hazardous substances. The symbol above, on the product or on its packaging, indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handling it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to collection and recycling of your waste equipment at the time of disposal will help to of your waste equipment at the time of disposal will help to of your waste equipment of recycling, please contact your local city office, your household waste disposal service, or the store from which you purchased the product.