		<b>₿ Bluetooth</b>	
Manual		ENDURANCE	
Manual	High Performance Earbuds WIRELESS		
190 9029 TG3			
In This Package			
*Bluetooth Earbuds	*2 replacement Eartips		
*Micro USB Charging Cable	*Quickstart Guide		
MICROPHONE + VOLUM	E/ MEDIE CONTROLLER O\	/ERVIEW	
		/ERVIEW	
1. Power on/ off. Phone answer	-call button.	/ERVIEW	
	-call button. rt press for raise volume.		
<ol> <li>Power on/ off. Phone answer</li> <li>Long press for next song, sho</li> </ol>	-call button. rt press for raise volume.		
<ol> <li>Power on/ off. Phone answer</li> <li>Long press for next song, sho</li> <li>Long press for previous song,</li> </ol>	-call button. rt press for raise volume.		
<ol> <li>Power on/ off. Phone answer</li> <li>Long press for next song, sho</li> <li>Long press for previous song,</li> <li>Microphone.</li> </ol>	-call button. rt press for raise volume.	6	
<ol> <li>Power on/ off. Phone answer</li> <li>Long press for next song, sho</li> <li>Long press for previous song,</li> <li>Microphone.</li> <li>LED indicator.</li> </ol>	-call button. rt press for raise volume.	4	
<ol> <li>Power on/ off. Phone answer</li> <li>Long press for next song, sho</li> <li>Long press for previous song,</li> <li>Microphone.</li> <li>LED indicator.</li> <li>Charge port.</li> </ol>	-call button. rt press for raise volume.	6	
1. Power on/ off. Phone answer 2. Long press for next song, sho 3. Long press for previous song, 4.Microphone. 5. LED indicator. 6. Charge port.  CHARGING DEVICE	rt press for raise volume. short press for lower volume.	4	
1. Power on/ off. Phone answer 2. Long press for next song, sho 3. Long press for previous song, 4.Microphone. 5. LED indicator. 6. Charge port.  CHARGING DEVICE  This Bluetooth earbud has two 6	rt press for raise volume. short press for lower volume.	charge earbud, follow steps below.	
1. Power on/ off. Phone answer 2. Long press for next song, sho 3. Long press for previous song, 4.Microphone. 5. LED indicator. 6. Charge port.  CHARGING DEVICE  This Bluetooth earbud has two 6 1. Insert USB end of micro cable	rt press for raise volume. short press for lower volume.  65mAh rechargeable batteries. To e, included, into computer USB pornto the media controllers micro pornto the micro pornto the micro pornto the media controllers micro pornto the m	charge earbud, follow steps below.	

- 5. Battery is fully charged in about 2 hours.
- 6. ways to recharge: Wall outlet, car, computer.

OPERATING DEVICE			
A. Power On	n/ Off		
Function	Operation		LED indicator
Power on	Press and hold the power but	ton for 3 seconds, you will hear the voice prompt "power on"	Blue indicator is on
Power off	Press and hold the power but	ton for 3 seconds, you will hear the voice prompt "power off"	RED indicator is on
	·		

## B. Pairing Earbuds

- 1. After you hear pairing, to enter pairing mode.
- 2. Press the power button for about 5 or 6 seconds until red and blue LED's blink alternatively.
- 3. On your device's Bluetooth menu, find and select "Stanley Bluetooth Earphones", you will hear "Pairing successful" "connected", your earbuds and device are now paired.

## C. Phone Calls

Press Power buttone to answer and end incoming calls.

t track.	
Short press for lower volume; Long press for previous track.	
-	

## **FCC Warning Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.