

Manual

FCC ID: 2ADH6-1902091

DEWALT Bluetooth Neckband Earphones

190 2091 DW2

In This Package

*Bluetooth Earbuds	*2 replacement Eartips	*1 sets L replacement Fins
*1 sets S replacement Fins	*1 sets L Three layers of earplugs	*1 set of Memory foam
*Micro USB Charging Cable	*Quickstart Guide	

MICROPHONE + VOLUME/ MEDIE CONTROLLER OVERVIEW

- 1. Power on/ off. Phone answer -call button.
- 2. Long press for next song, short press for raise volume.
- 3. Long press for previous song, short press for lower volume.
- 4.Microphone.
- 5. Bluetooth LED indicator.
- 6. USB charging port
- 7. Charging LED indicator



CHARGING DEVICE

This Bluetooth earbud has 270mAh rechargeable batteries. To charge earbud, follow steps below.

- 1. Insert USB end of micro cable, included, into computer USB port.
- 2. Connect micro end of cable into the media controllers micro port.
- 3. Red indicator light is ON when battery is charging.
- 4. Blue indicator light is ON when battery is fully charged.
- 5. Battery is fully charged in about 2 hours.
- 6. ways to recharge: Wall outlet, car, computer.

OPERATING DEVICE

A. Power On&Pairing/Power Off

Power On&Pairing:

- 1. First time use the earphone,hold press MFB button 4 second,you will listening "power on \pairing(Red and blue light will alternate flash at the same time) When you release the MFB button.find the "DEWALT Earphone 2091" on the bluetooth device list. and choose it you will listening "your devices connected" your earphone and device are connected
- 2. successful .When you use the earphone to connect with your device again, just need hold press, MFB button for 2 second.listening "power on "(it will red light), release the MFB button, earphone connect with bluetooth.device self-motion

Power off:				
Long press	the MFB button be off u	nder the power on at 2 seconds.		
D DI		T		
B. Phone Ca	alls			
Press Powe	er buttone to answer and	I end incoming calls.		
C. Playing N	√lusic			
Function	Operation	Operation		
0	Briefly Press to Play/ Pause.			
+	Short press for raise volume; Long press for next track.			
_	Short press for lower volume; Long press for previous track.			
When volur	me is adjusted to its min	imum/ maximum setting an indicator tone with sound.		
D. SIRI				
Double click	k MFB kev under connec	ction state(This function is effective based on the phone support Siri)		

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.