INNOFask2.0 Manual (Safety Instructions) 블랙 1도 양면인쇄(130mm X 70mm)





Composition of Product Before You Begin · User Manua

€

This Product can provide you a music enjoyment by wireless stream audio contents from your mobile devices such as smartphone MP3 player tablet of PC. You can roam around the house, office of outdoor to listen great music since the product has a rechargeable battery inside. Also, you can directly connect the devices using AUX line out. The device shall support Bluetooth higher than ver.2.1

Contents Power and Charging

To charge battery, connect supplied USB cable to USB port of PC or DC adaptor with USB Port and the other end to Micro USB Port of the right hand side fo the Product.
Frome the connection, the internal battery will start to be During re-charging, AUX source can playback regardless of

The internal battery may not be fully charged when you first open the Product. Please full charge the battery before use. Please use safety approved power adaptor

Operation and Indication

airing / Call Button

1) Play/ Pause/ Pairing/ Device reset
- Short press: Pause and Play
- Press and hold more than 2sec: Enter to Pairing mode
- Press and hold more than 5sec. Enter to Device reset r

Volume Up Button(+) - Press shortly : Volume up - Preess and hold more than

- Press shortly: Volume down - Preess and hold more than 1sec : Track down The volume control and track up/down control of system is also possible by a Blutooth device that paired with the system (using AVRCP function)

Connect your auxiliary source to the AUX-In jack on the right side of the Product with 3.5mm AUX cable.

ecting whith a Bluetooth device.

Turn on the system
White LED will slowly (0.5Hz) blink and search for the pa

Jn-pairing Bluetooth
Power off the product or deactivate Bluetooth wireless mode on your

Power ON: Slow blinking (0.5Hz) Wait pairing mode: Fast blinking (2Hz) Bluetooth paired: Always ON

Tone sound

Set a speaker unit with the case as show in the figure.

Safety Instructions

Read this instruction carefully and keep it Heed all warnings and follow the instruction

Do not use the Product near water

Do not block fornt or rear griles

Do not install near any heat sources such as stoves

Protect the power(USB) cable frome pressing by heavy substances or pulled by excessive power.

Only use on horizontal and flat place

Unplug the Product during lightning storms or when unused for long preriods of time.

Contact a designated AS center when the power (USB) cable damaged, spilling liquid on Product, exposing PRroduct to rain for ling time, serious damage on Product by dropping it.

Keep away magnetic recording devices frome the Product ad there may be a small amount of magnetic flux leakage.

 Protect product frome direct sun light. Do not use solvents to clean the Product and keep away frome dusty environment

· Do not attempt to disassemble the Product

AC adaptor is not supplied with the Product. Dameages caused by improper power adaptors is not compensated.

Always leave sufficient space around the Product for ventilation. Do not place Product in or on a bed, in a bag that may prevent air flow through vent openings

Don't place lighted candles, cigarettes, etc. on the Product.

· Be care that heavy objects do not fall into the Product.

To completely disconnect the power input, the USB cable should be disconnected from the Product.

Use of the Product in moderate climates.
 Use under extreme temperature may degrade system perfomance and product life span.

Certification Information and Warnings

This device complies with part 15 of the FCC Rules Operation is subject to the following two conditions: (1) This device may mot cause harmful interference, and (2) this device must accept any interference received, including

the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures

The life time of battery may decrease slowly by repeating charging and discharging cycles. Play time is based on 1/2 volume.

Increase the separation between the equipment and receiver Connect the equipment into an outlet on a circuit differnet from that to which the receiver is connected

Consult the dealer or an experienced radio/TV technician fo

WARNING: This equipment may generate or use radio frequency energy. Change of modification to this equipment may cause harmful interference unless the odifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

WARNING: This product contains magnets which can be harmful to pacemaker wearers

> Certified Company: INNO Device Co., Ltd. Product Name: Wireless Equipment with specified small power. Model: Series of INNO - FLASK2 Manufacturer/Country: HAJEN Co, Ltd. / China

Micro USB Cable for charging

The USB Cable is not for tele

(N)



SEE MARKING ON BOTTOM / BACK OF PRODUCT **WARNING:** TO PREVENT FIRE OR

C€ 0197

We hereby declare that all essential radio test suites have been carried out and that this device is in conformity to all the essential requirement of Directive 1999/5/EC. To which this declaration relates, is in conformity with the following

EN61000-3-2: 2006 / A1:2009 / A2:2009

2010+A12: 2011+A2: 2013 EN 62479: 2010 • Article.3.1.(b) ETSI EN 301 489-1 V 1.9.2 ETSI EN 301 489-17 V 2.2.1 EN 55013: 2013 EN 55020: 2007 / A11: 2011

• Article.3.1.(a) EN 60950-1: 2006+A11: 2009+A1:

EN61000-3-3: 2008 • Article.3.2 ESTI EN 300 328 V1.8.1(2012-06)

Q:The Product is not turned on. A: Make sure built-in battery is fully charged

Check that the USB cable is not damaged and USB port of

O:The Product is not charged.

A: Make sure the USB cable, plug is not damaged.

Check the USB cable is connected to PC or adaptor USB port properly.

Q: No sound or sound is very low. A: Make sure the Bluetooth wireless connection is correct and playback has been successfully started. Make sure the volume on your Bluetooth device is turned up.

Q: Paired device can not reconnect to the Product. A: Delete "INNO FLASK2" from the list on your Bluetooth device Repeat the pairing procedures again.

A re-connection may fail due to the pairing information has been deleted from your Bluetooth device.

Note in some device you may be prompted to enter a passkey. The passkey is "0000" This can be different for different devices.



Warranty

INO Device Co., LTD. warrants to the original retail buyer of this product, under normal use and condition, be proven the defective in material or workmanship within 12 month from the late of original purchasing. But the warranty for built-in battery

is for 6 month.
Such defect will be repaired or replaced at designated

To obtain proper repair of replacement within the terms of this

warranty, the product to be returned with proof of warranty cov (e.g. dated bill of sale) or visit the AS center with them. if the defective is proven as a user's responsibility, the cost of delivery

This warranty does not extend to the problem of compatibility with ser's device nor the problem by using abnormal adaptor or cable Also it does not apply to the problem by mis-handling, waterlogged or by removal of the Series labels or disassembled by non-qualifi person. Company's liability is limited to the purchase price paid by purchaser for the product.

(N) INNO Device

This warranty gives you specific legal rights and it may vary by regions. This warranty can not be moved nor transferred to the

BEFORE AS CLAIM Properly pack your unit including supplied accessories

We recommend using the original packing materials when you return the product to AS center.

COPYRIGHT AND TRADEMARK

The copyright of the product is owned by

INNO Device Co., Ltd. Without INNO Device permission, it can not be copied, modified, transferred nor saved. Note the copyright and trademark not to be transformed to electric mechanical, chemical, magnetic, optical or any other artificial

USE AND RESPONSIBILITY

he contents within this publication can be changed by INNO Device for improvement of internal design, operation performance or reliability without prior notice INNO Device has no responsibility on inevitable, direct, indirect and accompanying injuries by faults or omisson of this publication.





INNO Device Co., Ltd A-401 660, Daewangpangyo-ro, Bundang-gu

Seongnam-si, Gyeonggi-do, South Korea TFL: +82 31 776 5081

FAX: +82 31 776 5099 E-mail: cs@innodevice.cor DESIGN BY INNODESIGN California

Manufactured in China

INNO Flask 2.0 (N) INNO Device 한국어 사용설명서 해당 무선설비는 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없습니다.

블루투스 4.1을 지원하는 시스템으로 휴대와 조작이 간편하며, 맑고 선명한 고품질 사운드를 제공합니다. 모든 스마트기기의 블루투스를 통해 무선으로 음악을 수신하여 플레이 할 수 있으며, 또한, AUX 케이블을 이용한 직접 입력도 가능합니다. 본 기기는 가정 전자파 적합기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든

내장 배터리 3.7V DC /750 mAh Li-ion (충전2시간, 재생10시간) 3W X 2 at 10% THD 접속단자 Micro USB (충전) / AUX input (3.5mm) Bluetooth V4.1, Class2, EDR&BDR, A2DP, AVRCP, HSP, HFP 사용 주파수 2.402 ~ 2.480 MHz 조자/제조국가 주식회사 하젠 / 중국 재생시간 기준은 1/2 볼륨입니다. INNO - FLASK2(CG ※ BLE(Bluetooth Low Energy) 미지원 INNO - FLASK2(RG)

제품의 구성 및 명칭 재명칭 제품명 특정소출력무선기기 (무선데이터통신시스템용무선기기) /Bluetooth wireless stereo Speaker • 사용설명서 • 케이스

충전용 Micro USB 케이블 - 동봉된 USB 케이블은 통신용이 아닙니다. - AUX 케이블과 아답터는 제공되지 않습니다



사용하기 전에 `

로부터 무선으로 음악을 전송 받아 재생할 수 있도록 되었습니다. 또한, 기기에 내장된 배터리를 이용하여 집안이나 사무실 또는 아외에서 별로의 전원 연결없이 음악을 즐길 수 있으며, 경우에 따라 AUX 케이블을 통해서도 쉽게 연결할 수 있습니다. 단, 모바일 기기는 블루투스 버전 2.1 이상과 A2DP를 지원해야 합니다.

함께 제공되는 Micro USB 케이블을 이용하여 PC의 USB 포트 또는 USB 포트기 시는 DC 아답터를 이용하여 제품 우측 Micro USB 포트(DC IN) 에 연결하면 1원이 공급 됩니다. 이때 내부 배터리는 자동으로 충전되기 시작 합니다. 충전중, AUX in Play인 경우 Power Off를 하여도 AUX in Play는 계속됩니다.



최초 사용시 내부 배터리가 충분히 충전되어 있지 않을 수 있으므로, 충전 후 사용 바랍니다. 충전용 아답터는 안전 인증품을 사용 바랍니다

전원켜기: 슬라이드 버튼을 ON으로 밀면 약 2초후에 시작음과 함께 흰색 LED가

😝 버튼 : 짧게 누르면 소리를 높일 수 있으며 길게 (1초) 누르면

· 페어링 대기음과 함께 백색 LED가 빨리 깜빡입니다.

페어링 해제하기: 스피커의 전원을 끄거나, 블루투스기기에서 블루투스 기능 활성화를 해제 시킵니다.

스피커 시스템 리셋하기 : 시스템 오류가 있을 시 페어링 버튼(\bigseta)을

다시 연결 하기 : 스피커의 전원이 켜질 때마다 마지막으로 연결 된 기기와는

전원 ON: 'Bebebebeep' 톤이 높아진다. 전원 OFF: 'Bebebebeep' 톤이 낮아진다. 블루투스 장치 연결: Bebebebeep' 케이스를 사용하여 제품을 보관하거나 우측

그림과 같이 설치 또는 제품 본체를 세우거나 눕혀서 사용할 수 있습니다.



안전지침 및 주의사항

전자 제품 취급 및 사용에 대한 일반적인 주의 사항들이므로 주의깊게 읽어 주시기 바랍니다. 본 사용 설명서를 필독하신 후 보관하여 주십시오, 모든 경고에 주의를

- 기울여 본 사용 설명서에 준해 조작하시기 바랍니다 제품을 물 근처에서 사용하지 말아 주십시오.
- 제품 외관은 마른걸레로 닦아 주십시오.
- 제품의 전면부 그릴을 가리지 말아 주십시오.
- 난방기구나 발열기기 근처에 두지 마십시오. 전원(USB)케이블 위에 무거운 물체를 올려두거나 무리한 힘을 가해
- 사용하지 않도록 주의 하신 제품은 평평한 곳에서 사용해 주십시오.
- 번개가 치는 날이나 오래 사용하지 않을 경우에는 전원(USB) 케이블을 분리하십시오.
- 전원(USB)케이블 플러그가 손상되거나, 제품위에 액체가 엎질러졌거나, 습기나 비에 오랫동안 노출 되었거나, 제품을 떨어트려 심한 손상이 있는 경우 지정된 AS센터로 문의하여 주시기 바랍니다.
- 있는 물건을 접촉하지 마십시오.
- 본 제품은 소량의 누설 자기장이 있으므로 마그네틱카드 등 자기 기록이 본 제품은 내장 배터리가 들어있습니다. 주변 온도가 섭씨 50도 이상의 환경에서 사용하지 마십시오.
- 불 붙은 양초, 담배등을 올려 놓지 말아 주십시오. 무거운 물체가 떨어지지 않도록 주의해 주십시오. 제품을 임의로 분해하지 말아 주십시오.

곳에서 사용하지 말아 주십시오

제품으로 부터 완전히 전원을 제거하기 위해서는 전원(USB) 케이블을 익반전인 온도에서 사용해 주신시오 사용 온도가 너무 놓거나 낮으면

본 제품을 폐기해야 할 때는 법에서 지정한 적절한 폐기 업자를 통해 처리

추운환경에서 더운환경으로 갑자기 제품을 옮기면 결로 현상에 의해 성능과

본 제품은 아답터를 제공하지 않습니다. 규격에 맞지 않는 아답터를 사용하여 발생한 문제에 대해 책임지지 않습니다.

물기가 있는 작은 화분이나 이불속, 책꽂이, 가방속 등 공기의 흐름이 나쁜

되어야 하며, 가정용 쓰레기와 엄격히 분리되어야 합니다

제품이 직접 직사관선에 닫지 않도록 주의 바랍니다.

제품의 분해는 지정된 AS 센터에서만 가능합니다.

제품을 닦을때 솔벤트와 같은 용제를 사용하지 말아 주십시오. 또한 먼지가 많은 곳을 피해 주십시오.

Operation is subject to the following two conditions: (1) This device may mot cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures;

사용 전원 5V DC +/-5%, 1A

· Increase the separation between the equipment and receiver Connect the equipment into an outlet on a circuit differnet from

· Consult the dealer or an experienced radio/TV technician for



WARNING: This product contains magnets which WARNING: This product contains magnificant be harmful to pacemaker wearers.

Product Name : Wireless Equipment with specified small power. Model : Series of INNO - FLASK2 Manufacturer/Country: HAJEN Co, Ltd. / China





KC: MSIP-CMS-IDH-INNO-FLASK2 Class B Equipment
(For Home Use Broadcasting &
Communication Equipment)

기자재명칭 제품명 : 특정소출력무선기기

모델명: INNO - FLASK2 제조자/제조국가 : 주식회사 하젠/중국



전원끄기: 슬라이드 버튼을 OFF으로 밀면 종료음과 함께 흰색 LED가 꺼집니다.

➡ 버튼: 짧게 누르면 소리를 줄일 수 있으며 길게 (1) 누르면 **페어링 모드 진입 :** 전원이 켜져 있는 상태에서 , 페어링 버튼 (😵)을 2초간

페어링 하기 : 블루투스 기기에서 블루투스 기능을 활성화 시키고, "기기 검색" ,* 찾기* 등을 실행하여 INNO FLASK2* 를 선택하면 페어링이 됩니다. -페어링이 완료되면 백색 LED가 항상 점등되어 있습니다.

문제가 있습니까?

Q: 전원이 켜지지 않습니다. A: 제품의 내장 배터리가 방전되어 있을 수 있습니다. 완전히 충전 후 다시 시도해 보십시오. 또는, 전원(USB) 케이블의 플러그가 파손되었는지 PC 또는 아답터의 USB 포트가 정상인

Q: 충전이 되지 않습니다. A: 전원(USB) 케이블의 플러그가 파곤되었는지 확인하십시오. PC 또는 아답터의 USB 포트에 정상적으로 결합되어 있는지

 블루투스 기기가 잘 연결되고 정상적으로 시작 되었는지 확인해 주십시오, 그리고, 블루투스 기기(스마트폰등)의 볼륨이 적당한 크기로 조정되었는지 확인해 주십시오. Q: 한번 연결되었던 기기가 자동으로 재 연결되지 않습니다.

페어링 중 일부기기에서 passkey을 요구할

Q: 소리가 들리지 않거나 매우 작게 들립니다.

- 통화 하기 : 페어링이 되어 있는 상태에서 페어링 버튼을 짧게 누르면 통화가

급~~. - 통화 종료 : 통화 중에 페어링 버튼을 짧게 누르면 통화가 완료 됩니다. - 수신 거절 : 전화가 왔을 때 페어링 버튼을 길게 누르면 수신이 거절 됩니다. AUX음원 재생하기 : AUX잭을 AUX-In단자에 연결하는 것으로

(한 이사 - 박리(ED) 프라마 영향 충전진형: 조석 (ED) 점등 충전환료: 조석 (ED) 점등 방전경고: 작석 (ED) 점열(LED) 플래시 (times /1분) 패어링 대기: 박석 (ED) 점열 패어링 양료: 박석 (ED) 점등

LED 표시상태

블루투스 장치 리셋: 적색 LED플래시가 5번 점멸 후 백색 LED로 점등

이 보증은 특정 법적 권하옥 제공하며 지역 (관학구역)에 따라 다양하 기타 권한을 제공 받을 수 도 있습니다. 이러한 권한은 본 제품의 보증에

의해 영향을 받지 않습니다. 본 보증은 이전 또는 양도할 수 없습니다.

제공된 악세서리를 포함해 가능하면 구입 시 원 포장재를 써서 포장하는

본 제품의 저작원은 (주) 이노디바이스가 소유합니다. 무단으로 어떠한 방법으로든 복사. 수정. 전달, 저장을 금지하며, 다른 어떠한 언어로도 수정될 수 없습니다. 또한 다른 형식이나 전기적, 기계적, 자기적, 광학적, 화학적, 인위적 등 어떠한 매체에 의해서도 변형될 수 없음을 알려

(주)이노디바이스는 디자인, 기능, 성능 또는 신뢰성 개선을 위해 본 문서 에 수록된 제품의 내용을 사전 통보 없이 변경할 권한이 있습니다.

INNO Flask



(주) 이노디바이스 경기도 성남시 분당구 대왕판교로 660 에이-401


Manufactured in China





TEL: +82 31 776 5081

FAX: +82 31 776 5099 E-mail: cs@innodevice.com DESIGN BY INNODESIGN California



THE LICHTRING FLAM
AND ARROWHEAD AN
AND ARROWHEAD AN
AND ARROWHEAD AN
ALERTING YOU OF
DANCEROUS
VOLTAGE* INSIDE THE
PRODUCT.

SEPENDER TO GOLATE PERSONNEL

SERVICE P

WARNING: TO PREVENT FIRE OR




적합인증 받은 자의 상호 : 주식회사 이노디바이스 (무선데이터통신시스템용무선기기)

/Bluetooth wireless stereo Speaker

※ 제조일자 별도 표기





경우 "0000" 을 입력하시기 바랍니다. 그러나, 기기마다 차이가 있을 수 있습니다.





(주)이노디바이스는 본 제품을 정상적으로 사용한 상태에서 부품문제

또는 AS센터에서 인정하는 불량에 대해 구매일로부터 12개월 간의 품질을 최초 구매자에게 보증합니다. 단, 내장 배터리의 경우 6개월

보증 기간내에서는 무상수리 또는 교환 가능하며, 수리 및 교환을 위해

아래 명기한 AS 센터로 탁송하시거나 내방하시면 됩니다. 단, 고객 귀책

케이블로 인한 문제, 취급 부주의 및 사고, 침수, 오사용 또는 낙하, 임의

분해로 인한 파손에는 적용되지 않습니다. 출고 시 시리얼번호가 떨어져

본 제한 규정을 변경할 권한은 그 누구에게도 없음을 알려 드립니다.

손실된 제품에 대해서도 적용되지 않습니다.

제품의 복구 가치는 제품의 구입가로 한정됩니다.

구입 시기를 증명할 수 있는 영수증과 불량 제품, 그리고 불량현상을

불량의 경우 택배비는 수리비와 함께 청구됩니다. 본 보증은 고객의 기기와의 호환성으로 인한 문제 또는 규격과 맞지 않는 아답터나

(주) 이노디바이스