
# **USER MANUAL**

This manual provides more information about this wireless speaker, please read the instructions before using.



# Front Back Turn On/Off LED Micro USB port Indicator

# **Package Contents**

- ◆ UFO LED Wireless Speaker x 1
- ◆ Micro USB Charging Cable x 1
- ◆ User Manual x 1

#### Power On/Off

- Slide the ON/OFF Button to right, turn on the speaker.
- Power off
   Slide the ON/OFF Button to left, turn off the speaker.

# Pair wireless speaker with your mobile device

- Keep the distance between your Wireless speaker and mobile phone (or other devices) within 32.8 Feet.
- 2. Power on the wireless speaker.
- 3. Activate the Bluetooth function on your phone within range and select "UFO SPEAKER" from the list shown.
- 4. You will hear a beep sound when pairing is successful.

### Reconnect wireless speaker to your mobile device

 When powered on, the wireless speaker will automatically connect with the last successfully paired device.

# Charging your wireless speaker

- 1. Use the micro USB cable provided with this speaker.
- Connect the micro USB plug to micro USB charging port on the speaker, then connect the USB plug to a USB port on a computer or wall adapter to begin charging.
- 3. The light will turn red while charging and will turn off once fully charged.

#### NOTE:

- You must select a qualified charger from a regular manufacturer.
- You must charge the wireless speaker if it has been not used for more than 12 months.



## Technical specification

Bluetooth version:	4.1
Frequency response:	20Hz-20KHz
Play time:	1-2hrs
Standby time:	60hrs
Charging time:	2-3hrs
Bluetooth operating range:	32.8 Feet

# FAQ

- If the wireless speaker cannot be paired with your device, please try the following:
- Ensure that your speaker is in pairing mode or reconnection mode. Ensure that Bluetooth search function of your mobile device is activated.
- If the wireless speaker will not turn on: Make sure the speaker is fully charged.
- Can I change the battery for the speaker?
  Wireless speaker uses a built-in non-detachable battery which
- cannot be removed.
- If the wireless speaker cannot be recharged:

If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered.

#### FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

#### RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2ADM5-SP0298