

Intelligent HD

Video Glasses



USER MANUAL

Catalog

Safety con	siderations	3—11
Packaging	accessories	12
Product int	roduction	1317
Operate gu	ıidebook	1825
Technical p	arameters	26—32
Common	Problem	treatment
33-36		

Safety considerations

Please read the following concise product information carefully before use. Do not abide by the irregularities or illegal operation of the information, may be dangerous or illegal.

Do not use this product if you engage in any violation of local laws and regulations violations. Wireless connection should be closed on the prohibition of the use of wireless products areas.

 The products are wireless connectivity in wireless products. Please close the wireless connection in prohibit using place (for example, in the planes, gas stations, hospitals or medical equipments, fuel, chemicals or blasting places nearby), Please abide by all provisions in restricted areas.

Interference

 All wireless devices are likely to be disturbed, which affects performance.

The charger and other accessories

 please use the original charger or the confirmation of qualified products, the external power source charging. Protect hearing, eyesight

When using headphones, users should select medium volume. So as not to affect the hearing.

 Do not watch video continuously too long, so as not to affect vision.

Be careful to use your product

 This product does not have waterproof function, use and store in a dry environment.

- Please don't use and keep products in the hot and dusty places.
- Must use a soft cloth to clean the equipment surface, it can not use acidic, alkaline solution to clean equipment.
- To ensure that important data security, please backup of important data in different locations.

Fall

 This product contains precision devices, please avoid dropping or shocking.

Maintenance services

- The company or the company designated professional maintenance staff, do not disassemble products. Any unauthorized disassembly of products, will not be able to enjoy the company promises warranty service.
- The company has right to make this product improvement and upgrade of the right, without prior notice.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and(2) This device must accept any interference received, including interference that may cause undesired operation.Warning: Changes or modifications

not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to

radio communications. However. there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Parts





3D glasses



USB







USB Cable









Eye Patch Myopia lens template

Nose pad

Product Presentation







Function	Action
	Mobile mouse
	control direction
	● long by 3 seconds,
Track ball	and then rolling the
	trackball, can flip up
	and down or
	moving around the
	page
	Charging indicator,
	when the product is
	in charge, be bright
	red light. Full
	charge to blue light
Þ	●To return to the

	previous step operation	
	●Shutdown state, long	
	press the button for 3	
	seconds boot	
(1)	●Start state, long press	
O	the button for 3 seconds	
	off tips	
	● The working status,	
	click this button, enter	
	the screen state	
	●The working status,	
	click this button, enter	
	the screen state	
	 Connect the 	
	charger or mobile	

USB		power charging
	•	Connect computer,
		mobile phone and
		other products of
		data download
	•	Connect wireless
		mouse
AV IN	•	Connect
		computer, DVD,
		game consoles and
		other video input
		(optional)
TF Card	•	UP to 32GB TF card
slot		
Nose pad	•	By replacing the
		·

		nose support to
		adjust the screen
		height
Myopia	•	In the purchase of
lens		myopia lens, lens
template		size as template

Operate Guidebook

- Please don't plug the TF card in the play period.
- 2.In the initial use, if can not be boot properly, It may be product of was placed a long time, the electricity is shortage. Please use after charging. The normal charging time 2-3 hours.
- 3.If product crash by irregular performance, please push \circlearrowleft button for 10 seconds, the product will be restart automatically.
- 4.If you want to surf the website, please turn on the wireless connection. Setting— wireless and

internet-- /WLAN –turn on. The system will automatically search for available wireless networks, connecting operation according to the reminding.

 If you want to enjoy the fun of the games, please buy a wireless mouse to use together which will give you a surprise.

6.If you want to experience the 3D theater shock effect, please use the system comes with the 3D PLAYER player. If you want to display captions in the watch video 3D, please download the video, at the

same time download subtitles, and the subtitle file name to the same name. The same video files stored in the same folder.

7 .File Manager

If you want to see all the files in the file managert, you can click on the desktop, and entered the file manager desktop





Memory storage. You can all the data in the memory storage.

TF Card. You can view all of the data in the TF Card..

Via USB, you can see or download files from mobile phone, computer or other mobile hard disk.

Picture. you can see all pictures .

Movie: you can see all

movies..

8. When you need to wear glasses please take the attached lens myopia template to professional glasses store configuration myopia lens, and mounted into the hood of the groove.

Connected computer via USB

1> Products will be connected to the computer through a USB line 2>.Move the mouse to the upper left corner of the desktop, long press to track the ball for 3 seconds, and press down.



 Click USB connected menu, entering USB connected page.



4>.Click to turn on USB Storage, It can be connected to computer successfully.

10. WIFI Connection

Click Settings button, Enter the

settings panel

In the WI-FI menu bar, click the close button will open WI-FI connection.

Click the WI-FI menu bar again, enter the WIFI c panel, Long press to track the ball for 3 seconds, and scroll to page down, you can find the language & input method menu, click Set accordingly.onnection page, select your users, and set the corresponding password, then you can connect WI-FI successfully.

11. Language & input

Click Settings button, Enter the settings

Specifications		
CPU	•Cortex™-A7 Dual-Core	
	@1.5GHZ	
Memory	Built in	
	8GB-16GB(electable)	
	flash memory and	
	support up to 32GB	
	Micro SD Card,	
WIFI	Wi-Fi802.11b/g/n	
os	Android4.4	
Operati	Touch-button, Track ball,	
on way	support bluetooth	
	wireless mouse	
Input	Pre-install Android	

	keyboard
data	USB2.0
transfer	
110110101	Internet
	momor
Browser	Support Opera, UCWeb,
	SkyFile, Dolphin etc
Entertai	Support online video, tv,
nment	game, movie, music and
online	radio
Office	WORD,EXCEL,POWER
software	POINT,PDF,TXT
expansi	Google market more
bility	than 20,000 excellent
	app. download
Internet	Web browser, online

арр	talk, email, E-book,	
	Explorer	
Sc	creen Specifications	
Screen	98inch virtual screen (at	
Size	2 Meters distance)	
LCD	WVGA(854*480 pixels)	
Resoluti		
on		
screen	TFT LCD	
material		
Audio		
Audio	Support MP1, MP2,	
format	MP3, WMA, OGG, AAC,	
	M4A, FLAC,	
	APE,AC3,AMR,DTS,RA,	

	WAV etc
features	Support LRC lyric
	synchronism, audio
	information
	classification, Album
	cover shows
SNR	≥90DB
	Video
Video	AVI, H.264, VC1,
format	MPEG2, MPEG4,
	DIVD/DIVX, Real8/9/10,
	RM, RMVB, PMP, FLV,
	MP4, M4V, VOB, WMV,
	3GP, MKV etc, support
	Flash11.0

Feature	Up to 1080P(resolution		
s	1920X1200)full hd		
	display , support 3d		
	format side by side,		
	internet video download		
	and play		
	Picture and Text		
Format	Support JPG 、BMP 、		
	PNG 、GIF etc format,		
	rotate/slide play, support		
	resolution up to		
	4096*4096		
E-book	TXT		
	Other		
Langua	Simplified Chinese,		

ge	Traditional Chinese,
	English
Power	The built-in
Pack	3.7V/1350mAh
	Li-Polymer
	Rechargeable, theory of
	continuous work time 3-4
	hours,
	External support for the
	mobile power supply
Power	<1w
Consum	
ption	
Weight	120g
Dimensi	163x61x44mm(folded)

on	
Working	-5—40℃
Temper	
ature	

Common problem treatment Can not turn on

- Battery used out please connect the charger, or mobile power equipment after a reboot
- Crash long press the button
- of for 10 seconds, the system will be forced to restart
- If still unable to turn on, please contact us

Housing heating

 In charge or the normal use of the process, the housing heating, this is a normal phenomenon, users can use it without any angst.

Battery life

• Battery life estimates, the actual use of time determined by so many factors, such as network status, equipment setting, use the function, battery status and environmental temperature.

Screen flashing

 Restart protection on the screen after screen, flashing and there will be a short time, this is because during the screensaver period, each core part is in the electricity saving dormant, to start when the flash screen caused a short period of time, after a few seconds will be returned to normal. This is a normal phenomenon.

• Use the track ball. When you need to turn the pages via the track ball, please move the mouse to the bottom of the screen, long press the trackball, when the mouse at the menu highlighting, immediately release the track ball, scroll up and down to turn the pages up and down.
If no response on screen, please back to this setting and re-entered, repeat the above operation.