

User Manual











IMPORTANT

Safety

Important Safety Instructions

- Heed all warnings.
- Do not use this apparatus near water.
- Do not block any ventilation openings, Install in accordance with the manufacturers instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other devices (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel. Servicing is required when the device has been damaged in any way. Such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the device, the device has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Devices shall not be exposed to dripping or splashing.
- Do not place any sources of danger on the device (e. g. Liquid filled objects, lighted candles).

Warning

Never remove the casing of this apparatus.

Never place this apparatus on other electrical equipment.

Your Bluetooth Speaker Power supply

- 1. The speaker can operate on built-in rechargeable battery.
- 2. To recharge the built-in battery.
- 3. Connect micro USB socket with PC through supplied USB cable.
- 4. The power indicator (red) turns on.
- 5. The power indicator (red) turns off when it"s fully charged.

Play

Play from a Bluetooth device

Note:

The effective operation range between the speaker and your Bluetooth device is approximately 10 meters (30 feet).

Bluetooth Mode:

- 1. Turn on speaker, the indicator light is flashing (when power on, the blue light is on, when waiting pairing, the blue light is flashing fast, after paired, the blue light is flashing slowly.
- 2. Turn on Bluetooth function of device (i . e .Phone, computer or Tablet PC.....).
- 3. Search and select Bluetooth speaker, i .e."f*--****"to pair. You will hear "paired " from Bluetooth speaker, for some devices, you need to input password "0000"to pair.
- 4. Playing music and it is outputted from Bluetooth speaker.
- 5. Turn off the speaker if you don't use it.

Line In Mode

- 1. Push" button for 5 seconds to enter Bluetooth, line In mode.
- 2. When entering line in mode, please connect USB cable to computer and DC 5V jack of Bluetooth speaker, then the music playing by computer will output through Bluetooth speaker.

When somebody call in:

Push the "D" button to answer the phone. Push the "D" button again to hang up.

If you don't want to answer the phone, just push "button for 3 seconds to hang up.

Double push" buttons can call the last call in number.

Tip

You can speak to the MIC to get the best speakerphone performance.

TF CARD

- 1. Insert TF card, Bluetooth speaker will switch to TF card mode by default.
- 2. Bluetooth speaker will play the musics of TF card automatically, support formats include: WMA/MP3/WAV.
- 3. Push "+/-" button to control the sound volume.
- 4. Push "I◀/►I" button to choose song to play.

Q&A:

Please don't try to repair the product by yourself.

No Power:

Please recharge the Bluetooth speaker.

No Sound:

Please adjust the sound volume of your Bluetooth device.

Please make sure you Bluetooth device is in the effective range.

Please check the selected audio source is correct.

Speaker NO sound:

Please reboot the Bluetooth speaker.

(Please note the insert direction of TF CARD).

Note: Some models of f** don't have TF CARD and FM functions, Please check the introduction on the gift box.

Specification:

Note: product specification can be changed without notify.

| Rated Audio output power | 3W RMS |
|--------------------------|------------------------|
| DC power input | USB 5V -500MA |
| Built-in Li-ion battery | 3.7V 500MAH |
| Battery working time | 3-4 Hours |
| Bluetooth specification | V2.1+EDR |
| FM Radio | FM87.5-108MHZ |
| Frequency response | 120HZ-20KHZ |
| Signal to noise ratio | >80db |
| Range | 10 meters(No obstacle) |

This user manual is applied to all Bluetooth speaker products of F*.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.