If any emergency arises, dial 112/911 (or other emergency call number) for

Please read the user's manual so as to keep your mobile phone in the best condition. Due to the nature of cellular networking, the success of emergency call is not The manual has been verified and reviewed to guarantee the accuracy. Instructions and

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may Insert the sim card and the battery cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for Startup and shutdown compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B *** on the screen). digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures: -Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the

Consult the dealer or an experienced radio/TV technician for help.

receiver is connected

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types S1(FCC ID: 2AEJAGOLS1MON) has also been tested against this SAR

limit. The highest reported SAR values for head, body-worn accessory are 0.60 W/kg, 0.50 W/kg respectively. The Max simultaneous SAR is 0.81W/kg. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and Note: Consult with the local service provider for details about MMS sending and the back of the handset. The use of belt clips, holsters and similar accessories should receiving restrictions. not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and General should be avoided.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

You may set functions in relations to cell phone security. [phone lock: 1234] Per the setting.

descriptions contained herein are accurate at the time of publication. However, mobile to factory default state value, the user of the function be used with caution. (Default phones developed afterward and the contents of their manual are subject to password: 1234). modification without further notification. Our company reserves the rights in relation to Phone Network setting

Security setting

Declaration

Ensure to turn off the equipment and disconnect with the charger before taking out the

Press the key of power supply to start up or shut down the mobile phone. If it is prompted to input PIN or UPIN, please input the required password (shown as

any other radio and transmitting devices, don't touch the antenna if not necessary In the options of the video camera, you may set the exposure compensation, avoidance because it may affect the quality of telecommunication and result in equipment operating in an energy level higher than required, thus shortening the service life of the

Need to be sure to change one of Input Methods.

You may save the information of contacts including names & telephone numbers in the

The cell phone supports sending of and receiving of SMS. You may check the quantities

of sent and received messages from the menu of SMS counter.

you can edit the number of the service center (Which is obtained from the service

You may insert words, pictures, videos sounds or appendix in MMS, and may send the MMS to any Email address or any cell phone number. If the MMS size is oversized, the 15. Games cell phone may fail to send or receive it.

Note: The "account data" is to be provided by the network operator. discharged for several hundreds of times and finally will be disabled. In case the standby

20. Lamp

21. Calendar

Restore the factory settings

Enter the correct password of the phone will have to change your phone settings back 18. Bluetooth

The option is related to your network provider. Please get in contact with the network

provider for that. Flight Mode: No communication function is available in flight model.

You may select modes of dual-standby and single-pass, SIM 1 on/SIM 2on and flight Support Calendar function. 22. Calculator

You may surf online with WAP brower, which means that you may surf online at any

time and in any place. For details, please get in contact with the nearest network service usage of the accessories: Your mobile phone may be provided with built-in and exposed antenna. Just like using Video recorder

of flickering, white balance, special effect, profile and etc.

In the options of camera, you may set the photometry mode and etc. You may enter the correctly installed and whether work normally.

10. Video player/Image Viewer

game operating instructions.

Edit and set the GPRS access point

16. Connection

The music player is used to play music files in supported formats in the current player's certification or warranty terms or even lead to danger. Why is required to use the original accessories?

album to check the formats that the cell phone supports.

Turn on/FM broadcast, and you may manually tune the channel.

phone book. The storable entries of sim card depend on the type of the card.

Check the video or pictures files supported by the cell phone.

The call list lists all types of calls, including missed ones, dialed ones and answered ones

For the memory card, you may establish a data file folder and etc.

Write a message: You may select multiple receivers to send the message to more than 1

or you may enter the separate lists of missed calls, dialed calls and answered calls for SMS setting: You may select to edit the SMS setting either of SIM card 1 or 2, where. check or operation. 13. FM Radio

Use this function you can record or listen to your own record. This mobile phone provides a snake game, please see specific operation within the

time and call duration shorten obviously, please replace the battery. If the battery is

Set the time of alarm clock. At the time of alarm clock, an alarm ring will be given as using, it may be necessary to connect with the charger, disconnect and then reconnect

You may establish wireless connection with other compatible devices with the If the battery runs out of electricity, you may have to wait for a few minutes till the Bluetooth technology. symbol of charging is shown on the screen, and then you can make and answer any call.

19. PC connect Mass storage

Use the T-Flash inserted in the mobile phone as U-Disk.

Support Lamp function.

Support Calculator function

other types of batteries , chargers and accessories may result in violence of the

Battery and charger are key parts of a mobile part because they play important roles in

guaranteeing the normal operation of the mobile phone as well as your safety. It is

shown in our long-term customer investigation and aftersale service that lots of mobile

phone failures results from usage of ineligible accessories, especially ineligible battery

) Shorten the battery service life with times of battery charging/discharging much

2) Shorten the service life of the mobile phone largely. Unstable voltage will affect the

3) Affect the performance and reliability of the mobile phone, reducing the voice

4) May result in burning or explosion and thus endanger the personal safety of the

Chargeable battery is used for the equipment. The battery may be charged and

Hazards resulting from usage of ineligible battery and charger

normal operation of the circuit, resulting permanent damage.

fewer than that of the original battery.

24. About the battery

Charging and discharging

quality and being susceptible to halted system.

23. Original Accessories 25. Maintenance and service Refer to the local dealer for supply of accessories. Hereafter are some precautions for Your equipment is a product with exquisite design and process. Please use carefully. Following are some suggestions for you to effectively use the maintenance service.

Please keep the accessories out of children's reach. 1) Keep the equipment dry. Rainwater, moisture, other liquids or moisture contents

Hold the plug and pull out instead of pulling the power cord when cut off the may contain mineral matters, which may grode the electronic wires. If the equipment is wetted, please take out of the battery till the equipment is totally dried and then put in Regularly check the mobile equipment in the automobile to see whether they are

2) Don't use or store the equipment in dusty or filthy places: otherwise, the Only use batteries, chargers and accessories approved by the manufacturer. Usage of detachable parts and electronic elements may be damaged.

replaced and used for the first time, or the battery has been kept for a long time before

in order to charge the battery. When the charger is not used, please disconnect with the

Don't use the battery for any other purpose. Don't use any damaged charger or battery.

Avoid short circuit of battery: otherwise, the battery may be damaged, and generate

Don't put the battery under high temperature or in fire; otherwise, it may explode;

Stop usage in case of damage or obvious aging of battery and charger;

Return waste and used batteries to the supplier or specified recovery site.

equipment and plug it out from the power socket.

Usage and treatment of battery

Don't attempt to take apart the battery:

Don't throw it away in domestic garbage.

heat to cause fire hazard:

Don't put the equipment in overheated places.

4) Don't keep the equipment in under cooled places; otherwise, when the temperature rises to normal, moisture may be generated within the equipment, resulting in damage of the circuit board.

5) Please open the equipment as per the descriptions in the manual. Don't try any 6) Don't throw, knock or shake the equipment. Any rough treatment of the

equipment may result in damage of the inner circuit board and its exquisite structure. 7) Don't clean the equipment with ardent chemical, detergent or strong wash.

8) Don't paint any dyestuff on the equipment. Painting may block foreign substances

in detached parts and thus affect the normal operation. 9) Clean the lens with clean, dry soft cloth (such as the camera lens, range sensor and

10) Only use matched or approved antenna for substation of the damaged one

Unapproved antenna, alteration or accessories may result in damage of the equipment and violence of relevant specifications on radio equipment. 11) Please use the charger in indoor area.

12) Back up data that should be kept (such as the address directory and calendar

13) Please turn off the equipment and take out the battery to restore the equipment

setting irregularly to maintain the optimal performance.

contenidas dentro son precisas para el tiempo de su publicación. Sin embargo, los teléfonos móviles desarrollados luego, y el contenido de sus manuales, están sujetos a modificación sin notificación previa. Nuestra compañía se reserva los derechos en relación al manual. Introducción



-Insertar tarjeta SIM v batería Asegúrese de apagar el equipo y desconectar el cargador antes de remover la batería.

maintenance agency for repair.

pantalla aparece como *****).

Métodos de Ingreso

del tipo de tarieta.

Mensajes

-Encender y apagar Presione la tecla de "encendido" para encender o apagar el dispositivo. Luego se le

balance de blancos, efectos especiales, perfil, etc. Su equipo puede estar provisto con una antena interna o expuesta. Al igual que con

otros dispositivos transmisores, no toque la antena de no ser necesario, va que esto podría afectar la calidad de las comunicaciones y resultar en consumos de energía mayores a los regulares, acortando la vida de la batería.

Asegúrese de establecer el método de ingreso deseado. Libreta telefónica

16. Conexión

Puede guardar la información de los contactos incluvendo nombres y números de

teléfono en la libreta. La cantidad almacenable de entradas en su tarieta SIM depende 11. Administrador de Archivos Para la tarieta de memoria, puede establecer una carpeta para archivar los datos

enviados o recibidos desde el menú de SMS.

12. Historial de llamadas El historial de llamadas consiste en una lista de llamadas realizadas, recibidas, perdida

El teléfono puede enviar y recibir mensajes SMS. Puede revisar la cantidad de mensajes y contestadas. También puede establecer para almacenarlas por separado según su

Redactar mensaie: Puede seleccionar enviar el mensaie redactado desde SIM 1 o SIM 2. 13. Radio FM

Puede elegir varios receptores cuando desea enviar mensajes a más de 1 persona. Encender la transmisión FM. Puede sintonizar el canal manualmente. Ajustes de SMS: Puede seleccionar esta opción para editar el SMS de la tarjeta SIM 1 o

2. Aquí puede editar el número del centro de servicio (el cual puede ser obtenido con el proveedor de servicios).

El teléfono incluye un juego de serpiente, favor verificar la aplicación dentro del juego Puede insertar palabras, imágenes, videos, sonidos o apéndices en un MMS, El MMS para ver sus aiustes e instrucciones.

puede ser enviado a cualquier dirección de correo electrónico o número telefónico. Si el

MMS es demasiado pesado, el teléfono puede fallar en enviar o recibirlo. Nota: Consulte con el proveedor de servicios locales para más detalles acerca del envíc y recepción de MMS y sus restricciones.

Ajustes de Seguridad

Ingrese el código correcto en el teléfono para reestablecer la configuración original de teléfono. Esto debe ser realizado con precaución. (Clave original: 1234)

Favor leer el manual de usuario para mantener su móvil en las mejores condiciones. El

14) The above suggestions also apply to your equipment, battery, charger and other

manual ha sido chequeado para garantizar su precisión. Las instrucciones y decisiones

indica que ingrese su PIN o UPIN. Por favor ingrese la contraseña requerida (en la

accessories. In case any device doesn't work, please take it to the nearest authorized

Esta opción está relacionada al proveedor de redes. Favor contactar al mismo para Utilice el T-Flash insertado en el teléfono como disco de almacenamiento 20. Lámpara realizar este tipo de ajustes. Modo avión: No están permitidas las comunicaciones en este modo. Función para iluminar.

Modo alterno:

Aiustes de redes

Restaurar configuración de fábrica

Puede elegir opciones de espera duales o de pase individual, SIM1 en SIM2 y en modo

Puede navegar en línea con el navegador WAP, lo que significa que puede navegar en 23. Accesorios originales cualquier lugar o momento. Para más detalles, contacte al proveedor de servicios más Referirse al distribuidor de accesorios local. Aquí se incluyen algunas precauciones para el uso de los accesorios:

Grabadora de Video Con esta opción, puede elegir la compensación de la cámara, evitar el parpadeo.

En las opciones de la cámara, puede establecer el modo de fotometría entre otro Puede ingresar al álbum para revisar los formatos que utiliza el teléfono.

Solo use baterías, cargadores y accesorios aprobados por el fabricante. Uso de otro tipo Reproductor de Sonido de accesorios puede resultar en cancelación de la garantía o hasta causar daños. El reproductor de música reproduce archivos reconocibles como musicales en la lis ¿Por qué es requerido el uso de accesorios originales?

10. Reproductor de Video/ Visor de imágenes

su funcionamiento regular así como su seguridad. Se ha demostrado en nuestra Observe sus archivos de video o imágenes reconocibles por el equipo. investigación de clientes a largo plazo y servicios post-venta, que muchos teléfonos que

presentan fallas lo hacen debido a accesorios de otras marcas defectuosos que producen fallas en el equipo, en especial batería y cargador.

personal del consumidor.

24. Acerca de la batería

-Carga v descarga

18. Bluetooth

19. Conectar a PC

21. Calendario

22. Calculadora

solo halar el cable.

-Almacenamiento masivo

La función de calendario para verificar fechas.

Favor mantener fuera del alcance de los niños.

correctamente instalados y si funcionan con normalidad.

normal de los circuitos, resultando en daños permanentes.

calidad de sonido y volviéndose más susceptible.

esta función.

Puede establecer las conexiones inalámbricas con otros dispositivos compatibles con

Mantenga presión en el conector cuando desconecte de la fuente de noder, en vez de

La batería y cargador son partes clave del funcionamiento de un teléfono al garantizar

duración de llamadas acortadas notablemente, favor reemplazar la batería. Si la batería

es reemplazada y utilizada por primera vez, o la batería ha sido mantenida por mucho

tiempo en desuso, puede ser necesario conectar al cargador, desconectar y luego

reconectar, para poder cargar la batería. Cuando el cargador no esté en uso, favor

Revise con regularidad los equipos móviles en los vehículos para verificar que estén

Aplicación de calculadora para realizar operaciones matemáticas simples.

Peligros que pueden resultar de cargadores o baterías inadecuados

Acorta la vida de la batería al volverse más cortos sus tiempos de duración de carga de removibles y afectar la operación normal. lo debido. Limpie el lente con un paño limpio y húmedo (por ejemplo el de la cámara y el Acorta la vida del teléfono notablemente. El voltaje inestable afecta la operación sensor de rango y luz)

0- Solo use una antena aprobada para sustituir una dañada. Antenas no aprobadas El rendimiento y confiabilidad del equipo se pueden ver comprometidos reduciendo la pueden resultar en terminación de la garantía y daños al equipo.

luego puede contestar cualquier llamada.

generar calor o peligro de incendio.

No intente desarmar la batería.

25. Mantenimiento y servicio

No coloque en temperaturas altas.

-Uso v trato de la batería

- Favor use el cargador solo en áreas cerradas.

Puede resultar en guemaduras o explosión y por ende poner en peligro la seguridad La información de respaldo debe ser almacenada.

> funcionamiento cuando presente conductas inusuales. 14- Las sugerencias anteriores aplican para el cargador y la batería. En caso de

La batería recargable se usa para el equipo. La batería puede ser cargada y descargada funcionamiento irregular llevar al centro técnico autorizado más cercano. varios cientos de veces hasta que finalmente se inutiliza. En caso de tiempo de espera y





Editar y establecer el punto de acceso GPRS.

disparará un tono según sus configuraciones. Puede establecer funciones en relación a la seguridad de su teléfono. (Clave: 1234)

Establecer el tiempo de la alarma. En el momento indicado por usted para que suene.

Nota: Los "datos de cuenta" son provistos por el proveedor de red.

Utilice esta función para grabar o escuchar sonidos grabados

desconecte de la corriente eléctrica. Si la batería se queda sin electricidad, puede tener

que esperar unos cuantos minutos a que el símbolo de carga se muestre en la pantalla y

No use la batería para otros propósitos. No use baterías o cargadores deteriorados

Evite el corto circuito de la batería, de otra manera, la batería puede sufrir daños y

Regrese las baterías usadas y desechadas al proveedor o lugar de recuperación

Su equipo es un producto de diseño y proceso exquisito. Favor usar con cuidado. A

continuación se presentan una serie de sugerencias para su uso y mantenimiento

No use o almacene en lugares con polyo o sucios, de lo contrario, las partes.

removibles del equipo y elementos electrónicos pueden sufrir daños.

No limpie el equipo con químicos fuertes o detergentes comerciales.

3- Favor apague el equipo y remueva la batería para restaurar el equipo a su

humedece, favor remover la batería hasta que segue por completo.

normalice, se genera humedad lo cual daña los circuitos.

puede resultar en daños permanentes a los circuitos.

Mantenga seco. El agua de lluvia, humedad y otros líquidos pueden contener

materias minerales, las que pueden erosionar el cableado eléctrico. Si el equipo se

No mantenga el equipo en lugares fríos, de otra manera, cuando la temperatura se

Favor abrir el equipo solo bajo las instrucciones del manual. No lo intente de otra

No arroje o sacuda violentamente el equipo. Cualquier tratamiento rudo del mismo

No tiñe o colore el equipo. La pintura puede bloquear substancias ajenas en partes

Detenga el uso en caso de daño o deterioro de la batería o cargador.

apropiados. No deben desecharse como basura doméstica.

No coloque la batería en altas temperaturas o en fuego, de lo contrario, puede explotar,