Message

Call logs

Settings

Multimedia

M maxwest

- Basic Knowledge
 Introduction

 Thank you for choose our digital color screen mobile phone. By reading these guidelines before using your mobile phone you will have an overall knowledge of this phone set and understand its simple but outstanding functions.

 This phone set is designed for GSM/GPRS networks. On top of basic functions, it enables you to use name card style contacts, clock/ alarm, calendar, calculator, games, audio player, camera, video recorder, image,FM radio and other functions. It serves your work and leisure time. Having unique interface and perfect feature designing this phone set meets all your expectation.

 Our phone set meets the GSM/GPRS standard and has the qualification from related organizations worldwide.

 Our company reserves the rights modifying the content in this Instruction without pre-notify.

 Safety information

 Under the circumstance of stealing and lost, contact the telecom branch or sales outlet immediately.

 When you contact with telecom branch and sales outlet, it is necessary to provide them with IMEI number (printed on the badde of the arbora et a remove the butter, to discover in

- when you contact with refecom branch and sales outlet, it is necessary to provide them with IMEI number (printed on the back of the phone set, remove the battery to discover it). Please record the IMEI number and keep it safe for future use.
- ecautions such as:

 Set the PIN number of the SIM card, and update it timely When get off the car. Please do not leave the phone set unattended, keep it with you or in the suitcase. Set call barring

To prevent miss usage of your phone set please take

Safety and health precautions

Description of Keys				
Name of key	Letters or functions			
1key	,.?!"'-@:;/ 1			
2key	ABCabc2			
3key	DEFdef3			
4key	GHIghi4			
5key	JKLjkl5			
6kev	MNOmno6			

Call barring: All outgoing calls/All incoming calls/Incoming calls when roaming/ISD calling/Dial when INTL roaming/cancel all barring/change password Hide ID-Hide ID/Display own ID/Display ID by network Other:IP prefix/Call time reminder/Auto redial/Vibration when

,-?!`@:#\$/-1. In text editing interface, press "#" key to switch File manage . On the standby interface Press and hold "# Application tey to transfer the profile of General/Silen 88 Profiles Move cursor left Internet rolling left Move cursor right FM Radio eft soft key/ In the standby mode, press Left Soft key to access contacts.

Main menu, Right Soft key to access Contacts. Audio Ok key determining options Calendar Dial key dial telephone numbers and receive incor In the main display, you may see several icons shown on your status bar. 1.Return to idle screen 2.End calls or rej

l.after inputting telephone number, if you want t

input extension number, please press tw asterisk key, after the display screen shows "

olease input your extension number.

W.I	The SIM1 card's signal strength of the cellul	а		
3600	network at your current location.			
District	The SIM2 card's signal strength of the cellul	a		
15/4/1	network at your current location.			
(IIII)	The battery charge level.			
D	Contacts			

be displayed on the top of preview mode.

Store You can review pictures you have taken by pressing OK Switch to DV mode mode Effect Set photo color

Storage:phone/memory card

5.4.Image View the images 5.5.Recorder

To view the file memory

divide. The screen wi∎ initially display the number "0". Enter the first

Silent:Suitable for silent use.

Meeting: During the meeting, suitable for use.

Outdoor: Suitable for outdoor use
Indoor: Suitable for indoor use.

The service is provided by network operator, If SIM card or

10. FM radio

1.4.Import/Export

Export contacts

Own number

them to phone or memory card.

Copy contacts from phone/SIM card to SIM card/phone

Import contacts
Import contacts file from phone or memory card to

Choose some phone numbers in contacts then export

To edit the name and the number of your SIM card.

1.6.groups
You can view and edit the details of the group and

members of the group to remove or add operation.

Your phone provides the following selections for your

Mass texting
Send SMS to many phone numbers that you select from
Contacts.

2.1.Write message
You could write new message by using this function. When

you input the message to be sent, press left soft key to send, to insert the templates, to add contact person information, to add phiz and to save, etc. Within the write message menu you can write and edit text message up to 160 characters.

2.2.Inbox

After you have an incoming text message .The phone stores the message in the inbox folder of the SMS menu. When you fail to send a message. The phone stores the message in the outbox folder.

Memory status
To view the capacity of SIM card and phone.

option: Family/Friends/Business/Classmates

New group Add a new group

2. Message

Support the steps for reaching actual people to solve your

- Channel list: You can view all the broadcasting stations you saved.
-save:Save a channel to channel list.
-Manual search: Search the broadcasting station by input frequency manually.
-close/open speaker:You can start up loudspeaker to make the sound bouder.
-background play:you can do other operations while listening to the radio.
-Record to record a channel.
-Timing record:to set the time of recording and the channel.
-Record file list:list the record file you have recorded.

12. Calendar To view the calendar 2.5.Drafts

When you send a message successfully. The phone stores he message in the sentbox folder.

When you save a message you have written The phone stores the message in the drafts folder

2.6.Security inbox you can move a message from inbox ,outbox,drafts,sentbox

To enter the security inbox, you should input the security nbox password.

Your phone offers you a list of templates that you can use in replying to messages. You can also use templates who

2.8.Broadcast message Send or receive message to same area subscribers in Broadcast Message mode. You also can turn this function

on/off here. Receive mode: ON/OFF broadcasting function. Language: Turn On/Off all languages.

Language: Turn On/Off all languages.
Channel Setting: Set Broadcasting Message parameter.
2.9.Voice mail server
Line 1 number /Fax number/Data number
2.10.SMS Settings
SIM1 message center/SIM2 message center:to show your
text message centler.
Message validity period:6 hours/24 hours/72 hours/1
week/maximum

week/maximum Status report/You can request the network to send status reports on your text message(network service). A status report is indicated by in front of the message header. Save sent message:prompt user/save/don't save Preferred storage:phone/SIM 2.11.Message canacity.

2.11.Message capacity
to view the SMS memory of SIM card and phone.

- 5 -

3. Call logs

3.1.Missed calls
In Call logs menu, choose Missed calls and press "OK key" to
view the records.
Your phone provides the option to Recent Contacts with the

same.

3.2.Dialed number
In Call logs menu, choose Dialed number and press "OK key"
to view the records.

Your phone provides the option to Recent Contacts with the

same.
3.3.Received calls
In Call logs menu, choose Received calls and press "OK key" to view the records.
Your phone provides the option to Recent Contacts with the

same.
3.4.Rejected calls
In Call logs menu, choose Rejected calls and press "OK key" to view the records. 3.5.Delete call Your phone allows you to delete all of call logs.

3.6.Call timers
Your phone allows you to view the timers for calls made and In Call logs menu, choose Call timers, press "OK key" to view

 Last Call: List out the last call time of your conversation Received calls: Sum of total call time you have received.
 Dialed calls:Sum of total call time you have dialed.
 Reset All: Reset the time counter to zero.

4.1.Call Settings
Your phone provides the following selections for your option:
Dual-SIM:Standby mode/Reply by original SIM/Set SIM

Call divert:call forwarding unconditional/call forwarding on busy/call forwarding on no reply/divert if unreachable/cancel Call waiting: Activate/Deactivate/Query Status.

- 6 -

Modify PIN2:to modify PIN2 number Phone locked:on/off Modify the cellphone password Privacy :to choose the functions that you need to enter password when entering. Lock screen by end-key:to lock screen by end-key.

4.5.Connections
Network selection:Auto select/Manual select

5. Multimedia

5.1. Camera
The camera lens is on the top of the phone, and the display of the phone works as a viewfinder. If there's not enough memory for camera, you need to delete old photos to free some spaces for new photos or you can choose to save

Onter. In President and refinition/Audit etidar/Vioration when connected (Reply SMS after reject/Auto record voice call 4.2.Phone settings Into the phone set up sub-menu, you can set the following: Date and time: At the time and date menu, you can set the time, date.
Language setting: Includes languages type.
Shortcut settings:to define the shortcut functions.
Auto power on/off:In this menu, you can set the timer switch machine.

settings.
4.3.Display
Wallpaper settings/Idle display settings/Contrast/keypad
backlight/auto keypad lock
4.4.Security settings
Your phone provides the following selections for your option:
PIN:on/off/Modify PIN

machine.
Restore factory settings:input password to restore factory

Guardlock:status/change password
Fixed dialing: fixed dialing/Fixed dialing number Black list: blacklist list/blacklist setting:

Size:Set photo size Quality:Set photo quality Banding:to avoid flashing Shutter sound:activate/off Auto save:activate/off

5.2.DV You can record the video clip through build-in camera. The status of your video recorder setting will be displayed on the top of preview mode. To start using Video recorder in Multimedia menu, select Video recorder and press "OK key" Press Options to personalize your camera setting.

5.3.Video

Key Video Play Function

Press Will can play or pause video

Short press Will can choose the previous and next

Video long press Will can choose the previous and next

Video long press Will can fast back or fast forward.

Note: You can adjust this volume +/- through scrolling

righthleft key.Press Skey to adjust brightness.

Play: Allows you to play the video saved in the My stuff.

Local play listlist the video files of phone and memory ca

Shuffle-whether to shuffle play

Repeatto set the play mode, off/repeat all/repeat one

Settings:Local video play mode/settings reset/help

Details:to view the details of a video file

5.4.Image

6. File manager

7. Application

1. Contacts

qualified records.

will be stored to mobile phones.

7.1. Calculator
This function enables you to add, subtract, multiply and

You can use the Contacts features business card information

1.1.Quick search
Enter the name of the first letter in the contacts to find

1.2.New In the options, add a telephone number to phone or SIM

card.

1.3.Delete multiple choose to delete phone numbers from SIM or Phone, you can mark all of the phone numbers then choose "OK" to delete , you can also choose to delete them one by one.

- 3 -

The screen will initially display the number "0". Enter the first number to be calculated.

7.2.Alarm
To set a new alarm, alarm clock icon will be displayed when an alarm is active.

At the same time, three groups can be set up alarm clock.

7.3.Bluctooth
Your phone provides the following selections for your option: Bluetooth/Bluetooth visibility/Paired device/Transferring fles/device name/Bluetooth file storage/help
According to the menu, will enter the corresponding function set.

8. Profiles

Normal: Suitable for normal use.

network operator fails to provide the service, the function can not be available. Contact network service operator, if you want to have more information.

You can listen to Fm radio freely with plug in the earphone. Enter the radio interface, search the frequency, (87.5-108.) Auto search and save/Channel list/save/Manual search/dose/open speaker/background play --Auto search and save:Search frequency available automatically.

Channel list: You can view all the broadcasting stations you

- 4 -

11. Audio

Key Audio Play Function
Press Land Can play or pause music
Short press Land Can choose the previous and next
Music long ress Land Can fast back or fast forward.
Note: You can adjust this volume +/- through scrolling up/down key.
Music list:to list the musics of your phone and memory card.
Add:to saved play list/to new play list
Set as ringtone:set as incoming call ringtone/set as alarm

ringtone
Shuffle.whether to shuffle play
Repeat:to set the play mode,off/repeat all/repeat one
Settings:Equalizer/BT stereo output/BT stereo headset
Open review:to review music

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable profection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and. If not installed and used in accordance with the

reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certifiled power level in all tested frequency bands, although the SAR is determined at the highest certifiled power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is a available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body)as required by the FCC.

■ For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that Contains no metal and that positions the handset a minimum of 5 mm from the body.

■ Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

1. Información básica

1.1 Instrucción

Las Instrucciones sobre cómo hacer funcionar el teléfono se detallan en este manual del usuario. El teléfono MAXWEST es compatible con GSM y GPRS. El MAXWEST incluye todas las funciones básicas que se esperan de un teléfono con muchas más características,

como Bluetooth, cambiador de voz, cámara, reproductor de música, reproductor de vídeo, radio y muchos más. Estas funciones están diseñadas para la comodidad y

peligroso o ilegal. Lea la guía del usuario para obtener más información. Nota: La calidad de la llamada y la conexión depende de su proveedor de servicio local y de la señal. No nos hacemos responsables de cualquier daño físico o daños materiales

2. Apariencia

2.1 Descripción del teclado

Mover el cursor a la izquierda o derecha durante la edición. Mientras que en reposo, oprima la tecla izquierda de navegación al menú [Bandeja de entrada], pulse la tecla de navegación hacia la derecha al menú [perfiles]. Durante el uso de la aplicación de la cámara, pulse la tecla izquierda / pulse la tecla izquierda de navegación puede

- 1 -

Pulse la tecla programable izquierda para operar su foto

Renombrar, Eliminar, Eliminar todos los archivos de su foto, también se les

Ha separado imagen. Presione la tecla de navegación hacia

El auricular es compatible con función de grabación de

Esta función muestra la lista actual de la grabadora que se

almacenan en el teléfono, el apoyo grabadora de AMR y

archivo. Si su teléfono no tiene la grabadora, la pantalla le

soporte (también se puede utilizar en el estado de energía

Esta función de grabación del horario FM teléfono de

seleccionada, se puede ver, buscar Estilo, Enviar,

puede cambiar la posición de almacenamiento.

arriba / abajo para navegar.

3.5.4 Grabador de sonido

pedirá - 9 - [Vaciar carpeta].

apagado). Puede configurar

Mrecord horario múltiples.

3.5.6 Espectáculo de diapositivas

3.5.5 Lista FMrecord

3.5.3 Video

2.1.2 Tecla arriba / abajo de navegación Ver el nombre, número de llamada, mensaje y todas las opciones del submenú. Mover el cursor a arriba o hacia

abaio cuando edición. En estado de reposo, presione la tecla de navegación al menú [alarma]. 2.1.3 Tecla suave izquierda Para realizar la función del indicador que aparece en la

- 8 -

squina inferior izquierda de la pantalla 2.1.4 Tecla suave derecha Para realizar la función del indicador que aparece en la . quina inferior derecha de la pantalla

2.1.5 Tecla de marcación Para marcar o extracto de un número de llamada entrante. En el modo de espera, presione la tecla de marcación para mostrar la llamada SIM1

2.1.6 Tecla colgar

Para finalizar una llamada o rechazar llamadas entrantes. Mantenga pulsado este botón para el encendido / apagado. Bajo la mayoría de circunstancias al pulsar esta tecla pondrá el teléfono móvil en modo de

2.1.7 Número clave

0 ~ 9 tecla numérica número de entrada de Can y palabra, la velocidad para seleccionar el menú de opciones llamada velocidad (la llamada debe ser almacenado en el directorio telefónico).

2.1.8 Tecla * 2.1.9 Tecla #

Tiene función diferente en diferentes menús. iene función diferente en diferentes menús. 2.1.10 Medio clave

que la izquierda tecla de función 2.1.11 EX1

Anillo y vibran

SIM1 abierta Desvío

En el modo de espera, llave EX1 presione para entrar en

registros de llamadas SIM2. 2.1.12 EX2 En el modo de espera, presione la tecla de cámara o EX2 FM u otro menú principal.

Consejo: En este manual, la frase "pulse la tecla" se refiere a pulsar y soltar un tiempo clave "Mantenga pulsado una tecla" se refiere a pulsar una tecla y mantener pulsado durante 2 segundos o más. 2.2 Icono Descripción

Icono Descripción Cuantas más barras aparezcan, mayor será la intensidad de la señal GPRS conectado Bloqueo de teclado [™] Vibrar

Anillo. Vibrador y después melodía €auricular de entrada Indicador de itinerancia ndicador SMS Indicador MMS Mensaje de voz Configuración y alarma abierta

SIM2 abierta Desvío La llamada de SIM1 Estado de la batería Bluetooth abierto

3.14.3 Configuración del teléfono

1) El tiempo y la fecha

ronómetro de usos múltiples abierto

2.4 Conectar Red 2.4.1 Tarjeta SIM Asegúrese de que se inserta una tarjeta SIM antes de

a usted por su proveedor de servicios. no tocar la parte metálica de la tarjeta SIM y mantene alejado de los imanes y la electricidad. Si la tarjeta SIM se

de alimentación externa, ya que esto podría dañar potencialmente la tarjeta SIM. 2.5 Funciones característicos

para borrar la entrada error, mucho tiempo estado de la llamada, puede dirigir tecla numérica de prensa para el número de entrada si es necesario. Para

"0" hasta que aparezca el prefijo telefónico internacional "+" en la pantalla ("+" en lugar de 00). 2.7 Las llamadas de emergencia

diferencia pulsando el botón OK 4. El modo de introducción de texto

batería terminada.

Tecla de función izquierda: confirman Tecla de función derecha: el retorno o clara Tecla de navegación: mover el cursor o seleccionar esperar 0 ~ 9: número de entrada o carta.

EX2: pulse esta tecla para menú de la cámara. reemplazo de la batería tipo incorrecto causará una explosión peligrosa. Asegúrese de seguir las instrucciones para hacer frente a la

www.maxwesttelecom.com

conditions:

(1) This device may not cause harmful interference, and
(2) this device must accept any interference received,
including interference that may cause undesired operation.

Interceptions, may cause narmful interference to radio communications. However, it is no guarantee that interference will not occur in a particus stallation. If this equipment does cause harmful interference to radio or elevision.

M maxwest

Manual Del Usuario

contacto con su proveedor de servicios para obtener más

Esto redireccionará automáticamente las llamadas

nero para acceder a su correo de voz

entrantes al centro de correo de voz cuando no se puede

que la persona que llama puede dejar un mensaje en el

Entrar en el menú del reproductor de audio, presione

controlar la música para reproducir / pausa y parada.

Pulse la tecla izquierda de navegación / derecha para

cambiar la música, presione "*" y la tecla "#" para ajustar

lista de reproducción, pulse submenú "opción" pop-up

navegación para encontrar menú multimedia, pulse la

Utilizar esta función, tomar una foto o un vídeo por sí

mismo ama y guardar en el archivo de orden de la tarjeta

En el estado de menú principal, pulse la tecla de

tecla programable izquierda para entrar, o pulse

ono de multimedia para acceder a este menú.

el volumen. Oprima hacia la izquierda tecla de entrar en la

hacia arriba de navegación / abaio - 8 - clave para

sistema de correo de voz de la red de servicios. Marque la

detalles sobre la facturación y los ajustes.

Esta función se basa en SMS.

aceptar una llamada para

casilla de correo de voz

3.2.5 Mensaje de difusión

3.3 El jugador Audio

3.5 Multimedia

3.5.1 Cámara

en su teléfono.

de memoria o tienda

3.5.2 Imagen espectador

3.2.4 servidor de correo de voz

Gracias por elegir el nuestro teléfono móvil Maxwest .

mejorar la experiencia del usuario. 1.2 Para su seguridad Por favor revise estas sencillas instrucciones para su propia seguridad. No seguir estas instrucciones puede ser

dehido a un uso inadecuado

abrir el menú de opciones, pulse la tecla de retorno de

arriba / abajo de navegación para activar o desactivar la función de los canales de búsqueda, pulse la tecla de navegación izquierda / derecha para buscar canales automático hasta que buscó un canal. Cierre la función de púsqueda automática, puede buscar un canal por lo que

En el modo de espera, presione la tecla para entrar en el

menú principal. En otros submenús, que funciona igual

- 2 -

3.9 Alarm Pulse las flechas arriba / abajo y derecha / izquierda de la tecla de navegación - 10 - Interruptor para editar la fecha,

ontinuación, pulse submenú tecla izquierda de entrar en historial de llamadas

3.11 Organizador

En esta función, se mostrará la lista de llamadas perdidas. Seleccione un registro de llamadas perdidas, presione la tecla programable izquierda para visualizarla detalle 3.12.2 Configuración general de llamada

3.14.1 configuración Dual SIM Esta función incluye Dual SIM abierto, sólo SIM1 abierta, sólo el submenú de modo abierto y la fuga de SIM2. 3.14.2 calibración de la pantalla Tocar

Introduzca la calibración de tocar la pantalla para calibrar

Aiustar la hora local de la ciudad como su tiempo de 3) Ajuste de hora Se puede establecer una fecha y hora 2000-2030 4) Formato Establecer hora Puede establecer 12 horas o formato de 24 horas El teléfono tiene cuatro potencias On / Offtiempo para

Establecer la información de seguridad para proteger su tarjeta de teléfono y la tarjeta SIM contra el uso no 3.14.6 Restaurar fábrica Introduzca la contraseña de inicio de teléfono (número predeterminado es - 12 - 0000. Esta característica se restablecerá el teléfono a la misma

Nota: la función no se puede utilizar si el encendido /

apagado de tiempo se estableció el mismo

ajustes como los configurados en la fábrica.

3.14.4 Configuración de la red

3.15 Los perfiles de usuario

3.14.5 Configuración de seguridad

necesidad. Los perfiles de usuario incluyen en general, reunión, al aire libre, de interior, auriculares v Bluetooth. 3.16 botón de la luz de la antorcha Puede abrir la luz de la antorcha pulsando el botón OK durante mucho tiempo. Si la luz de la antorcha ha sido

Puede establecer perfiles de teléfono de acuerdo a su

2.3 De la batería Para un uso óptimo por favor asegúrese de que el celular se carga a plena capacidad antes de usar.

utilizar su teléfono. La tarjeta SIM debe ser proporcionada Toda esta información es almacenada en la tarjeta SIM, tales como información de contacto, agenda, La música , etc se almacena en la tarjeta SIM. Para un uso óptimo de

ha roto el teléfono el teléfono podría no ser capaz de completar todas sus funciones. Advertencia: Antes de insertar o extraer la tarieta SIM. asegúrese de que el teléfono esté apagado.
Asegurece que el teléfono no está conectado a una fuente

2.6 Realización de llamadas En estado de reposo, pulse la tecla de número a número de llamada de entrada, pulse la tecla de función derecha pulsar la tecla de función derecha para borrar todas las entradas. Pulse la tecla programable izquierda para guardar el número de llamada de teléfono o tarjeta SIM. Pulse la tecla de marcación para realizar una llamada. En

se abre al pulsar el botón lateral, no hará ninguna

4.1 Recapitulación definición 4.2 Teclado

Tecla #: cambiar el modo de entrada Clave: En el estado de entrada, presiónelo cuadro de entrada de símbolos para abrir. EX1: pulse esta tecla para ver los registros de llamadas

Gracias por elegir nuestro teléfono Maxwest - Si necesita cualquier información adicional, por favor, póngase en

2.8 Responder a una llamada

2.9 Finalizar una llamada

2.10 Historial de llamadas 2.11 opción de llamada

3. Función 3.1 Teléfono libro Puede guardar campos de información ya sea a su tarjeta SIM o el teléfono, esta información incluye el nombre linkman, número de teléfono, número de casa, nombre de la empresa, correo electrónico, teléfono de la empresa, número de fax, cumpleaños, tono de llamada selecto, grupo de llamada. Mientras la prensa de inactividad la

tecla derecha para "libreta de teléfonos", ver el registro de NOTA: El auricular almacenar max 250 pcs registros telefónicos, base de la memoria de la tarjeta SIM en la misma capacidad.

Mientras la tecla de navegación para seleccionar

"Mensajes" para entrar en el submenú, incluyen SMS, Chat y mensajes de voz del servidor de difusión Enviar un mensaje de texto por el Centro de Servicio. La

ción, melodía, tono de llamada en un mensaje. Acerca de MMS MMS o "servicio de mensajes multimedia", es la mejor manera de apoyar multimedia y es capaz de envia

imágenes, sonidos y otra información de formato

multimedia.

■ Cualquier cambio o modificación no aprobados expresamente por la parte responsable del cumplimiento podrían anular la autoridad del susario para utilizar los equipamiento. Este dispositivo cumple con la parte 15 de las normas de la FCC. La operación está sujeta a las siguientes dos condiciones:

(1) Este dispositivo no puede causar interferencias perjudiciales y (2) este dispositivo to puede nue presente de la desente de la cualquier interferencia recibida, incluyendo interferencias que puedan causar un funcionamiento no deseado.

deseado.

Nota: Este equipo ha sido probado y cumple con los límites para un dispositivo digital de Clase B, de acuerdo con la parte 15 de las normas FCC. Estos límites están disendados para proporcionar una protección razonable contra interferencias perjudiciates en una instalación residencial. Este equipo genera, utiliza y puede instrucciones, pede el causar inferferencias perjudiciales el na radio et comunicaciones. Sin embargo, no hay garantía de que no se produzcan interferencias en una instalación particular. Si este equipo causar interferencias perjudiciales en la radio o la recepción de televisión, que puede ser determinado girando el equipo apagado y, se recomienda al usuanto que interfere corregir la interferencia mediante una o más de las "Recorienta" o reubicar la antena receptora.

-Recorientar O reubicar la antena receptora.

-Recorientar O reubicar la antena receptora.

-Concete El equipo a una toma de un circuito distinto de aque al que está conectado el receptor.

■ Las pruebas de SAR se realizan en posiciones de funcionamiento estándar aceptadas por la FCC con el teléfono transmitiendo a su nivel más alto de potencia certificado en todas las bandas de frecuencia probadas, aunque el indice SAR se determina al máximo nivel de potencia certificado, el nivel SAR real del teléfono en funcionamiento puede estar muy por debajo del valor máximo, en general, cuanto más cerca se encuentre de una antena de estación base inalámbrica, menor será la potencia de salida.

Antes de que un nuevo modeio de teléfonc es una disponible para su venta al público, debe ser probado y certificado ante la FCC que no excede el limite de exposición establecido por la FCC, pruebas para cada teléfono se realizan en posiciones y ubicaciones (por ejemplo, en el oreja y llevándolo en el cuerpo) requeridas por la FCC.

Para usario en el cuerpo, este modelo de teléfono ha sido probado y cumple con las pautas de exposición a RF de la FCC cuando se utiliza con un accesorio designada para este producto o cuando se utiliza con un accesorio que no contiene metal y que posiciona el dispositivo a una distancia minima de 5 m md el cuerpo.

borrar, eliminar todos los archivos de ellos, también se les puede cambiar la posición de

3.8 FM Radio

de esta carpeta. 3.6 Gestor de archivos 3.7 Reproductor de vídeo

almacenamiento. Ordena, establece Bluetooth.

tarjeta de memoria o el teléfono, y reproducir imágenes En este menú puede ver la lista de archivos de vídeo y oprima la tecla izquierda para jugar, enviar, renombrar,

El teléfono ha construido en función de radio, basta con

insertar un auricular para abrir esta función. En el menú de

Puede seleccionar una carpeta, que se almacena en la

derecha para añadir o 0,1 MHz minis.

a mano. Pulse una vez la izquierda o la tecla de navegación

3.12.1 Las llamadas perdidas

Pulse la tecla de navegación para esta función, a

3.13 Servicios 3.13.1 Cuenta de Datos 3.14 Configuración En opción, puede configurar el teléfono como su

- 9 -

- 10 -

- 11 -