
Honeywell



Portable Air Conditioner Aire Acondicionado Portable Climatiseur Portable

OWNER'S MANUAL

Read and save these instructions before use

MANUAL DEL PROPIETARIO

Lea y guarde estas instrucciones antes de usar la unidad

MODE D'EMPLOI

Lire et conserver ces instructions avant utilisation

Model / Modelo / Modèle:
MN series IM

Voltage rating / Tensión / Tension nominale: 120V-60Hz

For product inquiries or support / Para consultas del producto o soporte
Pour les questions sur les produits ou pour du soutien:
www.honeywellportableac.com

Customer Support / Atención al cliente / Soutien au client: USA 1-800-474-2147 CANADA 1-888-209-0999 Made in China Hecho en China Fabriqué en Chine

INDEX

Read all instructions carefully before setting up and operating the unit. Keep this instruction manual for future reference. This manual is designed to provide important information needed to setup, operate, maintain and troubleshoot your portable air conditioner. Failure to follow these instructions may void the warranty.

SECTION		
1.	INDEX	. 1
2.	THANK YOU	. 2
3.	USER TIPS	3
4.	SAFETY	4
5.	PARTS DESCRIPTION	6
6.	INSTALLATION	7
7.	USE & OPERATION	10
8.	CLEANING & MAINTENANCE	13
9.	WATER CONDENSATION DRAINAGE	14
10	TROUBLESHOOTING GUIDE	15
11	.TECHNICAL SPECIFICATIONS	16
12	SERVICE AND WARRANTY	17

THANK YOU

Congratulations on your purchase of this versatile Honeywell Portable Air Conditioner.

Honeywell Portable Air Conditioners are ideal for spot cooling. The compressor, condenser and evaporator are housed in a compact unit. The air is filtered, dehumidified and cooled while a flexible air outlet hose sends heat outside. The air conditioner includes a window venting kit. No permanent installation is needed. The unit is easy to move from room to room and offers a truly flexible air conditioning solution.

Auto Evaporation System - The unit automatically evaporates the condensate through the air outlet hose. There is no need to empty the drainage tank except in very high humidity conditions.

Read and follow the instructions carefully.

USER TIPS

To ensure optimal efficiency of the product, keep doors and windows closed when it is used as an air conditioner or dehumidifier.

If the product is being used with the fan function only, an open window could improve air circulation.





Cooling and Dehumidifying Operation

Fan Operation

Important : Before installing the unit, place it <u>UPRIGHT for 20 minutes</u> before use to allow the refrigerant to stabilize.

Manually adjust the air vent located at the top of the unit to adjust the direction of air flow.

- Follow installation instructions to set up the unit.
- Plug the unit into a properly grounded circuit.

SAFFTY

READ AND SAVE THESE INSTRUCTIONS

Improper handling can cause serious damage to the appliance.




WARNING

- 1. DO NOT operate the unit with a damaged plug or loose wall outlet. If the power cord is damaged, it must be replaced by the manufacturer or an authorized service agent.
- 2. DO NOT cover the air intake and exhaust when in use.
- 3. This appliance is not intended for use by children. Children should be supervised and should not play on or around the appliance.
- 4. DO NOT place objects on or sit on the unit.
- 5. Always turn off and unplug the unit when cleaning or servicing.
- 6. If service is needed contact an authorized service agent.
- 7. Unplug the unit when stored or not in use.

SAFETY

- 8. DO NOT run the power cord under carpeting and rugs.
- 9. Use caution to prevent tripping on cord.
- 10. DO NOT use in areas where gasoline, paint or other flammable goods are stored.
- 11. Basic safety precautions should always be followed when using electrical appliances.
- 12. This appliance has been manufactured for use in domestic environments and must not be used for other purposes.




- 1. Control Panel (Incl. Signal Receptor)
- 2. Air Outlet
- 3. Handle
- 4. Casters
- 5. Upper Drain Plug (De-humidifier Mode) 11. Remote Control
- 6. Air Filter

- 7. Back Grill
- 8. Lower Drain Plug (Air Conditioning Mode)
- 9. Power Supply Cord
- 10. Exhaust Hose Connector


Installation Kit:

1. Window Bracket Kit	1	Set
2. Window Bracket Panel Adapter	1	Piece
3. Plastic Pin	2	Pieces
4. Hose Connector	1	Piece
5. Plastic Hose	1	Piece




INSTALLATION

1 Install the plastic hose with window bracket adapter and hose connector on both sides. Ensure proper fit on both ends.




Adjust the window bracket as per width or height of your window and insert the plastic pins to fix at the desired position. There is a hole where the Plastic Hose will be inserted later. Make sure this hole is not blocked.




Note: Do not install the window bracket to your window. This step is required only to adjust it to the size of your window. The bracket should be removed from the window after the size is adjusted.

③ Connect the plastic hose to the hose connector on the back of the unit. Push-in until it is locked in place.




INSTALLATION

(4) Connect the window bracket to the opposite end of the plastic hose. Ensure that all connections are tight and installed properly.



(5) Connect the window bracket to the window.




(6) The Portable Air Conditioner is now ready to use.

INSTALLATION

Note:


- 1. The supplied exhaust hose can be extended from 12 inches (1 foot) to 47 inches (3.9 feet).
- Do not bend (to the extent shown below) the exhaust hose.A bent hose will block exhaust air and cause the unit to malfunction or shut-off.



Warning:

- The length of the exhaust hose is determined by the product specifications. Do not replace or lengthen it as this could cause the unit to malfunction.
- Make sure the back of the unit is at least 20 inches away from a wall.
 Do not place the unit in front of curtains or drapes as this could obstruct the airflow.

USE & OPERATION



Power Control

The Power Control turns the unit on and off.

Mode Control

3 settings: Cool, Dehumidify and Fan

A light will indicate which setting is currently being used.

• Cooling Mode *

The unit works as an air conditioner. Adjust fan speed and air temperature to suit your desired comfort level. Temperature setting range is 61°F~89°F.

• Dehumidifying Mode 🗇

Air is dehumidified as it passes through the unit, without being in full cooling mode. If room temperature is higher than 77°F fan speed can be adjusted; otherwise fan speed is preset "LOW".

Note: If the unit will be used mainly as a dehumidifier, do not connect the exhaust hose and let the warm air return in the room. Continuous drainage is then necessary and more efficient (refer page 14, Continuous Draining).

• Fan Mode 9

For air circulation without cooling.

• Fan Speed Control

3 settings: High, Medium and Low.

Timer Control Auto turn off:

With machine in running mode, press timer button to select the number of hours you want the unit to run in air conditioning mode.

Auto turn on:

With machine in stand by mode, press the timer button to select the number of hours until you want the unit to automatically start running.

Temperature / Timer Set Controls

- Used for adjusting the timer and thermostat.
- The default display is room temperature.
- In cooling mode, when "▼" or "▲" button is pressed, the set temperature is displayed and may be adjusted. After 10 seconds the display will revert back to room temperature. Temperature is only adjustable in cool mode.

The time is adjustable between 1~24 hours.

Note: By pressing both " ∇ " / " \triangle " set buttons at the same time, the display will toggle between Celsius and Fahrenheit.

Warning Light


Condensed water may accumulate in the unit. If the internal tank becomes full, the Power Light will flash and the unit will not operate until the unit has been drained (refer page 14, Water Condensation Drainage).

After switching the air conditioner off, you must wait 3 minutes before switching it back on again.

USE & OPERATION

Remote Control

The functions work the same as the portable air conditioner's touch controls. All key functions can be accessed from the remote control.



Caution


• Do not place the remote control in direct sunlight.

USE & OPERATION

Battery Installation: Remove the cover on the back of the remote control and insert two AAA batteries with + and - pointing in the proper direction according to the polarity markings.







Caution ot

- Use only two AAA or IEC R03 1.5V batteries.
- Remove the batteries if the remote control is not in use for a month or longer.
- All batteries should be replaced at the same time, do not mix with old batteries.
- Properly dispose of used batteries.

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment dose cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement Caution:

To maintain compliance with the FCC's RF exposure guidelines, place the product at least 20cm from nearby persons.

CLEANING & MAINTENANCE

Appliance Maintenance:

- 1. Turn off the appliance before disconnecting the power supply.
- 2. Always clean the appliance with a soft dry cloth.

Air Filter Maintenance:

The air filter should be cleaned every two weeks.

Clean it as follows:

- 1. Turn off the appliance and remove the air filter (refer to page 6, #6).
- 2. Rinse it in lukewarm water. After cleaning, dry in a shaded and cool place, then reinstall.

End of Season Storage & Maintenance:

If the appliance will not be used for a long time:

- 1. Be sure to drain the left-over water condensation. Remove the lower drain plug and use a shallow pan to collect the water (make sure to replace the drain plug when finished).
- 2. To dry excess moisture, run the unit in Fan only mode for 30 minutes before storing.
- 3. Turn off and unplug the air conditioner from the power supply.
- 4. Remove the air filter and clean with water. Dry the air filter and then reinstall onto the unit.
- 5. Disconnecting the Window Installation Kit:
 - Remove the Plastic Hose from the unit by rotating it slightly clockwise and pulling away from the unit at the same time.
- Remove the Window Bracket, Window Bracket Panel Adapter and Hose Connector.
- It is recommended to store the Window Kit parts in a bag together with the Remote Control and placing them together with the air conditioner unit.
- If needed, you can clean the Window Kit with a damp cloth and water before storing.
 Make sure all parts of the Window Kit are dry before storage.
- 6. Cover the air conditioner with a cloth/ plastic bag before storage, to protect from dust and scratches collecting on the surface of the unit.
- 7. It is recommended to coil the power cord and store it away from the floor to ensure the cord is protected from bents and creases.

WATER CONDENSATION DRAINAGE

Water Condensation Drainage

When there is excess water condensation inside the unit, the air conditioner stops running and shows a warning light (refer to page 10). This warning light indicates that the water condensation needs to be drained using the following procedures:

Manual Draining

Water may need to be drained in high humidity areas

- 1. Unplug the unit from power source.
- 2. Place a shallow pan under the lower drain plug. See diagram.
- 3. Remove the lower drain plug.
- 4. Water will drain out and collect in the shallow pan.
- 5. After the water is drained, replace the lower drain plug firmly.
- 6. You can now turn on the unit.

Continuous Draining

While using the unit in dehumidifier mode, continuous drainage is recommended.

- 1. Unplug the unit from the power source.
- 2. Remove the upper drain plug. While doing this operation some residual water may spill so please have a pan to collect the water.
- 3. Connect the drain connector to a ¾" hose (not included). See diagram.
- 4. The water can be continuously drained through the hose into a floor drain or bucket.
- 5. You can now turn on the unit.

