
## OPERATIONAL MANUAL

SINGLE DIN CAR MP3/USB PLAYER WITH BLUETOOTH



## Manual

Thank you for buying this product. Please read through these operation manual so you will know how to operate your model properly.

## Important Reminder

- 1.If your vehicle is exposed to direct sunlight which causes excessive heat in the vehicle, then you should wait for lower temperature to operate this head unit.
- 2.If the machine does not have a supply power, Please check the connection status and see whether everything is normal. Check the fuse.
- 3. When playing from USB, please be careful not to enter a damaged file, to prevent damage from the machine. Unplug USD / SD card if it's not used for a long time.
- 4. Avoid shorting. Do not place metal objects (screws, coins) and other components into unit.
- 5.Before installation, please pay attention to the wiring diagram and connectivity. Avoid short-circuit
- 6.The unit can play MP3/WMA music format. Do not open a picture or video on this unit. The unit will display MP3/WMA which is being played currently.
- 7. This unit supports Bluetooth calling and Music playback from your phone. The unit however does not support a phone book function. The incoming/outgoing number will be displayed and read aloud by the unit.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.


#### INSTALLATION INSTRUCTION


Please pay attention when installing the wiring diagram


- 1.Installation of metal connection: consider an illustration, a set of metal into the instrument panel. With the driver. Power and polarity: positive line and positive pole of the battery and ground the negative (negative pole at the end)
- 2.Check to avoid shorting, that everything is connected and then connect the negative pole of the battery.
- -Yellow (cable memory): a positive connection with the 12v constant voltage (supplied with the machine memory lane)
- -Red (power cord) : 12v power switch and connected (with the lines on the vehicle ignition switch controls) Speaker cable connection: this tool is design to use speakers with impedance of 4-8 Ohm Disconnect power to the connected speakers to avoid shorting.

Note: Do not use the speakers connected to ground or a body or touched one another. Do not combine with the power cord, as this may cause damage to the machine. Replace the fuse that had gone bad. Remove first the bad and replace it with a fuse that has the same size that is new to the block output.

#### Installation of Instruction:








#### OPERATION MANUAL

# USB/SD/MMC/MP3/WMA PLAYER WITH RADIO RECEIVER& BLUETOOTH

### MP3/USB




### Panel function

- 1.On/Off
- 2.EQ/LOUD
- 3.Mode/Reject or hang up a call
- 4.Band/Answer phone
- 5. Station tuning, fast forward and rewind
- 6.Clock adjustments
- 7.Preset stations
- 8. Aux input
- 9.SD card slot
- 10.USB port
- 11.AMS
- 12.Display

#### **BLUETOOTH CONNECTION:**

Turn on the unit, Find the bluetooth name "car kit"in you phone then clik to connect. Once connected, The bluetooth icon on the screen of the device will stop flashing. Press"BAND"to respond and "Mode"to finish a phone call.



#### Remote function

- 1. Power Switch
- 2. Mute
- 3. Band
- 4. Last Track
- 5. Next Track
- 6.Clock
- 7. Volume Down
- 8. Volume Up
- 9. Multifunctional Selection Key
- 10. Radio Search
- 11.EQ
- 12. 0.1.2.3.4.5.6.7.8.9. digital key

# MAINTANANCE AND TROUBLESHOOTING

### SPECIFICATION

1.Power is not enough?

Box Fuse: make sure there's no short-circuiting between the wires; replace the old fuse with appropriate capacity. ACC position Auto Ignition System: hints same cable connected to the battery. A memory connected to the power lines and the positive power supply.

2.Off button doesn't work Press the reset button on the panel. If it still does not work, unplug the power and plug it in again after a while.

3.No response after pressing LOUD on some conditions for the selection of the source to adjust the tuning source, without any bass compensation.

4. Silence or noise

Balance or control sound settings are set on one side, fader and balance settings at the center position.

Cable input / output cable is connected properly

5.The sound quality (distortion)
Speaker wires pinched by a screw. Recheck the speaker cable and the output terminal of the speaker

6.Poor radio reception

Check if the antenna under normal conditions. Check If the antenna socket either with or without contact.

FM Radio

Range Tuning: 87.5 – 108.0 Mhz

Sensitivity: =< 20 dB

Stereo Separation: =>25 dB

SNR: => 60 dB

Playback Information Music Format: MP3, WMA Display Format: ID3 Display

Distortion: =<0.3% SNR: => 60 dB

Panel Size

PxLxT: 188 x 150 x 58 (mm)

Dimension Attached

P x L x T : 178 x 150 x 50 (mm)

Power Supply

Machine 12V: 11 – 16V

Note: This machine is 12V machine, not

suitable for power supply 24V

Audio

Temperature operation: -20 - +60°C

Speaker impedance: 4 Ohm

Frequency response:  $20 - 20000 \, \text{Hz}$ 

Fuse Red: 1A Yellow: 10A

Bluetooth
Calling Profile
A2DP

Audio/Video Control Transport Protocol	AVCTP 1.4 Controller Target
Audio/Video Remote Control Profile	AVRCP v1.3 AVRCP v1.3 Controller Target
Generic Audio/Video Distribution Profile	Acceptor GAVDP 1.2 Initiator
Audio/Video Distribution Transport Protocol	Acceptor AVDTP 1.2 Initiator Sink
Advanced Audio Distribution Profile A2DP 1.2	A2DP 1.2 Sink (SNK)