



## Quick Start Guide

### For Mechless and CD Receivers

Not all features listed in this QSG are available on all models.

• • • • • • • • • • • •



To download the complete, model-specific manual, please visit [www.dualav.com/support/manuals.php](http://www.dualav.com/support/manuals.php) or call 1-866-382-5476, 9AM-5PM EST (Monday-Friday).

## Installation

### Before You Start

- Consult a qualified technician for instructions. Dual always recommends professional installation.
- Disconnect negative battery terminal.
- Remove trim ring from unit (if installed).
- Remove 2 transit screws located on top of the unit (if applicable).
- Insert the removal keys, and remove the mounting sleeve from the head unit.

**Note:** Most vehicles require an installation kit, wiring harness and/or antenna adapter (all sold separately) to properly install the head unit in the vehicle.

### Installation Process

1. Carefully remove the existing head unit.
2. Connect wiring harness. Consult a qualified technician if you are unsure.
3. Mount the head unit using the mounting sleeve or ISO brackets (depending on your vehicle's dashboard).
4. Connect wiring harness and antenna. Test the head unit for correct operation.
5. Slide into mounting sleeve to secure, or mount the ISO brackets to the vehicle.
6. Snap trim ring into place.

### Wiring Connections

The chart below shows the connection for each wire in the wiring harness.


Color	Connection
Red	12V Ignition / Accessory
Yellow	12V Battery / Memory
Black	Ground
Blue	Power Antenna / Amp Turn-on
Grey	Right Front (+)
Grey/Black	Right Front (-)
White	Left Front (+)
White/Black	Left Front (-)
Violet	Right Rear (+)
Violet/Black	Right Rear (-)
Green	Left Rear (+)
Green/Black	Left Rear (-)

**Tip:**  
When a suitable ground wire is not present in the vehicle wiring harness, connect the black ground wire to the vehicle chassis.


**Fuse:**  
When replacing the fuse, make sure new fuse is the correct type and amperage. Using an incorrect fuse could damage the radio.

## Installation


### Mounting the Head Unit: Typical DIN mounting




**Step 1:**  
Insert the mounting sleeve into the installation kit or dashboard.



**Step 2:**  
Bend multiple mounting tabs around the mounting sleeve until the mounting sleeve is secure.



**Step 3:**  
Connect all wiring harnesses and slide the head unit into the mounting sleeve until it clicks into place.



### Mounting the Head Unit: ISO mounting

Using the existing brackets or the brackets supplied with the installation kit, mount the brackets to the sides of the head unit with the screws supplied with the head unit.

## CD Operation\*

Insert CD	With the label facing up, insert a standard size CD into the CD slot. Playback will begin automatically.
Eject CD	Press EJECT (located behind the front panel) to eject the CD. The unit will change to previous mode of operation.
Track Select	Press TUNE ►► to skip to the beginning of the next track. Press TUNE ◀◀ to return to the beginning of the current track. Pressing TUNE ◀◀ again skips to the beginning of the previous track.
Fast Forward/Reverse	Press and hold TUNE ►► or TUNE ◀◀ to fast forward or reverse a track.
Pause	Press ►/   to temporarily stop CD playback. Press ►/   again to resume playback.
Intro	Press INT to access the Intro menu, then turn the volume knob to select one of the following: • OFF - Cancels the INT function. • ALL - Plays the first 10 seconds of each track.
Repeat	Press RPT to access the Repeat menu, then turn the volume knob to select one of the following: • ALL - Plays all tracks on CD. • TRACK - Continuously repeats selected track.
Random	Press RDM to access the Random menu, then turn the volume knob to select one of the following: • OFF - Cancels the RDM function. • ALL - Plays all tracks in random order.
CD-R/CD-RW Compatibility	Some CD-Rs and CD-RWs may be incompatible with this unit, depending on media type and recording method. Refer to the online owner's manual for details.

\* Not available on all models.

To download the complete Owner's Manual for your radio, please visit [www.dualav.com/support/manuals.php](http://www.dualav.com/support/manuals.php).

## General Operation

Power On/Off	Press the <b>U</b> button to turn the unit on. Press <b>U</b> again to turn unit off.
Faceplate Removal	Press <b>RELEASE</b> and pull away from the left side to remove. To re-install, insert right side of faceplate first then push left side to secure.
Changing Modes	Press <b>MODE</b> to select between AM/FM, CD player, auxiliary front/rear, USB and operation of iPod/iPhone. Modes of operation are shown in the display.
Volume	Adjust volume using volume knob.
Mute	Press <b>MUTE</b> to silence the audio. Press <b>MUTE</b> again to resume listening at the previously selected volume.
Auxiliary Inputs	Insert a 3.5mm cable in the unit's front AUX port, or RCA cables into the rear AUX-IN connectors.
Reset	Press the <b>RESET</b> button to reset the unit back to the factory settings if abnormal operation occurs. The reset button is located behind the front panel.
Setting the Clock	With the unit on, press and hold <b>DISP</b> until the clock begins to flash, then release. Press <b>TUNE ◀◀</b> to adjust the hours and <b>TUNE ►►</b> to adjust the minutes. Press <b>DISP</b> momentarily to save the selected time.
Display	Press <b>DISP</b> to toggle display between various displayed information.
Audio / Menu	Press and hold <b>AUDIO/MENU</b> for more than three seconds to access the setup menu. Press <b>AUDIO/MENU</b> momentarily to select between the menu functions and rotate the <b>volume knob</b> left/right to adjust or activate the desired function.

To download the complete Owner's Manual for your radio, please visit [www.dualav.com/support/manuals.php](http://www.dualav.com/support/manuals.php).

## AM/FM Tuner Operation

Seek Tuning	Press <b>TUNE ◀◀</b> or <b>TUNE ►►</b> for more than one second to seek to the next strong station.
Manual Tuning	Press <b>TUNE ◀◀</b> or <b>TUNE ►►</b> momentarily to move radio frequency up or down one step at a time. Press and hold to advance quickly.
Band	Press <b>BAND</b> to select between FM1, FM2, FM3, AM1 and AM2 bands. Up to six presets can be programmed for each band, enabling up to 18 FM stations and 12 AM stations to be stored in memory.
Storing Presets	Up to 18 FM and 12 AM stations can be stored. To store a station, select the desired band and station. Press and hold the desired preset button (1-6) for more than two seconds. When stored, the preset number will appear in the display.
Recalling Presets	Preset stations can be recalled any time by pressing the corresponding preset button.

To download the complete Owner's Manual for your radio, please visit [www.dualav.com/support/manuals.php](http://www.dualav.com/support/manuals.php).

## MP3 / WMA Operation \*

Playing MP3/WMA Files	To play MP3/WMA files, insert a data CD, SD card or USB device containing MP3/WMA files.
Track Select	Press <b>TUNE ►►</b> to skip to the beginning of the next song. Press <b>TUNE ◀◀</b> to return to the beginning of the current song. Pressing <b>TUNE ◀◀</b> again skips to the beginning of the previous song.
Fast Forward and Reverse	Press and hold <b>TUNE ►►</b> or <b>TUNE ◀◀</b> to fast forward or reverse a track.
Pause	Press <b>►/  </b> to temporarily stop playback. Press <b>►/  </b> again to resume playback.
Folder Access	Press <b>■</b> to select the next folder. Press <b>■</b> to select the previous folder. Folder access is only available on discs or devices with more than one folder.
Repeat	Press <b>RPT</b> to enter the Repeat menu, then turn the <b>volume knob</b> to select one of the following options: • ALL - Plays all tracks on disc or device. • TRACK - Continuously repeats selected track. • FOLDER - Continuously repeats all files in folder.
Random	Press <b>RDM</b> to enter the Random menu, then turn the <b>volume knob</b> to select one of the following options: • OFF - Cancels RDM function. • ALL - Plays all tracks in random order. • FOLDER - Plays all tracks in folder in random order.
Intro	Press <b>INT</b> to enter the Intro menu, then turn the <b>volume knob</b> to select one of the following options: • OFF - Cancels the INT function. • ALL - Plays first 10 seconds of each track. • FOLDER - Plays first 10 seconds of each track in the selected folder.

\* Not available on all models.

To download the complete Owner's Manual for your radio, please visit [www.dualav.com/support/manuals.php](http://www.dualav.com/support/manuals.php).

## Operation of iPod/iPhone\*

Connect an iPod/ iPhone Device (sold separately)	To play music from an iPod/iPhone device, connect the USB cable (included with your iPod/iPhone device) to the unit's USB port. Playback will begin automatically.
Song Select	Press <b>►►</b> to skip to the next song. Press <b>◀◀</b> to return to the beginning of the current song. Pressing <b>◀◀</b> again skips to the beginning of the previous song.
Forward/Reverse	Press and hold <b>►►</b> or <b>◀◀</b> to fast forward or reverse.
Pause	Press <b>►/  </b> to temporarily stop playback. Press <b>►/  </b> again to resume playback.
Repeat	Press <b>RPT</b> to enter the Repeat menu, then turn the <b>volume knob</b> to select one of the following options: • ALL - Repeats all tracks. • SONG - Continuously repeats selected track.
Random	Press <b>RDM</b> to enter the Random menu, then turn the <b>volume knob</b> to select one of the following options: • OFF - Cancels the RDM function. • ALL - Plays all tracks in random order. • ALBUM - Plays all tracks in album in random order.
Intro	Press <b>INT</b> to enter the Intro menu, then turn the <b>volume knob</b> to select one of the following options: • OFF - Cancels the INT function. • ON - Plays first 10 seconds of each track.
Music Search	Turn the <b>volume knob</b> to select between artists, albums, songs, playlists, podcasts and audiobooks. Press <b>SELECT</b> to select the desired search category. Most search categories have subcategories to navigate through.
Manual Control for iPod	When "MANUAL" control is selected from the Setup Menu, the iPod or iPhone device can be controlled directly from the device's interface. All functions except for volume can be used from the iPod or iPhone device.

\* Not available on all models.

To download the complete Owner's Manual for your radio, please visit [www.dualav.com/support/manuals.php](http://www.dualav.com/support/manuals.php).

## Pandora® Operation\*

Requirements	Control for Pandora requires: • An iPhone device with a reliable data connection, or an iPod touch that is connected to wireless internet. • The Pandora App installed on the iPhone/iPod device. • An active account with Pandora ( <a href="http://www.pandora.com">www.pandora.com</a> ). • The USB sync cable included with iPod/iPhone device.
USB Connection	Connect an iPod or iPhone device (required, sold separately) to the USB port, using the USB sync cable included with your iPhone device.
Changing Stations	Press <b>SELECT</b> to display the stations menu. Turn the <b>volume knob</b> to cycle through the list of stations, then press <b>SELECT</b> when the desired station is highlighted.
Shuffle	Note: Stations must be created on your account prior to connecting your iPod/iPhone device to the head unit.
Skip Track	Press <b>►►</b> to skip the current song.
Play/Pause	Press <b>►/  </b> to temporarily stop playback. Press <b>►/  </b> again to resume playback.
Thumbs Up	Press <b>▲</b> to customize the station to play more songs like the currently playing song.
Thumbs Down	Press <b>▼</b> to customize the station to play songs that are different from the currently playing song.
Device Compatibility	Refer to the Owner's Manual for a complete list of devices compatible with this head unit. Refer to <a href="http://www.pandora.com/everywhere/mobile">www.pandora.com/everywhere/mobile</a> for devices compatible with the Pandora mobile application.
Troubleshooting	Note: Pandora is an internet service, carrier and data charges may apply.

\* Not available on all models.

To download the complete Owner's Manual for your radio, please visit [www.dualav.com/support/manuals.php](http://www.dualav.com/support/manuals.php).

Pandora is only available in certain countries. Please visit <http://www.pandora.com/legal> for more information.

## Limited One-Year Warranty

This warranty gives you specific legal rights. You may also have other rights which vary from state to state. Dual Electronics Corp. warrants this product to the original purchaser to be free from defects in material and workmanship for a period of one year from the date of the original purchase. (Note that select marine products carry a 2-year warranty. Please visit [www.dualav.com](http://www.dualav.com) for details.) Dual Electronics Corp. agrees, at our option, during the warranty period, to repair any defect in material or workmanship or to furnish an equal new, renewed or comparable product (whichever is deemed necessary) in exchange without charges, subject to verification of the defect or malfunction and proof of the date of purchase. Subsequent replacement products are warranted for the balance of the original warranty period.

**Who is covered?** This warranty is extended to the original retail purchaser for products purchased and used in the U.S.A.

**What is covered?** This warranty covers all defects in material and workmanship in this product. The following are not covered: installation/removal costs, damage resulting