AIKO



How to set up AIKO

Wie richten Sie AIKO ein Come impostare AIKO Como configurar AIKO Как начать использовать AIKO Comment régler AIKO AIKO安装说明







Charge AIKO until red light tums green. | Laden Sie AIKO auf, bis die LED von rot auf grün wechselt. | Caricare AIKO fino a quando la luce rossa non diventa verde. | Cargar hasta que la luz roja se tome verde. | Зарядите АIКО до тех пор. пока красный сигнал не сменится на зеленый. | Charger AIKO jusqu'à се que le voyant rouge devienne vert. | 请先为AIKO乔起,直室红色的是即是不过多为经验。









Download the free AlKO app by searching for 'AlKO'. | Laden Sie die Kostenlose AlKO App herunter, indem Sie nach 'AlKO' suchen. | Scaricare l'app gratuita AlKO ricercandola come 'AlKO'. | Descargar gratis la aplicación AlKO para AlKO. | Загрузите бесплатное приложение AlKO. | Теlécharger l'application gratuite AlKO en recherchant 'AlKO'. | 请从应用市场搜索并下载AlKO程序 | 請從應用市场搜索並下藏AlKO程式



To connect with your AIKO





Location
To find your AIKC





Notification To remind you sth



Bluetooth | Location | Microphone | Camera Open the app. Enable Bluetooth, location access, microphone, and camera. | Bluetooth | Ortung | Mikrophone | Kamera Öffnen Sie die Арр. Aktivieren Sie Bluetooth, Ortung, Mikrofon und Kamera. | Bluetooth | Posizione | Microfono | Fotocamera Aprire l'app. Attivare Bluetooth, Posizione, Microfono e Fotocamera. | Bluetooth | Localización | Micrófono | Cámara Abrir la aplicación, activar Bluetooth, localización, micrófono, cámara. | Bluetooth | Location, Microphone | Camera Откройте приложение. Поставъте галочки на Bluetooth, Location, Microphone, Camera. | Bluetooth | Position | Microphone | Camera Ouvrir l'application, autoriser le Bluetooth, la position, le microphone et la caméra.





Activate AIKO by holding its button down for 5-6 seconds until a blinking red light appears. | Aktivieren Sie AIKO, indem Sie den Knopf 5-6 Sekunden gedrückt halten, bis ein rotes Licht blinkt. | Attivare AIKO premendo il pulsante per 5-6 secondi fino a quando la luce rossa non lampeggia. Activar AIKO presionando el botón 5-6 segundos hasta que la luz roja aparezca parpadeando. | Активируйте AIKO, нажав на кнопку и удерживая ее в течение 6 секунд до тех пор, пока красный сигнал не начнет мигать. | Activer AIKO en appuyant pendant 5 secondes jusqu'à l'apparition du voyant rouge clignotant. | 按下按键5-6秒倍,AIKO会被 激活,LED开始闪烁 | 按下按键5-6秒後,AIKO會被激活,LED用始昂续





Next, place AIKO near your mobile device. The AIKO app will search for your AIKO. | Platzieren Sie AIKO in der Nähe hres mobilen Gerätes. Die AIKO App wird nach Ihrem AIKO suchen. | Posizionare AIKO vicino al vostro dispositivo mobile. L'applicazione AIKO cercher il vostro AIKO. | Siguiente, sitiúa AIKO cerca det ut lelifono móvil. La aplicación AIKO buscará tu AIKO. | Разместите AIKO вблизи вашего мобильного устройства. Приложение найдег ваш AIKO. | Егике, рlacer AIKO à côté de votre mobile. L'application AIKO cherchera votre AIKO. | ijiřk AIKO 為近郊的子前, AIKO施用程序会搜索物的AIKO | išiřk AIKO 靠近郊的行動電話, AIKO應用程式會自動搜索您的AIKO AIKO







Attach your AIKO to the item you want to track. | Befestigen Sie Ihr AIKO an dem Gegenstand, den Sie tracken wollen. | Collegate il vostro AIKO all'oggetto di cui desiderate tenere traccia. | Adjunta tu AIKO al item que quieres rastrear | Прикрепите ваш АІКО к ключам (или другой вещи), местоположение которых вы хотите отслеживать. | Fixer votre AIKO sur l'objet que vous souhaitez tracer. | 持AIKO家到您想要追踪的物品上

How to Find Your Lost Rem Wie Sie Ihren verlorene Gegenstand finden Come trovare il vostro oggetto che avete perso Como encontrar el item perdido Как найти вашу потерянную вещь Comment trouver l'objet perdu 通过AICO提到是大好购品





Tap the 'Find' button. AIKO will begin to beep. Follow this sound to find your lost item. | Drücken Sie die 'Finden-Taste. AIKO wird Fileptöne aussenden. Folgen Sie dem Geräusch, um Ihren vermissten Gegenstand zu finden. | Date un colpetto al tasto 'Find/Trox'. AIKO comincerà a suonare. Seguirei Il suono per ritrovarei l'oggetto perso. | Clic sobre 'Find'. AIKO comenzará a pitar, sigue el sonido para localizar tu item perdicio. | Kлинчите имонну Find. AIKO начнет издавать звуковой силнал. Следуйте по направлению к сигналу, члобы найти потерянную вещь. | Cliquer sur le bouton 'Find'. AIKO сотменелета à bipper et suivez le son pour trouver 'lobjet perdu. | 点击Find'按钮, AIKO全按出提示音,只要缩音可以找到效应的标题。 | Supper et suivez le son pour trouver 'lobjet perdu. | 点击Find'按钮, AIKO全按出提示音,只要缩音可以找到效应的标题。 | 影響Find'按钮, AIKO會發出提示音,只要缩音響音能可以找到效应的标题。



Tap either the 'Stop' button on the app, or the button on AIKO to stop the alam. | Drücken Sie entweder die 'Stop'-Taste der App oder die Taste am AIKO, um den Alam zu stoppen. | Per arrestare l'allame dane un colpetto al pulsante 'Stop' sull'app o premere il pulsante sull'AIKO. | Clic sobre 'Stop' en la aplicación o sobre CAIKO para parar la alarma. | Чтобы выключить звуковой сигнал, кликните кнопку Stop в приложении или нажижете инолу на IKO. | Cliquer sur le bouton Stop' del 'application, ou sur la bouton sur l'AIKO pour arrêter l'alarma. | 点击Stop'按证或者争击AIKO的按键像可以停止提示音 | 點哪Stop'按键或按下AIKO的按键像可以停止提示音



ONE-YEAR LIMITED HARDWARE WARRANTY

nonda warrants that your nonda hardware product (the "Product") will be free from defects in materials and workmanship under normal use for a period of one (1) year from the date of delivery.

REMEDIES

If a hardware defect in the Product arises and a valid claim is reviewed within their Marranty Period, nord will all its lost option and subject in specialsel level; Other and Product with a new or refurbished components or (b) replace the Product with a new or refurbished component or (b) replace the Product with a recovery or refurbished product upon return of the defective Product with several resolution of the Product with a recovery does not apply to Product syot purchase from unauthorized resellers, or where the instructions for use and activation of the Product are not completed with where the Product is damaged as a result of abuse, accident, modification or other acuses beyond our reasonable corruct Any replacement product will be warranted for the emainder of the original warranty period or 30 calendar days, whichever is lance.

EXCLUSIONS AND LIMITATIONS

Decisions Profusion Relocation and Profusion In the original purchaser of Product that was purchased from an authorized retailer or sales channel Kon-authorized 3rd party receptls or order numbers are NDT accepted for warranty verification. Without limiting the foregoing, the Limited Warranty does not apply to any (a) nonda products and services other than the Product, LiP Product that is, or nonda reasonably believes to be, stolen (c) to damage caused by sectional abuse, misuse, flood, fire, earthquake or other external causes; (d) to damage caused by operating the Product outside he permitted or intended uses described by nonda or with improper voltage or power supply.

OBTAIN WARRANTY SERVICES

To obtain remedies under this Warranty, nonda must receive your claim before the need of the Warranty Petend You also must delive the Product, in either its order packaging or packaging providing an equal diegree of protection, to the addiess specified by nonda. Consumer shall be the too stof shipping the device to nonda. By sending the Device, consumer agrees to transfer ownership to nonda, nonda may not reterrunt the original device to consumer if the claim is justified based on this Worn, nonda shall bear the cost of shipping the repaired or replacement device to the Consumer.

HOW TO MAKE A WARRANTY CLAIM

Read through our warranty above; if you believe you are covered by the warranty please prepare following documents and send them to cs@nonda.us.

- A copy or screenshot of the original purchase invoice to verify your warranty
 Corder id. purchase date, website or store)
- A description of the problem with a photo illustrating the physical damage.
 Your shipping address including name, postal code and phone number.

If you need software support only, you may contact us with your app account and phone operation system. We would be glad to help.

Specification / Spécification / Specifikation / 产品規格 Especificação / Specificazione / Specificatie / 製品の仕様 / 규격

Model: NDAFWTREG Size: 35.8 x 39 x 7.0 mm

1.41 x 1.53 x 0.27 inch Weight: 9g / 0.31oz Battery Canacity: 30mAh Battery Type: Li—lon Charging Current: 0.1A Charging Voltage: 5V Charging Port: Micro USB

RISK OF EXPLOISON IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERYS ACCORDING TO THE INSTUCTIONS.

型号: NDAFWTREG

尺寸: 35.8 x 39 x 7.0 mm 1.41 x 1.53 x 0.27 inch 重量: 9g / 0.31oz 电池容量: 30mAh 电池类型: Li - Ion 充电电流: 0.1A 充电电压: 5V 充电端口: MicroUSB

モデル: NDAFWTREG サイズ: 35.8 x 39 x 7.0 mm 1.41 x 1.53 x 0.27 inch 重量: 9g / 0.31oz 電池の容量: 30mAh

電池の種類:Li-lon 充電電流:0.1A 充電電圧:5V 充電ポート:MicroUSB

NCC聯語:

根據交通部低功率電波輻射性電機管理維法規定: 第十二條



經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得擅自變更頻率、 加大功率或變更原設計之特性及功能。 第十四條

低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停 田、並改美至無干陽時方溫繼續停田、前语会注通信、均依雲信注根完作業之無線雲通信

低功率射頻電機須必受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。 NCC Statement: Administrative Regulations on Low Power Radio Wayne Radio that Designs warning

Article 12
Without permission granted by the NCC, any company, enterprise, or user is not allowed to change frequency, enhance transmitting power or alter original characteristic as well as performance to a appropriate low power radio-frequency devices.

Article 14
The low power radio-frequency devices shall not influence aircraft security and interfere legal communications; If found, the user shall cease operating immediately until no

The said legal communications means radio communications is operated in compliance with the Telecommunications &ct

The low power radio-frequency devices must be susceptible with the interference from legal communications or ISM radio wave radiated devices.

FCC Compliance Statement:

This equipment has been tested and found to comply with the limits for a Class Bigliald device, pussant top art 15 of the FCC Rules These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to crieret the interference to you or more of the following encouraged to try to crieret the interference to you or or more of the following

- Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - -Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.









Developed by nonda in California. Assembled in China. TM and © 2017 No NDA Inc. All rights reserved. No NDA Inc., 320 Mountain View Avenue, Mountain View, CA 94041