


2.4G Quadcopter 2.4G 四轴飞行器 INSTRUCTION MANUAL


使用说明书




1. STANDARD EQUIPMENT 标准配件



2. CONTROLLER DIAGRAM 遥控器功能说明




3. TRANSMITTER BATTERY INSTALLATION 遥控器电池安装



1

CHARGING BATTERIES 电池的充电



**Use ONLY the supplied USB cord for charging.
请使用原厂提供的USB充电线充电。


WARNING
Battery charging should be done under adult supervision at all time. 充电时需要有成年人的全程监护。
CAUTION

Charger Specifications 充电规格	
Input 输入	Charging Current 充电电流
5V	300~400 MAH
Charge Completion 充电完成	Charging 4.2 ± 0.03V

BATTERY AND CHARGER SPECIFICATION 电池与充电器相关规格

Battery usage and charge duration reference 电池使用时间与充电时间参考表				
Battery type 电池种类	ITEM NO.	Battery Specification 电池规格	Usage Duration 可使用时间	Charge Time 充电所需时间
Li-po battery 锂聚合电池		3.7V/400MAH	Helicopter flight time 飞行器飞行时间 约7分钟	Approx 7 Minutes (Charging current approx) 约60分钟
Carbon-Zinc (Non Rechargeable) 碳锌电池(不可充电)		1.5V (GP 15G R4P)	Transmitter Operation Time 供遥控器开机时间 用18小时	18 Hours Non Rechargeable 不可充电

BINDING OF RADIO TRANSMITTER AND RECEIVER 遥控器与接收器的对频




Step1 步骤1

Turn ON aircraft using switch on bottom side. Place the aircraft on a flat surface (do not move the aircraft during the binding process) to ensure the gyroscope is centered. 把电源头插入插座里面，将飞行器置于平坦位置，状态指示灯闪烁时不要再移动机身，让陀螺仪读取中点。

Step2 步骤2

Turn the controller power button to the ON position. The LED will flash. Wait 5 seconds and the bind has been established. Push the throttle stick from the lowest position to the highest position, and then back to the lowest position. When the flashing light turns solid, the bind is complete. 把油门摇杆从最低推到最高，然后回到最低位置，指示灯由慢速闪烁变为常亮，油门行程检测完成。

7. BINDING OF RADIO TRANSMITTER AND RECEIVER 遥控器操作说明



Step3 步骤3

After flying, turn the power switch on the transmitter to the OFF position(Power light will turn off) and also turn the power switch on the bottom side of the aircraft to the OFF position (Lights will turn off) indicating all systems are now powered OFF.


飞行结束，关掉遥控器电源，（指示灯熄灭）关掉飞行器上电源开关（指示灯熄灭），进入所有系统关闭电源状态。

Step4 步骤4

Turn off the transmitter. If the transmitter is not going to be used for an extended period of time, please remove the batteries and store properly. 关闭发射器电源，长时间不使用时请将遥控器电池取出并妥善保管。


WARNING
If transmitter is not to be used for a long duration, please remove the battery for storage. 长时间不使用时请将遥控器电池取出并妥善保管。
CAUTION
Warning: If the "A" batteries are left in the transmitter, potential leakage could occur which may damage the transmitter and possibly create a fire hazard. 电池未取下，将导致电池漏液而损坏遥控器，甚至造成起火燃烧的危险。

Operations 操作



2

8. Low-fast mode selection 高低速选择



3


changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.⁴⁾

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.⁴⁾

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:⁴⁾

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.⁴⁾

10. Optional 选配: Taking Photos&Videos/拍照摄像



Before you take photos or shoot camera, please confirm the SD Card is inside the right place./在你开始拍照摄像之前，请确认已插入内存卡。

When you want to take photos, please press the camera button. then you will get 1 photo.

When you want to take a video, please press the video button, then the camera start shooting. when you press the video button again, you will get a video.

想要摄像，就按下摄像键，摄像头就开始拍摄，再次按下摄像键，视频就拍摄完成了！

11. Optional 选配:(定高版本才具备此功能/Only for Auto-Hover Function)

One Key Take Off 一键起飞
When Code paired, press the One Key TakeOff, the drone will fly up and keep the height by itself.
对码完成后，按下一键起飞键，飞行器会起飞，并自动保持高度。

One Key Landing/一键着陆
Press the one key landing button, the drone will automatically landing slowly and the blade stop running, during the landing, you could trim right stick to make it landing in right place.
按下一键着陆键，飞行器会自动慢慢减速着陆直到螺旋桨停止，在降落过程中可以波动方向操纵杆，让飞行器降落到正确的位置！

One Key stop/一键停止
If the drone hit an obstacle, press One Key Stop running emergency
如果飞行器碰到人等障碍物，按下一键停止键，马上停止飞行运转。

4