

Brief Self-balanced scooter will bring you a new life experience, there will be a surprise waiting for you. Please carefully and completely read the user Introduction manual before using it.

### Content

	Introduction 01
	1. Self-balanced Scooter03
	2. Safe Driving Attention04
Charles 1	3. Product Parameters07
	4. Usage Common Sense08
	5. Usage and Control Information09
	6. Learning to Drive a Self-balanced Scooter12
	7. Maintenance 13
	8. Warranty 14

Box contains: Scooter, Charger, Manual, Warranty Card, Certificate of Quality.

0 www.gfivemobile.com

8. Warranty
Keep well the warranty card and purchase invoice as proofs for after-sales uses. For non-human damages and bugs, service provided in accordance with the following terms service provided in accordance with the following terms and consumables:

1 year varranty for the scotter excluding Patrians and consumables:
6-month warranty for battorics; the tyres belong to consumables thus with 1-month harrants.

- The fell-wing liens are not covered by the varranty.

  The fell-wing liens are not covered by the varranty.

  The construction caused by non-compliance to the Cuscr Manuals.

  The dimensional professional and non-compliance by users or upprobletable motions.

  The varianty card, involce, or innonicrimity of the vehicle, warranty card and invoces, after using, the damage of the appressional are not covered by the varranty.

  The varianty card damaged pleess out of the range specified in the instructions.

  The damage caused by long in the rain and soak in the nater.



# Protect Function

During operation, if any system errors or violation operations occur, the Ahool Will warn to stop in different ways, the indicator lights up and beeps, the wheel worlt shar in self-balanced mode. • well drived under a proper speed, if over-speed, the wheelvill up-warp to control the speed to

- - a nate range.
    when standing on the pads, the titing angle is over 10°, over-low battory voltago.

- the system steps into protection mode, the indicator light is long stay, and high frequency the board up-wraps to prevent operation during riding. The scooter snays back and forth over 30s.

- beeps during riding.

  The scooter All switch off automatically if the board tits over 35°.

  The scooter All switch off in Ze automatically if the tyres locked-rotor.

  The scooter All switch off in Ze automatically if the tyres locked-rotor.

  The scooter All switch off in 15s if the hattery is lower than the protection level

  The long-time howeyload discharging (cg. Climbing albing and stoop slope in the long time),

  the scooter will switch off in 15s.

## 7. Maintenance

7.1 Storage.

Do no store the device in wet condition, charge the battery at least once a month to protect the battery activity it is not used for along time.

7.2 Change bytes.
Power off the scooter beanging tyres, use a scrowdriver to take off the belts, open the shell be careful with the connection lines in the shell.

### Attention

- After the maintenance, instantignition might occur when connecting the power terminals, this is a normal phonomonon, do not be paid.

  Hease comply with all he fems in the <User Manuals, and if anything beyond control occur, turn to Gfive after sales sorvice.

www.gfivemobile.com

73

# Indication Icon



Note: it may be the damage to your device or other equipment.



Tips : notes, usage tips , or additional information.

# G'FIVE

1.Self-balanced Scooler
Soft-balanced varieties is a new high-toch outdoor sport product, which usos acrospace attitude control theory, fuzzy algorithms and givescope system, to achieve self-balancing forward and backward directions. Through filling the body slightly forward and backward, to achieve progressy acceleration, deceleration, praking balance and other traffic operations, list and right direction are similar to the bio,de, realizing the balance by twisting the body. Self-balanced vehicle is a groon, orwironmental and carry-on dovec, is a good higher for recreation.

## Save Space

With its unique appearance design, it is available to take and move at any time, and save space.

### Save Time

The max speed is 10-15i in among models, and it can be continuously running for 10-25 miles when full, chargod.



www.gfivemobile.com

# 6. Learn to Drive a Balance Wheel


attention to the relevant safety issues, and fully understand all presautions of < User Manual> mentioned prior before


Step 1: Start the vehicle, press the switch button.
Step 2: Start the vehicle, press the switch button.
Step 2: Cet ready for driving, stand onto the pad with one of the feet, the sensor will consequently work, the indicator turns green, and the system will see a blance condition, then stand onto the pad with the other foot to operate.
Stop 3: (scop the balance with we standing on, by to move by slightly thing your body forward and backward.
Step 4: Control the left and right interition of the winell.
Stop 5: Got off, stop and balance the whool bofore gotting off, one foot got off first, then the other foot got off quickly.

# Weight on back of left foot to turn right









Attention:
If the wheelis not in horizontality when step, onto the pads. The alarm buzzer will beep and the indicator light will turn red, the system then fall in keeping its belence, then the not allowed to operate.



# 5.4 Max Drive Distance

ho max rango is rebovant with many factors, such as: Iand type: driving on smooth, flat ground will increase the range, contrartly, it will reduce the travel distance.

- body weight; driver's weight can affect the travel distance.
- embent temperature, store and drive the balance car under recommended temperature vill increase the driving distance, contrarily, extreme temperature vill reduce the distance, maintenance, reasonable battery charging and maintenance vill increase the distance, the
- opposite will reduce the distance, speed will increase the distance, oppositely, frequent start, stop, accelerate will reduce the distance.

# 5.5 Limited Speed

- the maximum speed is 10–15km/h among models. The alarm buzzer will warn when over-speed driving occurs, well drived under a proper speed, if over-speed, the wheelvill up-varp to control the speed to well drived under a proper speed, if over-speed, the wheelvill up-varp to control the speed to
  - a cafe range.

### 5.6 Charge

insert the charger into the wheel first, then into an AC power socket, or the charger will not work, this might avoid potential risks, ensure the charging safety.

\_ www.gfivemobile.com

# 2. Self Driving Attention:

This socition highlights some safety knowledge and varning statements, allowing you to have good knowledge of the safety precautions before using the hadness society. Hears be sure to read the kuser manuals and compty with the relevant safety instructions. Please note wall the kuser manuals have formed and allowed an analysis of safety pre-eautions, to improve the balance are fining to safety and pleasure.



### Attention:

Under whatever droumstances, you are likely to be in the loss of control, collision, fall or cause injury during using a balanco car. To avoid injury, you must carefully road the usor manual for instructions to drive the balance car. Make sure that the product is in good condition, and carefully read all product related materials provided during the use of this product.

- When you are leading to drive the halance can, be sure to do security measures, such as wearing a helmet, knee pads, elbow test and other protective gear.
  Below test and other processive gear.
  Salance can is just for personal entertainment, it's prohibiled to use for public transportation.
  Do not drive after drinking or valing drugs.



- When driving, make sure the feet are always on the mat.
- Please wear suitable sports dothing when using the balance car so as to better deal with the
- cincogency situations. The behaves are accessed in the behave of a crean only load one person. Users and from behavior should not exceed the maximum loading weight indicated in the specification, otherwise it, would be easier to fall or be injured, or even damage the ear's balance specification, otherwise it, would be easier to fall or be injured, or even damage the ear's balance. systom. In addition, the driver's weight should also not be less than the minimum loading weight indicated in the specification, or it will cause the driver fail in handling the balance, especially in
  - Must control well the vehicle speed to ensure the safety of oneself and persons around, make the downhill situation, the speed can not be safely reduced or stopped.
    - oure the balance car is ready to stop and run at any time. When traffic accident oncurs while driving, please hay where you are and wait for related
- When you drive the car with others drivers, please keep a certain distance from each other to departments come to handle.
  - avoid collisions.
  - Remember that when driving, your body situate at the height of 10 centimeters higher to the ground, ensure the security of the head while going though the door gate.

05 www.gfivemobile.com

# 5.2 Pedal Sensor

- four sensors under the pads, when stops on the pads, the balance wheel will be adjusted into the balance mode automatically.
- make sure feet are on the mats, do not stand on other parts of the platform. do not put other things on the pade, or the wheel will not be switched off, thus may cause damage to humans and

- 5.3 Display Panel
- The display panel is in the middle part of the wheel, for displaying operating information.

  power display area; greenlight means full charge; \$60%, electricity left when green furns yellow; \$20%, electricity left when yellow furns red then you need to charge it soon.

  perform turns red then you need to charge it soon.

  poperating indicator; the indicator will light up when the foot switch is triggered; and if any errors occur, the indicator will turn red.



# **G'FIVE**

# 5. Use and Control

5.1 Turn ON/OFF Button

ON" button: Long press the button for 2S, power on. (the power will automatically, turn off in 10 mintures if no operations,

"OFF" button: Long press the button for 2S, power off.

### Notes:

- do not ride with carrying other things.

  complywith local traffic laws, be couchedus to pedestrians during riding,
  be carcted with your front; and rafe recopa good field of vilow will do good to the safe-driving,
  refax your feet, while driving, hent knees Slighily to maintain a halance on unaven ground.

60 www.gfivemobile.com

Pay attendents the balance and body center of gravity while steering, avoid falling down due to centre-of-gravity shift or fast speed.

Do not be distracted while driving, such as enswering the phone, listening to music or engage in any other activities. Isaning apperpriated formation absoluted and inspection of the property backwards driving, asserting are not allowed. Bus designed adming, over speed driving are not allowed. The balance cardoos not become the hoedite are objectived more more than the property of the balance cardoos not become the hoedite are objectived more morans of dosign, tost or any related proofs, thus,

users must drive the balance car without any external help.
Do not drive under drift light, dark places or any natrowy blaces.
Do not drive on the alippery road or cread with obstacles, such as enow road, lice road, wet and emonth floor.
Do not drive on the road full of odds and ends, such as tree branches, trashles, or smell stones etc.

Please use the balance car under proper Aorking condition, if any environments need to get permission to use, please obtain the consent.

Avoid driving on stoop slopes. Do not drive under certain unsafe places with flammakle gases, vapors, liquids, dust, liber and other factors which might cause fire hazard or explosion incidents.

During driving, you may encounter many unanticipated and unexpected dangers, so any time requires careful driving. If not comply with the usor's manual, resulting in personal injury accidents, the company does not assume any responsibilities.



# 3. Product Parameters

Item	Specification Model	GS61	6989
Size	Motor Size	19	6.5"
	Max. Gradient	15°C	್ಲಿ
	Range Loading	50-100kg	Okg
	Batten, Power&Capacity	158W&Sams	158W&Samsung4100mAh
Function	Charger Voltage	DC42	DC42V 2AH
	Charging Time	06	90min
	Working Temperautre	-50	-20°0-60°0
	Max. Speed	10km/h	10km/h
	Oruise Distance	10-20km	10-20km
	Package Size	660*250*250(mm)	(www)982*8286(mw)
	Net Weight	10kg	10.8kg
Apprearance	Pedal Distance	110mm	m
	Chassis Clearance	30mm	
	Color	Black/3rown/White/Blue	Black/White/Dark Purple
Protect Measure	Limit Speed Protection	Starts on speed of over max, beeps and up-ward prevent speeding.	is and up-ward prevent speeding.
000000000000000000000000000000000000000	Standard	charging cable/adaptor/user manual/warranty card	er manual/warranty card
cessones	Optional	B Γ audio/lighting/rem	B Γ audio/lighting/remote control/handbag

07





4. Usage Common Sense The main functions shown below:





4

Bedals
 Chassis cover
 Tire protective cover
 Switch / charging port







VE INTERNET (HK) LIMITED

iss: Grive Shangxue Technology Industrial Zo BanTian, Londgang, Shenzhen, China

| Ban Han, Longgang, Shenzhe| | Tel: (0086)-755-83685375 | Fax: (0086)-755-33828666-8769

Fax: (0086)-755-33828666-8769 www.gfivemobile.com

### FCC warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio Frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.