
### Listening for a Response



Release the **Talk** button to receive incoming transmissions Your microTALK® radio is always in Standby mode while the Talk or Call buttons are not pressed


### To Adjust Volume



Down button. A double been sound is used to indicate the minimum and maximum volume levels

(1 through 8).

### **Call Button**



The other person will hear a three second call tone. This tone is used only to establish voice communications.



See page 10 on how to select between

### LED/S.O.S. Flashlight



Press the LED flashlight button below the TALK button to use the LED flashlight located at the bottom of the radio

To activate S.O.S. function, press and hold the LED flashlight button to turn on. Press and release to turn off the flashlight or S.O.S. function.

### Auto Squelch/Maximum Range


Your microTALK® radio will automatically shut off weak transmissions and unwanted noise due to terrain, conditions or if you've reached your Maximum Range limit.



### Making Life Easier and Safer

Staying in touch with your family and friends is convenient and easy when using your microTALK® radio. Some of the many uses you will discover include:

Communicating with others while hiking, biking, and working; keeping track of family and friends at a crowded public event; checking with travel companions in another car; talking with neighbors; arranging meeting spots with others while shopping at the mall.



**Lock Function** 

microTALK® Range

Secure your microTALK® radio while on the go. Carrying your microTALK® radio with you is easy

when using the belt clip or optional wrist strap. The belt clip easily attaches to your belt, purse, or



### Customer Assistance

### **Product Service & Support**

For any questions about operating this new Cobra branded product PLEASE CONTACT US FIRST... do not return this product to the retail store. The contact information for support will vary depending on the country in which you purchased and utilize the product.

To obtain warranty service or other information for products purchased from Altis itself or through its authorized reseller or agent and utilized in the U.S.A.. please call our consumer support line at (866) 721-3805 or email us at support@altistec.com. You will receive instructions on how to ship the products at your expense to an Altis Global Limited Authorized Service Center To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase: (b) a written description of the problem: and, most importantly: (c) your address and telephone number.

For warranty and customer service information outside the US, please contact

The Lock function locks the Channel Up, Channel

buttons to prevent accidental operation

or off request. When in Lock mode,

- Press and hold the Call/Lock button for

Down, Volume Up. Volume Down and Mode/Power

A double beep sound is used to confirm your lock on

For further information needed on its features, please visit www.cohrawalkietalkie.com for frequently asked questions and the electronic manual

To turn the lock on or off:

two seconds.

the **Lock** icon will be displayed.

Your range will vary depending on terrain and conditions

Maximum Range In flat, open country your radio will

operate at maximum range

reduce the range of the radio.

Buildings and foliage in the path of the

Dense foliage and hilly terrain will further

automatically switches to low power, which

will limit the range the radio can communicate.

signal can reduce the range of the radio

On Channels 8 through 14, your radio

©2018 Altis Global Limite

### 1. Memory/Escape Button Tri-Watch Button

External Speaker Microphone/ USB Charge Jack Mode/Power Button

Volume Up/Down Buttons

**Mode Functions** 

Scrolling Through the Mode Function

By scrolling through the Mode function, you will be able to

scrolling through the **Mode** function, your radio features

will be displayed in the same predetermined order

select or turn **on** preferred features of your microTALK® radio. When

Set CTCSS Privacy Codes

Set DCS Privacy Codes

Set Hi-Mid-Low Powe

Set Vox On/Off

Set Vox Sensitivity

Set Call Tones 1-10

Set VibrAlert On/Off

Set Roger Beep On/Of

Set Key Tones On/Off

Your microTALK® radio incorporates two advanced coded squelch

systems that can help to reduce interference from other users

on any given channel. CTCSS (Continuous Tone Coded Squelch

provides 83 privacy codes. This provides a total of 121 Privacy

cannot be used on the same channel at the same time.

System) provides 38 privacy codes and DCS (Digitally Coded Squelch)

Codes. Either system can be used on all channels, but both systems

To successfully communicate using a privacy code, both the sending and receiving radios must be tuned to the same

The privacy code 00 is not a privacy code, but allows all signals to be heard on a change! It is

the CTCSS and DCS systems

hannel and to the same privacy code system (CTCSS or DCS)

and privacy code number. Each channel will remember the last privacy code system and number you select.

signals to be heard on a channel that is set to 00 on both

Set Rewind-Sav-Again On/Off

Call/Lock Button

Backlit LCD Display

Speaker/Microphon

LED Light Button

10. Talk Button

ン/ мо**р**∈ (<sup>R</sup>

**Privacy Codes** 

Introduction

(11)

(10)

9

20

1 Antenna

**Product Features** 

S

MEM TRI SCAN CO

88:::

**\$**Cobra

- 14. Rewind-Sav-Again® Button Wrist Strap Connection
- 16. Belt Clip
- 17 Battery Compartment 18. Battery Door Screws (2)

(15)

**16**)

**(17)** 

(5)

**(3**)

 $\cdot (7)$ 

(19)

18

- 19. Rubberized Grips 20. LED Flashlight
- 21. Weather Button

### Backlit LCD Display

2341

(11)

Rog )) Vox

A BURP Power Saver

**16 (5) (17** 

### Features

- 22 Channe
- 10 Channel Weather Radio
- Weather Alert
- 121 Privacy Codes (38 CTCSS codes/ 83 DCS codes)
- Hands-Free Operation
- VihrAlert® Silent Paging
- Rewind-Sav-Again<sup>6</sup>
- Tri-Watch

Call Alert

Button Lock

Charge Jack

Selectable On/Off

Keystroke Tones

Roger Beep

Speaker/Microphon

- Scan Channels, privacy codes
- Backlit LCD Display
- Roger Beep Icon • I FD Flashlight
  - 3 VOX Icon 4. Weather Icor

(15)

(12)

- Lock Icon Ten selectable tones
  - 6. Hi/Med/Low Power Icon 7. DCS/CTCSS Icons
    - 8 Scan/Memory Icon 9. Weather Alert Icon

. Battery Level Indicator

- 10. DCS/CTCSS Privacy Code Numbers
- 11. Power Saver Icon 12. Channel Numbers
- Battery/Power Saver 13 Receive/Transmit Icon
  - 14. Memory Channel Number

16. Kev Tone Icon

- 15 VibrAlert® / Call Alert Icon Battery Level Indicato
- Low Battery Audible Alert 17 BURP Icon

**Set CTCSS Privacy Codes** 

- Auto Squelch 18 Rewind-Say-Again® Icon 19. Signal Strength Meter
- Belt Clin

/ MOD€ (¹)

A-2

To select a CTCSS privacy code:

the Mode/Power button until the CTCSS icon

appears and the small numbers next to the

If DCS is turned on at the channel

selected, the display will flash the

CTCSS icon and "OFF." To switch from

DCS to CTCSS, press the Channel Up

will then be able to proceed to step 2.

or Channel Down button while the display

is flashing "OFF." The display will then

show the small numbers flashing and you

channel number flash on the display.

1. After selecting a channel, press

2. Press using the Channel Up or Channel Down button to select a

3. When your desired CTCSS privacy code is displayed, press the

privacy code. You can hold the **Up** or **Down** button for fast advance.

Mode/Power button to enter the new setting and proceed to other

functions, or press the Talk button to return to Standby mode.

# This radio floats with included NiMH batteries.

vour Cobra microTALK® radio.

t may not float with some other AA batteries.

Cobra recommends your radio is turned off while being charged.

• Non-rechargeable alkaline batteries can also be used in your radio.

ton of the radio

A-3

• It normally takes about 15 hours to fully charge batteries.

Caring for Your microTALK® Radio

Avoid exposure to extreme temperatures

Installing Batteries

Tip of Belt Clip

(o⇒

To install or replace batteries:

Your microTALK® radio will give you years of trouble-free service

sliding clip up.

if cared for properly. Handle the radio gently. Keep the radio away from dust.

Remove Belt Clip

1. Remove belt clip by releasing belt clip latch and

2. Loosen the two top and bottom screws on the

compartment cover HINT: the screws should be

loose enough (and sticking up) that you could use

them to help pull off the battery door if needed.

batteries or non-rechargeable alkaline batteries

4. Replace battery compartment cover, screw down

Position batteries according to polarity markings.

Tighten the screws using the tip of the helt clip to

overtighten. Only use the tip of the belt clip to

secure the battery door to the radio. Do not

• Do not attempt to charge alkaline batteries.

• Do not mix alkaline, standard (carbon-zinc), or

rechargeable (Ni-Cd, Ni-MH, etc.) batteries.

1. Check to see that the batteries are inserted properly

**3.** Plug the charging cable into a power source.

2. Insert the cable into the charge jack located at the

. Do not mix old and new batteries.


To charge batteries in radio:

• Use only the supplied rechargeable batteries and charger for recharging


back of the radio to remove the battery

3. Insert the supplied three AA rechargeable


the screws and re-attach the belt clip.



### To select a DCS privacy code:







- 2. Press using the Channel Up or Channel Down button to select a DCS privacy code. You can hold the **Up** or **Down** button for fast advance.
- 3. When DCS privacy code is displayed, press the Mode/Power button to enter the new setting and proceed to other functions, or press the Talk button to return to Standby mode.

### Set High/Medium/Low (H-M-L) Power Button

Your radio can transmit selectively at 0.5, 1, or 2 watts of power. Use the low power setting for short-range communications and use the high power setting for long-range communications.





Hi/Med/Lo Icon

HI MED LO

Mode/Power To toggle between H-M-L Power Modes:

1. Press the Mode/Power button until HI MED LO icon appears.





Channel 8 through 14 only operates on **Low** power setting.

For charging microTALK radio(s) in desktop charger:

2. Insert the micro-USB cable into jack on back of charger.

Note: Charger should be installed near the equipment

3. Plug the charging cable into a power source. For

pluggable equipment, the socket-outlet shall be

installed near the equipment and shall be easily

1. Insert radio(s) into desktop charger as shown.

and easily accessible

If charging light is not **on**, check position of radio. Radio should be

upright. The charge indicator light will stay **on** until the charging is

1. Press and hold the Mode/Power button to turn on your radio.

2. Press the Channel Up or Channel Down button to select

Both radios must be tuned to the same

channel/privacy code to communicate

Mode/Power Press and hold the Mode/Power button until you hear

Mode/Power buttons are pressed.

In **VOX** mode, your microTALK® radio can be used "hands-free," automatically

transmitting when you speak. You can set the VOX sensitivity level to fit the

volume of your voice and avoid transmissions triggered by background noise.

button to turn VOX On or Off

setting is displayed.

To set VOX sensitivity

1. Press the Mode/Power button until the VOX

2. Press the Channel Up or Channel Down

3. When VOX is turned on or off, press the

button to return to Standby mode.

least sensitive level.

button to change the setting

2 Press the Channel IIn or Channel Down

button to return to Standby mode

3. When VOX sensitivity is selected, press the

Mode/Power button to enter the new setting

and proceed to other functions, or press the Talk

Mode/Power button to enter the new setting

1. Press the Mode/Power button until the VOX icon

The current VOX sensitivity level is

flashes and the current sensitivity level is displayed

displayed with letters "L" and a Number 1

through 5, with Number 5 being the most

sensitive level and Number 1 being the

and proceed to other functions, or press the Talk

icon flashes on the display. The current **On** or **Off** 

a series of audible tones indicating the radio is on.

ready to receive transmissions. The radio is always in

Your microTALK® radio is now in **Standby** mode.

Standby mode except when the Talk. Call or

3. Press and hold the Talk button while

4. When finished talking, release the Talk

speaking into the microphone

Turning on Your microTALK® Radio

Voice Activated Transmit (VOX)

Mode/Power To turn VOX mode on or off:

button and listen for a response

### **Using Your Radio**


Quick Start


/MODE (¹)

Offi

Channel Button

**\**\\/





### **Auto Battery Save**


**Battery Low** 



Battery Save Mode


If there are no transmissions within 10 seconds, the radio will automatically switch to Battery Save mode Power Saver and the Power Saver icon will flash in the display. This will not affect the radio's ability to receive incoming transmissions.

### Communicating with Another Person



2. With the microphone about two inches (5 cm) from your mouth, speak in a normal voice.

3. Release the Talk button when you are finished talking and listen for a response You cannot receive incoming calls while pressing the Talk button



same channel to communicate.

### To Select a Channel



pressing the Channel Up or Channel Down button. Both radios must be tuned to the same channel to communicate.





See page 19 for frequency allocations.

# **Ten Call Tone Settings**

You can choose between ten different Call Tone Settings to transmit

# //wode ()/ Call Tone Setting

### To change a call tone setting: 1 Press the Mode/Power button several times until

# the letter "C" and the current call tone number (01 through 10) is displayed. The current call tone will

sound for three seconds 2. Press the Channel Up or Channel Down button to

hear the other call tone settings. . Choose one of the following:

a. Press the Mode/Power button to enter the new setting and proceed to other functions.

> b. Press Talk or Call/Lock button to return to Standby mode c. Do not press any buttons for 12 seconds to

## return to Standby mode.

Your MicroTALK® radio can alert you to incoming signals by sounding an audible call tone or an audible tone with VibrAlert®.



### To change call settings


1. Press the Mode button several times until the Call **Setting** icon flashes on the display. The current setting ("01" vibrate + ring, "02" ring only) is

2. Press the Channel Up or Channel Down button to

change the call setting.

c. Do not press any buttons for 12 seconds to return to Standby mode.

VibrAlert® and Call Alert



3. Choose one of the following: a. Press the **Mode** button to enter the new setting

and proceed to other functions. b. Press Talk or Call/Lock button to return to

Standby mode.

Mode Functions (continued on back side)



# Mode Functions (continued)

### **Roger Beep Confirmation Tone**


Your listener will hear an audible tone when you release the Talk button. This alerts the other party that you have finished talking and it is OK for them to speak



### To turn roger beep on or off:

### 1. Press the Mode/Power button several times until the Roger Beep icon flashes. The current on or off setting is displayed.

- Roger Beep On 2. Press the Channel Up or Channel Down button to select roger beep on or off.
  - 3. Choose one of the following:



### Standby mode. c. Do not press any buttons for 12 seconds to enter the new setting and return to Standby

# **Key Tone On/Off**

When **Key Tone** is **On** an audible tone will sound each time a button is



### To turn key tone on or off:

- 1. Current key tone status On/Off will flash.
- 2. Press the **Channel Up** or **Channel Down** button to select key tone on or off
- Choose one of the following a. Press the Mode/Power button to enter the Standby mode
- b. Press Talk or Call/Lock button to return to Standby mode.
- c. Do not press any buttons for 12 seconds to enter the new setting and return to Standby mode


### Rewind-Say-Again<sup>6</sup>


### Rewind On/Off


If **Rewind** is enabled, the last 20 seconds of incoming audio is recorded and you can play back calls by pressing the **Rewind** button.



### To set the Rewind mode ON or OFF:







### Example 1:



### When music or conversation creates too much noise to hear an inbound message clearly, press the REWIND button to hear the message a second time.

### Channel Button Example 2:

When listening to an urgent message with confusing background noise, press the REWIND button to hear the message a second time. To erase the recorded audio, hold down the **REWIND** button while turning on the radio, 2 confirmation beens will be heard indicating that the recorded audio has been erased.




12


### **10 Memory Location**

Your microTALK® radio has 10 Memory Locations for storing your most frequently used channels and channel/privacy code combinations. These **Memory Locations** can be selected individually or can be scanned.



### MEM/ESC Button To program a memory location:







If a location has been programmed before, its associated channel/privacy code will be shown on the display




- Press the MEM/ESC button to enter a new memory location or edit an already programmed memory location
- 1. Press the Channel Up or Channel Down button to select the memory location.
- 5. Press the MEM/ESC button. The channel numbers will flash on the display.



to select a channel (1 through 22). 7. Press the MEM/ESC button. The CTCSS icon and



3. Choose one of the following:



b. Press the MEM/ESC button to switch from CTCSS to DCS. The DCS icon and privacy code numbers will flash on the display. The Channel Up or Channel Down button can then be used to select a DCS privacy code (00 through 83) for the channel

13

If "OF" flashes in place of the privacy code numbers, a privacy code is already set in the opposite (CTCSS or DCS) system. Press the **Channel Up** or **Channel Down** button to cancel the opposite code and select a privacy code from the active system for the selected channel.

### 9. Choose one of the following:

- a. Press the MEM/ESC button to enter the channel/privacy code in the selected memory location. Radio then proceeds to next memory location, which will blink
- b. Press and hold the MEM/ESC button to save the current state of the Set Memory Function and press the **MEM/ESC** button again return to Standby mode.


### To recall a stored memory channel location:




7月月十

ISEDC WARNING

and the memory location number flash on the 2. Press the Channel Up or Channel Down button to







**MEM/ESC** button to begin.


### Tri-Watch Set-up

Your microTALK® radio can be set up to scan three of your favorite channels for activity




. Press and hold the TRI-WATCH button from Standby mode for two (2) seconds to activate Tri-Watch Setup mode. The TW icon on the display will turn ON.












- 4. Repeat steps 2 and 3 to program the remaining additional Tri-Watch memory channel.
- 5. After programming both Tri-Watch memory channels the radio will immediately engage Tri-Watch mode.

### Using Tri-Watch: . From Standby mode, press the TRI-WATCH

# button. The **TW** will appear in the display along with













- 4. Press Channel Up or Channel Down button to resume scanning the Tri-Watch channels or to change the scan direction
- 5. To EXIT the Tri-Watch scan, press the TRI-WATCH button again, and the radio will return to Standby mode.


15

**BURP** features allows the user to expel water from inside the speaker grille. This is useful if the radio is dropped in the water which may become trapped in the speaker grille and muffle the audio.

### To activate BURP








# 4. After an 8-second interval, the radio will return to

### Channel Scan

Your microTALK® radio can automatically scan channels.



### . Press and release the Scan button until the Scan icon and the channel numbers appear

2. Press and hold the Scan button to begin scanning





The radio ignores specific privacy codes while scanning channels. The Scan icon will continue to be displayed when

scan is **on** Your radio will continue to scan all channels and stop if an incoming transmission is detected. Your radio will remain on that channel for 6 seconds

### During scanning (while receiving an incoming transmission), you can choose from the following:

a. Press and hold the Talk button to communicate on that channel. Your radio will remain on that channel and return to **Standby** mode

BY THE PRODUCT OR BY THE PRODUCT TO PERFORM, INCLUDING ANY LOST PROFITS,

LOST SAVINGS, INCIDENTAL DAMAGES, OR CONSEQUENTIAL DAMAGES. ALTIS IS NOT

LIARLE FOR ANY CLAIM MADE BY A THIRD PARTY OR MADE BY YOU FOR A THIRD PARTY

THIS LIMITATION APPLIES WHETHER DAMAGES ARE SOLIGHT, OR A CLAIM MADE, LINDER

THIS WARRANTY OR AS A TORT CLAIM (INCLUDING NEGLIGENCE OR STRICT PRODUCT

LIABILITY), A CONTRACT CLAIM, OR ANY OTHER CLAIM. THIS LIMITATION CANNOT BE

- **b.** Press the **Channel Up** or **Channel Down** button to resume scanning channels.
- c. Press and hold the Scan button to return to Standby.

16

### \*National Oceanographic and Atmospheric Administration

be displayed when All Hazards Radio is on.

EVEN IF ALTIS OR AN AUTHORIZED REPRESENTATIVE OF ALTIS HAS BEEN ADVISED BY YOU OF THE POSSIBILITY OF ANY SUCH DAMAGES. Some states and countries do not allow limitations on how long an implied warranty last and do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights, and

WAIVED OR AMENDED BY ANY PERSON. THIS LIMITATION OF LIABILITY WILL BE FEFECTIVE

you may also have other rights which vary from state to state and country to country Provided that the product was purchased from Altis itself or through its authorized reselled or agent and utilized in the U.S.A., Altis will, without charge, repair or replace, at its option defective products, products or component parts upon delivery to the authorized Altis Global Limited Authorized Service Center, accompanied by proof of the date of first customer purchase, such as a duplicated copy of a sales receip

You must pay any initial shipping charges required to ship the product for warranty service but the return charges, to an address in the LLS A, will be at Altis' expense, if the product is

### For Products Purchased Outside the U.S.A.

Cobra®, microTalk®, Nothing Comes Close to a Cobra®, and the snake design are registere trademarks of Cobra Electronics Corporation, USA, Cobra Electronics Corporation™ is a trademark of Cobra Electronics Corporation, USA, All other product or service names are the property of their respective owners.

# Warranty & Trademark Acknowledgment

**Limited One-Year Warranty** Altis Global Limited warrants to the original consumer purchaser only that this product and the component parts thereof, will be free from defects in workmanshin and materials for a period of one year from the date of first consumer purchase. During this period. Altis will. repair or replace, at its sole option and discretion, this product or any defective parts. Altis liability hereunder shall be limited to repair or replacement of the defective part or parts, and such correction shall constitute a fulfillment of all of Altis' warranties hereunder

This limited warranty is only valid for the original consumer purchaser in limited jurisdictions and is not transferrable. This limited warranty will automatically terminate prior to expiration if this product is sold or otherwise transferred to another party. The product must be purchased from Altis or an authorized dealer or the warranty is void. This limited warranty is valid only for products purchased and utilized in specific jurisdictions. Please visit our website at www.cobrawalkietalkie.com for a list of jurisdictions wherein this limited warranty is valid.

This limited warranty does not cover damage due to misuse, abuse, negligence, acts of God accident, commercial use or modification of, or to any part of this product. This warranty does not cover damage due to improper operation, maintenance or installation; ordinary wear and tear: or attempted alterations or repairs by anyone other than Altis or someone authorized by Altis to do warranty work. Any unauthorized alterations or repairs will void this warranty. This limited warranty does not cover product sold AS IS or WITH ALL FAULTS. This limited warranty is invalid if the factory applied serial number or date stamp has been altered, defaced or removed from this product. This limited warranty does not cover product purchased or utilized in a jurisdiction not covered.

The procedure for obtaining service and support, and the applicability of this warranty, will vary depending on the country or jurisdiction in which you purchase and utilize the product For details on obtaining product service, support and other warranty information please visit www.cobrawalkietalkie.com

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state and country to country EXCEPT AS EXPRESSIVEST FORTH IN THIS WARRANTY ALTIS MAKES NO OTHER

WARRANTIES EXPRESSED OR IMPLIED INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. ALTIS EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO THE TERMS OF THIS EXPRESSED WARRANTY

LIMITATION OF REMEDIES AND DAMAGES. REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. ALTIS SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES. INCLUDING BUT NOT LIMITED. TO ATTORNEYS' FEES AND/OR COSTS OF LITIGATION, FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. ALTIS IS NOT LIABLE FOR ANY DAMAGES CAUSED

# Please contact your authorized local reseller or agent for warranty information. Trademark Acknowledgement

# Weather (WX) Alert Mode

alert to Weather and other emergency alerts broadcast by NOAA.



Channels selection in the previous menu.

(Weather) radio mode.


Off setting is displayed.

## To turn Weather Alert On or Off:

2. Press the **Weather** button again and the Weather

3. Press the Channel Up and Channel Down button to turn Weather Alert On or Off.

This feature is set to **OFF** by default.



4. Press the Weather button again to save the new

# Press the Weather button to enter the All Hazards

Alert icon flashes on the display. The current **On** or

Turning On the Weather Alert function will allow your radio to automatically receive NOAA weather signals and warnings from designated weather broadcast stations. If the radio is turned ON, it will



sing the NOAA All Hazards Radio

setting.

### Operation

# **General Specifications**

Frequency Allocation A = Channel No. for 22 Channel Models B = Frequency in MHz

C = Power Output

19

21

20

22

| Α  | В        | С    |
|----|----------|------|
| 1  | 462.5625 | High |
| 2  | 462.5875 | High |
| 3  | 462.6125 | High |
| 4  | 462.6375 | High |
| 5  | 462.6625 | High |
| 6  | 462.6875 | High |
| 7  | 462.7125 | High |
| 8  | 467.5625 | Low  |
| 9  | 467.5875 | Low  |
| 10 | 467.6125 | Low  |
| 11 | 467.6375 | Low  |
| 12 | 467.6625 | Low  |
| 13 | 467.6875 | Low  |
| 14 | 467.7125 | Low  |
| 15 | 462.5500 | High |
| 16 | 462.5750 | High |
| 17 | 462.6000 | High |
| 18 | 462 6250 | High |

462,6500

462.6750

462,7000

462.7250

Hiah

High

High

High

### IMPORTANT NOTICE:

responsible for compliance could void the user's authority to operate the equipment. two conditions: 1) This device may not cause harmful interference, and 2) this device

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

However, there is no guarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or television reception, which

 Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the

Safety Information for microTALK Radios Your wireless handheld portable transceiver contains a low power transmitter. When the talk button is pushed, it sends out radio frequency (RF) signals. The device is authorized to operate at a duty factor not to exceed 50%. In August 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels

FCC RF Exposure Requirements: For body-worn operation, this radio has been tested

Normal Position

for handheld wireless devices

and meets the FCC RF exposure guidelines when used with Cobra accessories supplied or designated for this product. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. Use only the supplied antenna. Unauthorized antennas, modifications or attachments could damage the transmitter and may violate FCC regulations

WARNING: Any changes or modifications to this unit not expressly approved by the party This device complies with part 15 of the FCC Rules. Operation is subject to the following must accept any interference received including interference that may cause undesired

equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures. · Reorient or relocate the receiving antenna.

receiver is connected • Consult the dealer or an experienced radio/TV technician for help.

Hold the transmitter approximately 25 mm from your face and speak in a normal voice, with the

### MODEL ACXT1035R FLT:

wing two conditions: 1) This device may not cause harmful interference, that may cause undesired operation.

### Under ISEDC regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by ISEDC. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication The applicant is responsible for providing proper instructions to the user of the radio device, and any usage restrictions, including limits of exposure durations. The user manual shall provide installation and operation instructions, as well as any special usage conditions, to ensure compliance with SAR and/or RF field strength limits. For instance, compliance distance shall be clearly stated in the user

14

Cet appareil est conforme aux normes RSS exemptes de licence ISEDC. Son fonctionr soumis aux deux conditions suivantes: (1) cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris les interférences pouvant entraîner un fonctionnement indésirable de l'appareil. En vertu des réglementations ISEDC, cet émetteur radio ne peut fonctionner qu'avec une antenne d'un type et un gain maximal (ou inférieur) approuvé pour l'émetteur par l'ISEDC. Pour réduire les interférences radio potentielles avec d'autres utilisateurs, le type d'antenne et son gain doivent être choisis de manière à ce que la puissance isotrope rayonnée équivalente (e.i.r.p.) ne soit pas supérieure à celle nécessaire à une

communication réussie. Le demandeur est responsable de fournir des instructions appropriées à l'utilisateur du dispositif radio et de toute restriction d'utilisation, y compris les limites de la durée d'exposition. Le manuel de l'utilisateur doit fournir des instructions d'installation et d'utilisation, ainsi que des conditions d'utilisation spéciales, pour assurer la conformité avec les limites de champ de SAR et / ou RF. Par exemple, la distance de conformité doit être clairement indiquée dans le manuel d'utilisation.

his device complies with ISEDC license-exempt RSS standard(s). Operation is subject to the

any interference, including interference that may cause undesired operation of the device.

following two conditions: (1) this device may not cause interference, and (2) this device must accept

Exigences de la ECC/ISEDC concernant l'exposition aux champs électro-magnétiques RE (radiofréquences Engenices de la rOchico Contentant i Appositioni aux inalins electron-inagitaques in (acutivity) references en En ce qui concerne le fonctionnement de l'appareil porté sur le corps de l'utilisateur, les tests effectués ont permis de vérifier que cet émetteur-récepteur satisfait aux directives FCC/ISEDC limitant l'exposition aux champs électro-magnétiques RF lorsqu'il est utilisé avec les accessoires Cobra fournis ou conçus pour ce produit; 'utilisation d'autres accessoires peut ne pas garantir le respect des critères des directives ECC/ISEDC limitant 'exposition aux champs electro-magnétiques RF. Utiliser l'appareil uniquement avec l'antenne fournie. L'emploi d'une antenne non homologuée ou modifiée, ou d'accessoires non autorisés, pourrait faire subir

des dommages à l'appareil, et peut violer les prescriptions de la réglementation FCC/ISEDC.

Position normale: Tenir l'émetteur à environ 25 mm de la bouche et parler normalement, l'antenne étant éloignée et


### This device complies with part 15 of the FCC Rules. Operation is subject to the

and 2) this device must accept any interference received, including interference FCC Warnings: Replacement or substitution of transistors, regular diodes or

other parts of a unique nature, with parts other than those recommended by Cobra may cause a violation of the technical regulations of part 95 of the FCC rules, or violation of type acceptance requirements of part 2 of the rules.

# Scan Button To scan privacy codes:


Privacy Code Scan



Your microTAI K® radio can automatically scan the Privacy Codes (either

CTCSS 01 through 38 or DCS 01 through 83) within one channel. Only

one set of privacy codes (CTCSS or DCS) can be scanned at a time.









### **NOAA\* All Hazards Radio Channels** You can use your microTALK® radio to listen to NOAA All Hazards Radio

channels transmitting in your area.

To listen to All Hazards Radio channels: 1. Press the Weather button until the All Hazards Radio icon and the currently selected All Hazards Radio channel are displayed



4. To exit All Hazards Radio, press the TALK button.

Manufactured, distributed, or sold by Altis Global Limited, official licensee for this product. ©Cobra Electronics Corporation, USA 2018. All rights reserved.