# 8.5"H x 11"W

### **FRONT**

# - Examine the unit periodically I/o make sure item is in good working condition. - Finsure play area if here from hazards. - DO NOT leave Children unstended at any time. - Do keep sawy from fire. - Do keep sawy from fire. - Do keep sawy from fire. - Do real allow appear to use this product who is under 3 years of age. - Avoid direct impact with obstacles. - DisCARD PACKAGING AND REMOVE ALL ACCESSORIES BEFORE GIVING THE VEHICLE AND TRANSMITTER TO A CHILD. A DETECT AND THE ADMINISTRATION OF THE ADMIN

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


ATTENTION: PLEASE DO NOT RETURN TO STORE.

**₩**Ø@(€

& other countries:
Used under license by
Better Sourcing Worlds



## **BACK**



# **QUICK START**

### DRIVING THE RC VEHICLE

- Place the RC vehicle on the floor.
   To assure your RC vehicle will pick up the correct frequency, <u>first slide to the "ON" position located under vehicle.</u>

NOTE: When finished playing, turn OFF the RC vehicle



### IMPORTANT NOTE:

In the event of a malfunction, reset the item by removing and replacing the batteries. If function is still not restored, replace the batteries with fresh alkaline batteries.