This manual contains important safety precautions and information of correct use.
Please be sure to read this manual carefully before use so as to avoid any accidents.

Do not place the product in hot, wet or dusty environment, especially in summer, do not leave the product inside a car with all windows closed.
Avoid dropping, impacting or shaking the product violently, otherwise it may cause damages or malfunctions. Select a proper volume to avoid ear problem when using earphones.
Do not cross the road or drive vehicles, using headphones to avoid traffic accidents.
Be sure to use the provided chargers and accessories in the package.
Be sure to charge the product when the following situations take place,
- The battery icon shows lower or empty.
- System automatically shut down and it turns off soon after restart.
- Operation keys do not respond properly.
- The device shows on the top right corner.

specification

Hardware

10.1”High Definition IPS LCD Touch Screen(1280x800 pixe)
Capacitive multi-touch (10 touch) point function
CPU: ROCKCHIP 3128T
RAM : 1G (3D accelerator possible for 3D games)
Wi-Fi (IEEE802.11 b/g/n) for internet connection
USB host for OTG function
G-sensor
Micro SD card slot recognizing up to 32GB
Built-in speaker & Built-in MIC
5V DC power adapter
Compatible with Bluetooth devices
keyboard ,mouse,Earphone

Software

Andriod 4.2.2 ICS
Google browser
Wi-Fi connection
e-Book function (all e-book formats supported by application)
1080p HD file playback
VoIP phone function with Wi-Fi connection
Possible to view/edit MS office files by application
Video: AVI, RM/ RMVB, FLV, MPG4 – 1, MPEG – 2 etc.
Audio: MP3, WMA, AAC, WAV etc.
Photo: JPEG, BMP, GIF, PNG, TIFF

1. Power On/Off

Long press power button to turn on/off the device. It may take a minute to boot the device.
Short press power button to turn on/off the screen.(Standby mode. Refer to 3. below)

2. Desktop

After turning on the device, desktop displays with shortcut icons and arrow panel at the right side

3. Standby mode(Screen off mode) / Unlock the screen

Short press the power button to turn on/off the screen (standby mode on/off).
After standby mode o , slide the lock icon in order to unlock the screen.

4. System settings

On the desktop, press menu button and select system settings.

Press System Settings

1.Wireless & networks and compatible bluetooth





Wi-Fi – Press Wi-Fi to turn on/off Set up each setting as you like. Wi-Fi settings - Press Wi-Fi settings, then the device
will automatically search the available Wi-Fi signals. Select the network you want to connect with.

2.Data usage

Slide mobile data switch to select open or close the flow usage.

3.More...

For more information on mobile data and Bluetooth options, Flight mode, Bluetooth sharing, support information

4. Sound


Settings
WIRELESS & NETWORKS
Wi-Fi
OFF
Bluetooth
OFF
Data usage
More...
DEVICE
Sound
Display
Hdmi
ScreenshotSetting
Storage
Battery
Apps
PERSONAL
Sound
Volumes
SYSTEM
Default notification sound
Pixie Dust
Touch sounds
Screen lock sound
Vibrate on touch

5. Display



Set up each setting as you like.

6. Storage

Check device memory and microSD card status.
Unmount SD card – Unmount the SD card for safe removal.

7. Battery

Check battery usage status.

8. Apps

Manage downloaded or running applications.

Downloaded
All installed application are listing.

9. Account & sync

Create your account. After connecting Wi-Fi network, the e-mailing system synchronizes your account with the device. Emails are automatically downloaded into the device.



10. Location access

Google’s location service - Let apps use data from sources such as WiFi and mobile networks to determine your approximate location



11. Security

Screen lock – Protect your device from unauthorized use by creating a personal screen unlock pattern. Make passwords visible – Show password as you type.
Unknown sources - If you want to allow installation of non-Market
Applications, Press Unknown sources and presses OK.



nstall from SD card – Install encrypted certi cates from SD card.

12. Language & input

Language – Choose your preferable language.
Keyboard & input method – Change keyboard & keyboard settings.
On Language & input settings, if you need other languages besides English on keyboard, press the relevant keyboard and enter the chosen Keyboard settings, select Keyboards, press the language you need.



13. Backup &Reset



14. Date&time

Set date & time and format



15. Accessibility

Set the voice services and systems the gesture operation etc.



16. Developer options

Set options for application development



17. About tablet

See status, legal information, ETC



How to connect/disconnect the device with/from the computer

On main desktop, connect the device with the PC,
touch right side of the status bar on the bottom of desktop

Press “USB connected”, select “Turn on USB storage”. The device is recognized at Explorer of the computer. Now you can use it as an external storage.



After finishing your work,
Press “Turn on USB storage”to unmount it.

How to install Applications(.apk file) into the device

Method 1.

1. Connect the device with internet. See above [1.Wireless & networks] in order to connect internet.
2. Run “Getjar” and search the applications you want to install.
3. Follow the instruction on the screen for installation.

Method 2.

1. With your computer, search application file(.apk) that you want to install into the device.
2. Download the file(.apk) into your computer.
3. Connect the device with your computer.
   See above [How to connect/disconnect the device with/from the computer.]
4. Copy and paste .apk file into the device and disconnect it from your computer.
5. Run “File browser” and nd .apk le that was copied into the device.
6. Press the file to install and follow the instruction on the screen.

Note

You may only download adult applications if you are at least 18 years of age, or at least the age of majority in the jurisdiction where you reside or from which you download adult applications. If you do not meet these requirements, then you do not have permission to download adult applications.

In case of any problems including legal issues from the breach by end-user’s own decision, the manufacturer shall not be responsible.

How to make desktop icons

Press the middle of the desktop ICONS, the pop-up displays.

Shortcuts
Long press your desired APK icon and put it on the desktop.



Widgets
Press Widgets and press your desired icon to put it on the desktop.

Wallpaper
Long press the desktop, press Wallpapers and select one of categories of wallpaper.
Select one you desire and press Set wallpaper.

Specification

OS

		Android 4.2.2 ICS
CPU		ROCKCHIP 3128T
SDRAM		DDR 1G (3D accelerator possible for 4D games)
Display		10.1" IPS 1280*800 Capacitive touch panel
Multi-touch screen		Yes : 10 point multi-touch
Built-in flash memory		16GB
IO PORTS	Audio port	3.5ø earphones
	USB port	1 x 5pin micro USB port (support USB host and OTG)
	DC port	5V, 2A
	HDMI port	
	Micro SD	Micro SD card
	OTG port	Same with USB port
	Button	Power, VOL-, VOL+, reset,
Speaker		1W
G-sensor		Yes
Bluetooth		Yes
Camera		0.3M pixel (front)+5.0M pixel(back)
Wi-Fi		802.11b/g/n
Power		Adaptor 5V 2A
Battery		3.7V Li-Polymer
Dimension		11*171*261mm

Charging time by charger approx. 4~8hours

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by International Center for Numerical Methods in Engineering (CIMNE) may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

SAR Statement

This Tablet meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: KPAU02 (FCC ID: 2AHS8-KPAU02) has also been tested against this SAR limit. SAR information on this and other pad can be viewed on-line at http://www.fcc.gov/oet/ea/fccid/. Please use the device FCC ID number for search. This device was tested for typical operations with handset Tablet 0mm from the body. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.