# (Fold Inward) — — — **▶**

(Back Cover)

(Front Cover)

#### Compliance Information

FCC Information
This device complies with Part 15 of the FCC Rules.
Caution: Any changes or modifications not expressly approved could void the user's authority to operate the

equipment.

Mote: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: of the following measures:

Reorient or relocate the receiving antenna.

- I learning to include the decoving alterning.

  Increase the separation between the equipment and receiver.

  Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.


  Consult the dealer or an experienced radio(TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

#### Rating Label Definitions



This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.





Bluetooth

This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Southern Telecom is under license.

### Warranty Information

This product as supplied and distributed new by Southern Telecom, Inc. to the original consumer purchaser is warranted by Southern Telecom against defects in material and workmanship for a period of one year from your date of purchase ("Warranty"). In the unlikely event that this product is defective, or does not perform properly, you may within one yea from your original date of purchase return it to the authorized service center for repair or exchange.

Obtaining Warranty Service
To obtain warranty service on your Polaroid product go to our website, SouthernTelecom.com, and click on Product
Support Select Polaroid, then click on Service Request to get started.

IN NO EVENT WILL SOUTHERN TELECOM, ITS MANUFACTURERS, DISTRIBUTORS OR PLR IP HOLDINGS, LLC BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) RELATED TO THIS PRODUCT EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY.



# ART+SOUND

# **ART+SOUND**

Printed in China v1. 07-2019

Instruction Manual

Bluetooth speaker AR4189

## Before You Begin...

## **READ CAREFULLY AND SAVETHIS MANUAL FOR FUTURE REFERENCE**

## Customer Support

For any questions or problems with your product, please visit our website at SouthernTelecom.com and click on Product Support.



To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with
- Do not disassemble, modify, or repair the device.
- Do not submerge in water.


such as liquids, metallic powders, etc.

- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Low power may cause poor Bluetooth® connection or sound distortion. • Do not allow the USB ports, power jack or other inputs of the device to be exposed to dust, or water, or come into contact with any conductive materials

#### In the Box

- AR4189 Wireless Speaker (x1)
- USB Charging Cable (x1)
- Instruction Manual (x1)

## Location of Controls



## Charging the Speaker

Attach the small connector of the supplied micro-USB cable to the USB charging port on the side of the speaker. Attach the large connector to the USB port on a computer, a USB charging device, or a **5V USB adapter** (not included) and plug into an electrical outlet.

**Getting Started** 

The LED indicator will turn RED while charging and turn off when fully charged. When low on power, a tone will be heard, indicating that the speaker should be

When finished charging, press the protective seal back into place.

#### Powering ON/OFF

- Press and hold the [ ] button to power the speaker ON.
   When powered ON, the speaker will automatically reconnect to the Bluetooth
- device it was most recently paired to, so long as that device is within connection range (30 ft.) and Bluetooth is enabled.
- $\bullet$  Press and hold the [  $\mbox{\em \emph{0}}$  ] button to power the speaker OFF.

#### Playing Music

To listen to music on your speaker, make sure it is paired to a Bluetooth-enabled device. For more on pairing the speaker to your device, please consult the

Once paired, you can control media playback and volume adjustment with the controls on your paired device or the controls on the speaker.

- 1. Power the speaker ON. A tone will be heard and the LED indicator will quickly
- 2. Set your mobile device to search for Bluetooth devices. When it appears, select AR4189 from the list of found devices.
- 3. Once successfully paired, a tone will be heard and the LED indicator will turn solid

## Adjusting Playback & Volume

- Press the [▷■] button to pause/resume playback. The LED indicator will **slowly** flash BLUE during playback.
- Press the [I≼3] and [□>1] buttons to skip tracks.
- Press and hold the [◄☐] and [☒☐] buttons to adjust volume.

#### Phone Calls

- Press the [ \$\gamma 1 button to answer an incoming phone call.
- Press the [ 🤊 ] button again to end the phone call.