User Manual AR1006

18 Adjusting Volume and Playback

• Adjust volume by pressing and holding let [+++] and [+++] buttons on the speaker, pressing the [++] and [+++] buttons on the speaker and [-++] buttons on the speaker similar consistent of the speaker similar consistent of the speaker similar consistent of the speaker similar consistent similar sim

Skip tracks in AUX mode using the controls on your device.

Press the [**] button on the speaker or the [**] button on the remote control to pause and resume playback in Bluetooth mode. Use the controls on your device to pause and resume playback in AUX mode.

The speaker must be switched ON in order to use the remote control.

• [6] Button: Enter or leave standby mode



ART+SOUND

Compliance Information

FCC Information
This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate

The experience of the control of the

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable excourse condition without restriction.

Rating Label Definitions

Direct current symbol.

This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect neural resources, however, the product health and the enviscoment.

Bluetooth This symbol signifies that this is a wirefess device powered by Nuetooth' technology. The Nuetooth' word mark and legos are negistered trademarks owned by Shatooth SK, Inc.

Warranty Information

Your product will be repaired or repticed, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a riskin with

ART+SOUND

previously-paired coveries.

- Move the [Power] switch to the OFF position to power OFF.

- While the speaker is powered ON, you can enter and leave standby mode by pressing the [] button on the remote control.

To listen to music on the speaker, you must be paired to a Bluetooth-enabled device (see the **Bluetooth Pairing** section) or connected with a 3.5 mm cable (see the **Using** with a **Wired Device** section).

Printed in China Designed in USA

ART+SOUND

Bluetooth speaker



Instruction Manual AR1006

Before You Begin...

A CAUTION

READ CAREFULLY AND KEEP THIS MANUAL

·THIS IS NOT A TOY, Please keep away from children and pets . TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY

. WARNING: To reduce the risk of fire or electric shock do not expose this apparatus to

 - WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain, moisture_driping, or splashing
 - Button cell inside the remote control, please keep kids safe from swallowing.
 - Button cell inside the remote control, please keep kids safe from swallowing.
 - Keep away from water and extreme temperatures.
 - Do not open this product or attempt to repair the unit yourself should it not be working.
 - Do not open the unit to extreme temperatures fleat or cold,i. open flames, humid
 - Do not expose the unit to extreme temperatures fleat or cold,i. open flames, humid conditions, or wet conditions.

Do not submerge in water.

☐ Questions & Customer Support
For questions, troubleshooting or any other assistance, please visit our website at
SouthernTelecom.com and click on Product Support.


The Box

AR1006 - Wireless Speaker (x1) 5V/1.5A Power Adapter (x1)

· Wooden Base (x1)

 Screws (x2) Remote Control (x1) Instruction Manual (x1)

[Mode] Button: Press: Switch Mode (··/·) M **①**



Location of Controls

Installing the Base


I. Remove the speaker and contents from its packaging.
Carefully turn the speaker upside down and place the wooden base on the underside, aligning the screw holes on the base with the screw holes on the pseaker.
Screw the base to the speaker with the screws.

CAUTION
The speaker should be placed ONLY on a level, sturdy floor.
Do NOT place on a table or other piece of furniture.

If using the FM radio, it is recommended that the speaker is placed near a window or area with an open view of the sky for best antenna reception.

For more on using the FM radio, please read the **FM Radio** section of this instruction manual.

* Powering the Speaker
Plug the small connector of the included power adapter into the DC 5V Power Port on
the back of the speaker. Plug the other end into an electrical outlet.



Getting Started

O Powering ON/OFF Move the [Power] switch to the ON position. A tone will be heard, and the speaker will enter Bluetooth pairing mode. The speaker will automatically re-pair to any nearby, previously-paired device.

When properly installed, the non-slip feet on the underside of the wood base should be touching the floor.

* Bluetooth Pairing
1. Power the speaker ON. A tone will be heard, and the LED indicator will quickly flash BLUE.
Set your device to search for Bluetooth devices. When it appears, select AR1006 from the list of found devices.

After a successful pairing, a tone will be heard and the LED indicator will slowly flash BLUE.

In Rhietonth mode, playback and volume adjustment in bluetourn mode, playback and volume adjustment can be controlled with the buttons on the speaker, the buttons on the remote control, or the controls on your paired device.



LED Indicator

Quickly Flashing BLU Slowly Flashing BLUE Speaker is paired Solid BLUE
 Using FM Radi


Press the [►4/-] and [►4/+] buttons on the speaker or the [►4] and [►4] buttons on the remote control to skip through scanned stations.

NOTE: The FM radio will have best reception where there is a clear line of sight to the sky.

✓ Using with a Wired Device

Plug one connector of a 3.5 mm auxiliary input cable (not included) into the 3.5 mm input port on the side of the speaker. Plug the other connector into your device. The speaker will automatically switch to aux mode, and the LED indicator will *turn solid BLUE*.

In aux mode, playback will be controlled by your paired device, and volume can be controlled with the buttons on the speaker, the remote control or your paired device.



Tusing the FM Radio

Switch input modes until you hear sound. The LED indicator will **turn solid BLUE**. This is FM Radio mode.

Press the [▶■] button on the speaker or remote control to scan stations. While scanning, the LED indicator will *quickly flash BLUE*. Press the [▶■] button again to stop scanning.