

FRIDAY

A large red sans-serif font word "FRIDAY" is positioned on the left. To its right is a red circle containing a white, stylized number "6".

fridaylabs.net



fridaylabs



fridaylabs

Quick Guide

1

Download the Friday app from the App Store or Google Play, then open the app.

2

Click 'Setup Product'  and follow the instructions.

Installation Tips



If you have any issues pairing the lock with the app, simply restart the process by reinserting the battery. This will set the lock into Search Mode for 5 minutes.

In the app, select the 'Settings' icon  and then 'Add Product' - your phone will begin searching for the lock.

Moving the lock to another door will require another install and setup.

Friday app layout

Name of Location

The screenshot shows the Friday app interface. At the top, there's a header with signal strength, battery level (22%), and a clock showing 4:21 PM. Below the header, the location name is "Thomas home" with a note "Latest activity Kevin 12:15 PM". To the right of the location name is a red arrow pointing to a circular icon with a clock symbol, labeled "History" and "Last Activity in this Location". On the left side, there are three main sections: "Settings" (with a gear icon), "Location" (with a location pin icon), and "Navigation" (with a map icon). In the center, there's a list of locks: "Frontdoor" (red lock icon), "Backdoor" (green lock icon), and "Garagedoor" (red lock icon). To the right of the locks is a red arrow pointing to the green lock icon, labeled "Locks". At the bottom, there's a section for "Users" with two tabs: "Owners" (showing Markus Kjelsson and Thomas Andersen) and "Guests" (showing Kevin Ball and Line Iversholt). To the right of the "Owners" tab is a red arrow pointing to a green "+" icon with the text "Add Users".

Settings

Location

Navigation

Users

Frontdoor

Backdoor

Garagedoor

Thomas home

Latest activity Kevin 12:15 PM

History

Last Activity in this Location

Locks

Add Users

Owners

Guests

Kevin Ball

Line Iversholt

Inside the lock

Tailpiece Adapter



Mounting Holes



Credit Card Release



LED Pairing Indication
Blinks while in pairing mode

Reset Button

Hold for 3 seconds until LED turns on for 10 seconds.

Battery Charger



Charge the battery fully (from factory, it will be charged a maximum of 30%)



- ➊ 0 - 25% Charged
- ➋ ➋ 25 - 50% Charged
- ➌ ➌ ➌ 50 - 75% Charged
- ➍ ➍ ➍ ➍ 75 - 99% Charged
- ➎ ➎ ➎ ➎ Fully charged
- ➏ ➏ ➏ ➏ Reverse the battery!
- ➐ ➐ ➐ ➐ Remove battery, Hot!

Plug the charger into any USB outlet.
Insert the battery into the charger cradle,
noting the + and - indicators.

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED BY
AN INCORRECT TYPE. DISPOSE OF USED
BATTERIES ACCORDING TO THE INSTRUCTIONS.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

IC Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF exposure warning:

The equipment complies with RF exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Avertissement d'exposition RF:

L'équipement est conforme aux limites d'exposition aux RF établies pour un environnement incontrôlé.

Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps. L'antenne (s) utilisée pour ce transmetteur ne doit pas être co-localisées ou fonctionner en conjonction avec toute autre antenne ou transmetteur.

Your Warranty

1. This Friday Smart Lock ("Device") is covered by a two-year warranty ("Warranty") from the date of purchase ("Warranty Period"), on the terms set out below.
2. By installing and/or using the Device, you are agreeing to be bound by the terms of this Warranty. If you do not agree to the terms of this Warranty, our returns policy entitles you to a refund upon receipt of the unused (in its original condition and packaging) Device within 30 days of the date of purchase (or the return period stipulated by the place of purchase, whichever is longer).
3. The Device must have been purchased through our authorised distribution channels.
4. A proof of purchase shall be required when submitting any claim under this Warranty.
5. This Warranty only covers defects in or to the Device.
6. During the Warranty Period, we undertake to rectify any and all defects in the Device attributable to faulty workmanship, materials and function (or at our discretion, replace the Device or provide a full refund) provided that the installation, use and maintenance instructions are followed in full and provided that the **Exclusions** set out below do not apply.
7. Where there is a defect in your Device that may come within this Warranty, please contact the place where you purchased the Device supplying them with your proof of purchase and relevant contact details together with a description of the defect. Your place of purchase will provide these details to us and an assessment will be made. There may be a requirement for the Device to be returned to us for a detailed assessment.
8. Following an assessment, if we determine that the Device is defective and none of the Exclusions set out below are applicable, we, at our discretion, shall either repair or replace the defective Device or refund the price of the defective Device.
9. We do not accept liability for your costs of dismantling, installation or carriage. Parts that we have replaced become our property.
10. **Exclusions** - this Warranty does not cover damage caused to the Device through:
 - Normal wear and tear
 - Improper installation
 - Negligent care and maintenance
 - Deliberate or accidental damage
 - Continued use following notification of a defect to your distributor or to us
 - Improper initial and subsequent operation
 - Alterations or modifications to the Device made by, or authorised by, the customer
 - External causes such as fire, water, salts, alkaline solutions or acid, power outages, internet problems
 - Unauthorised repairs or repairs carried out by unapproved persons
 - Removing the product number or making the Device unidentifiable
11. When a Device is repaired under this Warranty, the remaining time left on this Warranty will still be valid, but not extended. On a replacement product, you will receive a new warranty for the replacement Device and this Warranty will become void.
12. This Warranty is non-transferable and applies to Devices purchased in the United Kingdom only.
13. This Warranty does not affect your statutory rights.
14. This Warranty (and any disputes arising from it) is governed by the law of England and Wales.



TAILPIECE

8mm - - - 5/16"

Contact

Feel free to contact us whenever you need to!

See if your question is answered at:

www.fridaylabs.net/support

Or email us directly at:

support@fridaylabs.net