Side



Quick Installation Guide





POS Terminal



WARNING:

- Do not disassemble the terminal, battery or AC adapter. Only qualified technicians may sercive the device.
- Do not use batteries, AC adaptors or terminals near water.

Top

V 1.0

58mm Thermal Printer

MSR Reader

LED Indicator

IC Card Reader

Capacitive Touch Screen




Bottom



4

Settings

Federal Communications Commission (FCC) Statement



Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- . Increase the separation between the equipment and receiver.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by EP Intelligent Technology Co., Ltd may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's

RF exposure statement:

The transmitter must not be colocated or operated in conjunction with any other antenna or transmitter. This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

3. Click setting button to set options.

2. See setting option in this menu.

WiFi

Power on

POWER ACCESS

1. Click this button""

Connect the power adapter to the power jack, and the other end to the 220V mains socket.

POS POWER ON

Press the "Power Switch" button to start the terminal.

Bluetooth **Environment**

2. Click" "to open Bluetooth.

1. Click" "to open wifi.



Operating Humidity: 20~85%, no condensation

Storage Temperature: -20~60°C (-4° to 140°F)

Operating Temperature:

0~40°C (+32° to 104°F)

Storage Humidity: 10~90%, no condensation +86(0)755 2663 5376

