



















the product out of reach from children. The bags themselves or the many small parts they contain may cause choking if ingested.

- Don't disassemble the product yourself or insert any type of object into it, as this may cause
- a circuit failure that can lead to a fire. None of the components can be replaced or repaired by users. Only authorized dealers or service centers may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, contact your dealer or service centers.
- · Avoid exposing your product to rain or other liquids.
- ${\boldsymbol \cdot}$ Keep all products, cords, and cables away from operating machinery.
- Observe all signs and instructions that require an electrical device or RF radio product to be switched off in designated areas such as hospitals or aircrafts.
- · If the product overheats, has been dropped or damaged or has been dropped in a liquid,

Remember: Always drive safely, avoid distractions and follow local laws!

The use of a speaker while operating a motor vehicle may be regulated by local laws!

Using a headset while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions, just as use of this headset with both ears covered while driv-ing is not permitted in certain jurisdictions. Check with your local authorities.

BUILT-IN BATTERY CARE: Please observe the following if the product contains a battery

Your product is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles.

- The battery can be charged and discharged hundreds of times, but will eventually wear out. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime.
- · If left unused, a fully charged battery will lose its charge over time Leaving the product in hot or cold places will reduce the capacity and lifetime of the battery Always try to keep the battery between 15°C and 25°C(50°F and 77°F). A product with a hot or cold battery may not work temporarily, even when the battery is fully charged.

- "Caution"-the battery used in this product may present a risk of fire or chemical burn if mistreated. Batteries may explode if damaged.
- Only recharge your battery with the provided approved chargers designated for this product.
- · Dispose of batteries according to local regulations. Please recycle when possible.
- Dispose on batteries according to local regularious. Prease recycle when possible.
 Do not dispose as household waste or in a fire as they may explode.
 Unless otherwise specified in the user manual or quick start guide the battery in your product can not be removed or replaced by the user. Any attempt to do so is risky and may result in damage of the product.

Important: Please refer to the user manual for a description of the charging status indicator lights. Some products cannot be used while charging.

Charger warning! \bullet Do not use a wall charger with more than 5V and 2A output.

- When you disconnect the power cord or any enhancement, grasp and pull the plug, not the cord. Never use a charger that is damaged.

- Do not attempt to disassemble the charger as it may expose you to dangerous electric shock. MAINTENANCE
- Unplug the product or charger before cleaning.
- Clean the product by wiping with a dry or slightly damp cloth. The cord and charger may only be dry-dusted.

Any Changes expressly or modifications not approved by the party responsible for compliance could void the user's authority to operate the equipment

This device complies with part 15 of the FCC Rules. Operation is subject to the following two

(1) This device may not cause harmful interference, and (2) this device must accept any interference

received, including interference that may cause undesired operatio Note: This equipment has been tested and found to comply with the limits for a Class B digital

pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of • This package contains small parts that may be hazardous to children. Always store

-Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver.

- —Connect the equipment into an outlet on a circuit different from that to which the receiver is
- -Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be coÿlocated or operating in conjunction with any other antenna or

padmate°	Padmate Warranty Card (Please keep this card as proof)
Customer Name:	
Gender: :	
Address:	
Phone No.:	
Product Model:	
Product Series No.:	
Date of Purchase:	
Purchase Stamp :	
E-mail:	
Notice:	
Please fill out the form above with purchase stamp for the procedure of warranty. Any change on warranty card and invoice will result in invalidation.	
Please keep warranty card and invoice as the proof of warranty for the product. No replacement for warranty card or invoice.	

4. This warranty is valid within 1 year from the date of purchase.