

# How to use the wireless powerbank

(this function is optional, non-standard)

1. Double click the button to turn on





2. Put the mobile phone with wireless charging

### Warning and Declarations

BUILT-IN BATTERY CARE: Please observe the following if the product contains a battery ·Your product is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles.

•The battery can be charged and discharged hundreds of times, but will eventually wear out. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime.

•If left unused, a fully charged battery will lose its charge over time.

•Leaving the product in hot or cold places will reduce the capacity and lifetime of the battery Always try to keep the battery between 15°Cand 25°C (59°Fand 77°F) A product with a hot or cold battery may not work temporarily even when the battery is fully charged.

### Battery warning

- -"Caution"—the battery used in this product may present a risk of fire or chemical burn if mistreated. Batteries may explode if damaged.

  Only recharge your battery with the provided approved chargers designated for this product.

  Dispose of batteries according to local regulations. Please recycle when possible.Do not dispose as household waste or in a fire as they may explode.

·Unless otherwise specified in the user manual or quick start guide the battery in your product can not be removed or replaced by the user. Any attempt to do so is risky and may result in damage of the product.

Important:Please refer to the user manual for a description of the charging status indicator lights.Some products cannot be used while charging

- -Do not use a wall charger with more than 5V and 2A output.

  -When you disconnect the power cord or any enhancement, grasap and pull the plug, not the cord. Never use a charger that is damaged.

  -Do not attempt to disassemble the charger as it may expose you to dangerous electric shock.

- waint ENERGY.

   Unplug the product or charger before cleaning.

   Clean the product by wiping with a dry or slightly damp cloth. The cord and charger may only be dry-dusted.

**Padmate Warranty Card** padmate\* ( Please keep this card as proof) Product Series No.: \_\_\_\_\_ Date of Purchase: \_\_\_\_\_ Purchase Stamp: — E-mail: \_\_\_\_\_ Product Model: \_\_\_\_\_

## Notice:

- 1. Please fill out the form above with purchase stamp for the procedure of warranty. 2.Any change on warranty card and invoice will result in invalidation.
- 3. Please keep warranty card and invoice as the proof of warranty for the product. No replacement for warranty card or invoice.
- 4. This warranty is valid within 1 year from the date of purchase.

Any Changes expressly or modifications not approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation Note: This equipment has been tested and found to comply with the limits for a Class B digital

pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment

off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. More about test reports and DOC, please download from:



https://padmate-tech.com/pages/test-report-download