

Operator's Manual



Original Instructions

Table of contents

1	Introduction				
	1.1	General information	4		
	1.2	Intended use	7		
	1.3	FCC information	ç		
2	Safe	ty			
	2.1	Recognizing warnings	10		
	2.2	Safety instructions	11		
3	Proc	luct description			
	3.1	Overview and functionality	15		
	3.2	Identification plates and identification numbers	17		
	3.3	Information on the product	18		
4	Ope	rating and display elements			
	4.1	CLAAS Wireless Interface (CWI)	20		
	4.2	CWI Setup App	21		
5	Tech	Technical data			
	5.1	CLAAS Wireless Interface (CWI)	27		
6	Prep	paring product			
	6.1	Installing product	28		
7	Ope	ration			
	7.1	Initial commissioning	31		
	7.2	CWI Setup App	38		
	7.3	CWI Setup - Settings	44		
	7.4	CWI Setup - Advanced settings	46		
	7.5	EASY on board App	52		
8	Faul	t and remedy			
	8.1	Overview of the problems	54		
9	Mair	itenance			
	9.1	Maintenance tables	56		
	9.2	Tablet	57		
10	Dec	ommissioning and disposal			
		General information	58		
11	Tech	nnical terms and abbreviations			
- •		Terms and explanations	60		
	Inde	X	62		

1 Introduction

1.1 General information

1.1.1 Validity of the manual

184120-002

Product	Туре	Part number (software version)	
		from	to
iPad Kit	_	00 1393 709 0	_
CWI Setup App	_	1.0	_
EASY on board App	_	1.5	_

1.1.2 Information about this Operator's Manual

180412-002

Read through this operator's manual carefully to familiarize yourself with the safe and correct operation and maintenance of the product. This will help to prevent injuries and damage to equipment. If parts of the operator's manual are not understood, contact a CLAAS dealer.

This operator's manual goes with the machine and must be turned over to the purchaser of the product if the product is resold. If lost or damaged, the operator's manual can be ordered from a CLAAS dealer. The operator's manual is also available in other languages.

Directional indications, such as forward, reverse, right and left are to be understood in relation to the direction of travel.

169886-009

1.1.3 Symbols and instructions

Symbol	Meaning
©	Reference to page or documentation with more detailed information
*	Optional equipment
>	Procedural instruction
—	Lubricate the lubrication points with multipurpose grease.
~	Lubricate the lubrication points with lubricating oil.

NOTICE

The note describes how operation is made easier or material damage is prevented.

160551-008

1.1.4 CLAAS dealer

A CLAAS dealer has the required technical knowledge, tools and qualifications for the proper execution of the required work operations, such as:

- · Maintenance operations
- Repair operations
- · Installations and modifications

The CLAAS dealer documents the performance of work in accordance with CLAAS specifications. This documentation may be the prerequisite for warranty claims.

CLAAS recommends a CLAAS dealer.

180422-001

1.1.5 Notes on maintenance

Observance of the prescribed maintenance intervals ensures the best possible performance, reliability and safety of the product.

CLAAS recommends having the maintenance work performed by a CLAAS dealer.

165617-003

1.1.6 Notes about the warranty

The warranty claims arise from the terms and conditions of sale agreed upon with the CLAAS dealer.


The instructions of this operator's manual must be observed. The failure to observe these instructions may result in loss of warranty claims.

Maintenance work operations that are not described in this operator's manual may only be performed by a CLAAS dealer.



2021-001 180423-003

1.1.7 Replacement parts and technical questions



261530-001

1

► Enter the identification number, serial number, part number or software version of the product in the adjacent field.

The number is on the identification plate. The software version is in the menu.

► In the case of replacement part orders and technical questions, indicate the respective numbers and software version.



1.2 Intended use

1.2.1 Intended use

184131-001

An Apple iPad 4 or newer with the operating system iOS 8.0 or newer are required for the operation of the EASY on board App.

The EASY on board App is additional equipment / optional equipment and is provided exclusively for attachment to the machines (tractors / self-propelled harvesting machines) approved / released by the manufacturer.

The EASY on board App is suitable and intended to use in fields while operating CLAAS ISOBUS implements, to gather process data and send set values to implements.

The EASY on board App stores the control software transmitted by the CLAAS ISOBUS implement. With this software the implement can be operated using the tablet.

The product may only be used, maintained and repaired by persons who are familiar with the operation of the product and have been instructed about the operational risks when working with the product.

Intended use includes among other things the observance of the indications in the operator's manual, the digital operator's manual for the EASY on board App and the observance of the messages displayed on the tablet.

The pertinent accident prevention regulations and the other generally acknowledged safety technology, occupational health and traffic regulations must be observed by users and owners.

Any other use shall be considered <contrary to the intended use>; the manufacturer shall not be held liable for any damages that results from this improper use. These risks shall be born solely by the user.

You can obtain detailed information regarding intended use for special cases from CLAAS.

184132-001

1.2.2 Reasonably foreseeable improper use

Use falling outside the parameters of intended use comprises any use not intended by the manufacturer and therefore constitutes improper use in the sense of the machine directive. The manufacturer shall not be held liable for any resulting damages. These risks shall be born solely by the user.



Improper uses of the EASY on board App of this type are:

- Performance of adjustments, cleaning and maintenance work contrary to the specifications in the operator's manual.
- Performance of troubleshooting and maintenance work on drives and/or the diesel engine while they are still running.
- Performance of troubleshooting and maintenance work while the power supply is connected.
- Performance of maintenance and repair work by personnel not trained for this.
- Failure to heed warnings that are displayed on the tablet or included in the printed operator's manual or in the digital operator's manual.
- Unauthorized modifications to the product.
- Installation of unapproved/impermissible additional equipment.
- Use of replacement parts that do not comply with CLAAS requirements.



1.3 FCC information

1.3.1 FCC Compliance statement

195759-001

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Modifications not expressly approved by CLAAS could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



2 Safety

2.1 Recognizing warnings

2.1.1 Safety alert symbol

2.1.2 Signal word





This safety alert symbol gives a warning about risk of injury.

➤ To prevent injuries and death, follow all measures that are labeled with the safety alert symbol.

173668-003

The warnings in this operator's manual are introduced with the safety alert symbol and a signal word. The signal word gives expression to the danger.



DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

MARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



2.2 Safety instructions

2.2.1 Significance of the operator's manual

180681-003

The operator's manual is an important document and a part of the product. It is oriented toward the user and contains safety-relevant information. Only the procedures specified in the operator's manual are safe.

- ► Read and observe the chapter on safety before using the product for the first time.
- Read and observe the respective sections of the operator's manual before working.
- If contents are not understood or help is needed, notify a CLAAS dealer.

180669-003

2.2.2 Requirements for all people who work with the product

In order to prevent accidents, each person who works with the product must meet the following requirements:

- · Be physically able to control the product.
- · Be healthy and not suffer from fatigue.
- · Not be under the influence of drugs.
- Be able to safely carry out the work described in this manual.
- Understand the way the product works and be able to recognize and avoid the hazards of the work.
- Have understood the operator's manual and be able to implement the information in the manual.
- Be familiar with the safe operation of vehicles.
- For road travel, be familiar with the relevant rules of road traffic and possess the required operator's permit.

191086-001

2.2.3 Design modifications

Design modifications and expansions can impair the functionality and operational reliability of the product. As a result, people can be severely injured or killed.

 Have design modifications and expansions approved by CLAAS.

180684-003

2.2.4 Optional equipment and replacement parts

Optional equipment and replacement parts that do not conform to the requirements of the manufacturer can impair the operational reliability of the product and cause accidents.

- Use only CLAAS original parts or parts that conform to the requirements of CLAAS.
- If you have questions about equipment or replacement parts, contact a CLAAS dealer.



2021-001 191074-001

2.2.5 Hazard arising from damage to the tablet

Damage to the tablet can impair the operational reliability and cause accidents. As a result, people can be severely injured or killed. The following parts are especially important for safety:

• Screen

In the event of damage to the tablet or unexpected operating behavior:

- ➤ To stop any operations: turn off tractor ignition or press an EMERGENCY STOP button.
- ▶ Shut down tablet.
- ▶ Determine the cause of the damage or altered operating behavior and correct it.
- Have damage that can effect safety corrected by a CLAAS dealer.

191072-001

2.2.6 View of work area

Mounting location of the tablet must not obstruct the view of the work area. Diminished view of the work area can cause accidents.

Mount the tablet in such a way that the view of the work area is maintained.

184531-001

2.2.7 Glare and reflections

Glare and reflections can impair the operation of the tablet. Incorrect operation can trigger uncontrolled movements of the implements and cause accidents.

- Mount the tablet so that glare and reflections are avoided.
- ▶ Mount a glare shield on the tablet (anti-glare film).
- ▶ Darken cab.

191071-001

2.2.8 Inadvertent activation of functions

Inadvertent triggering of functions can cause uncontrolled movements of the implements and cause accidents.

Brackets and tablets must be attached in such a way that no body parts can inadvertently touch the screen and activate functions.

191073-001

2.2.9 Unauthorized operation

The user bears custodial responsibility for the tablet and the installed applications. Unauthorized operation can cause uncontrolled movements of the implements and cause accidents.

- ▶ Do not put the tablet in children's hands.
- ▶ Do not leave the tablet lying around unattended.



- Protect the tablet from unauthorized access (for example, lock cab).
- Only share the password with authorized persons.

191080-001

2.2.10 Use of the tablet outside of the cab

Tractor and machine can also be controlled via the tablet from outside the cab as far as the WLAN connection extends. If control functions are triggered using the tablet outside of the cab, the hazard zones cannot adequately be seen and accidents may result. The user can go into the hazard zones with the tablet in hand and thereby endanger himself and other persons.

- Make sure that the danger zone can be adequately viewed.
- Make sure that neither the user himself nor other people are in the danger zone.
- Never leave the WLAN reception range.
- Never allow children to play with the tablet.

184532-001

2.2.11 Follow safety instructions

Relevant safety instructions are displayed on the tablet that the user must confirm. Failure to observe the safety instructions may result in incorrect or unauthorized operation and cause accidents.

Note safety instructions that are displayed on the tablet.

191088-001

2.2.12 Check interaction of self-propelled machines / tractors and implements

The table can be used on various self-propelled machines / tractors with various implements. Tablets, self-propelled machines / tractors and implements can interact with each other. Therefore, check the compatibility and operability of the components with each other before use.

- ▶ In so doing observe documents such as:
 - Tablet operator's manual
 - Operator's manuals of the self-propelled machine
 - ► ™ Tractor operator's manual
 - ▶ ③ Operator's manuals of the implements
 - ISOBUS certificate.

170642-002

2.2.13 Hazard during travel on road with ISOBUS implement

The ISOBUS implement must be separated from ISOBUS or remain connected, depending on the particular ISOBUS implement, during travel on public streets and agricultural roads. If there is incorrect use, uncontrolled movements of implements, tractor or machine are triggered and cause accidents.



▶ ③ Operator's manual of the implements.

191089-001

2.2.14 Shutting down the tablet during operation

If the tablet is shut down during operation, all functions of implements, machines or tractors that are controlled by the tablet are canceled. Loss of control over the functions controlled by the tablet can cause uncontrolled movements of implements, machines and tractors and result in accidents.


- ► Never switch off the tablet while the vehicle is in operation.
- ► Always keep EASY on board App active in the foreground.

3 Product description

3.1 Overview and functionality

3.1.1 CWI overview

184139-001




288344-001

	Designation
1	Tablet
2	CWI
3	LED red
4	LED green
5	Key
6	LED blue
7	LED orange
8	Power supply
9	ISOBUS cable
10	ISOBUS socket



2021-001 184140-001

3.1.2 CWI mode of functioning



288347-001

	Function	Description
A	Initial commissioning	The CWI Setup App establishes a secure data link between CWI and table via WLAN.
В	Machine operation	The CWI loads the control program from the job computer of the connected machine via ISOBUS and transmits the screens and status information to the tablet.
		Inputs on the tablet are transferred to the CWI and from there via ISOBUS to the connected machine.
С	Expansions	The EASY on board App displays all installed modules and enables the program start.



184141-001

3.2 Identification plates and identification numbers

3.2.1 CWI identification plate



Identification plate on the CWI.

288348-001



288349-001

	Name	
1	CCN	
2	Serial number	
3	CLAAS part number	
4	Index	
	(Last position of the CLAAS part number)	
	Increase of the index is identified by blacking out the expired numbers, for example, in the case of a software update.	

189830-001

3.3 Information on the product

3.3.1 Factory settings



288348-001



288350-001

The factory setting for the WLAN name is located on the back side of the CWI (see arrow).

Alternatively, the preset WLAN name is displayed in the tablet in the following situations:

- After connection of the CWI to the ISOBUS socket.
- After resetting to the factory settings Page 47.

6

The factory setting for the password is located on the inside of the cover (see arrow).

The preset password reads:

claas-cwi

7

189836-001

3.3.2 Version of software and hardware



289409-001

Software version and hardware version are displayed in the screen <CWI Setup - Legal notice>.

Page 43

- (1) = Software version of the CWI Setup App
- (2) = Hardware version of the CWI



2021-001 189382-001

189383-001

3.3.3 Seal on the CWI



302224-001

NOTICE

Loss of warranty claims.

Damaged seal results in loss of warranty claims.

▶ Do not open the housing of the CWI.



4 Operating and display elements

4.1 CLAAS Wireless Interface (CWI)

4.1.1 CWI controls

184142-001



288351-001

1	0	

	Designation	Function
1	LED red	Flashing = Hardware error, overtemperature.
		Lights up (10 seconds) = data link interrupted.
2	LED green	Flashing = Waiting after button is pressed for establishment of the secure data link.
		Illuminated = Secure data link is active.
3	Key	Brief press of the button: Identification of the CWI when the secure data link is set up.
		Long press of the button (15 seconds): Resets the CWI to factory settings.
4	LED blue	Flashing = Initial commissioning required.
		Slowly flashing = Time exceeded in initial commissioning.
		Illuminated = Initial commissioning completed.
5	LED orange	Not used.



4.2 CWI Setup App

4.2.1 Screen overview





288352-001

	Designation	Function
1	Symbol	Displays the symbol of the CWI Setup App.
2	Menu name	Shows the names of the current screen.
3	Button	Executes corresponding actions when tapped.
4	Heading	Indicates the heading for the following lines.
5	Menu bar	Indicates data, status information and symbols.
		When tapped: calls up other screens.
5	Status field	Displays status information.



2021-001 184502-001


4.2.2 Buttons

	Designation	Functions
(i)	Button <information></information>	Displays the <cwi -="" legal="" notice="" setup=""> screen.</cwi>
	<easy app="" board="" on=""> button</easy>	Starts the EASY on board App.
~	Button <ok></ok>	Saves the entries and displays the previous screen.
×	Button <cancel></cancel>	Deletes the entries and displays the previous screen.
<	Button <back></back>	Displays the previous screen.
←	Button <left arrow=""></left>	Cursor one character to the left.
→	Button <right arrow=""></right>	Cursor one character to the right.



2021-001 184503-001

4.2.3 Main menu <CWI setup>



289083-001


	Designation	Function
1	Button <information></information>	When tapped: Displays the <cwi -="" legal="" notice="" setup=""> screen.</cwi>
2	<easy app="" board="" on=""> button</easy>	When tapped: starts the EASY on board App.
3	Menu bar <cwi connection=""></cwi>	Displays the status of the CWI connection:
		 <none> = no CWI connection present.</none> <connected> = CWI connection present, safe data link not present.</connected> <safe linked=""> = safe data link present.</safe>
4	Menu bar <wlan name=""></wlan>	Displays information about the WLAN network: • <-> = No WLAN connection present. • Name of the CWI, on which a WLAN connection exists. When tapped: displays further instructions.

	Designation	Function
5	Menu bar <safety link=""></safety>	Displays the status of the data link:
		 <-> (black) = No CWI connection present. <-> (white) = CWI connection present, safe data link not present. <safe linked=""> = safe data link present.</safe> When tapped: displays further screens.
		 Sequence for changing the factory settings (initial commissioning). Query dialog for setting up the safe data link. Query dialog for overwriting the safe data link. Query dialog for deleting the safe data link.
6	Menu bar <settings></settings>	When tapped: displays the <cwi -="" settings="" setup=""> menu.</cwi>



2021-001 184416-001

4.2.4 <CWI Setup - Settings> menu



289088-001


1	3
	J

	Designation	Function	
1	Button <back></back>	When tapped: displays the previous screen.	
2	Menu bar <device identifier=""></device>	When tapped: Change the name of the tablet.	
3	Menu bar <network name="" ssid=""></network>	When tapped: Change the name of the CWI (WLAN name).	
4	Menu bar <password></password>	When tapped: Change password for WLAN.	
5	Menu bar <communication led=""></communication>	Displays the status of the LEDs on the CWI: • green: LEDs are on. • gray: LEDs are off. When tapped: Switch LEDs on the CWI on or off.	
6	Menu bar <advanced settings=""></advanced>	When tapped: displays the <cwi -="" advanced="" settings="" setup=""> menu.</cwi>	



2021-001 184417-001

4.2.5 Submenu < CWI Setup - Advanced settings>



289090-001

	Designation	Function	
1	Button <back></back>	When tapped: displays the previous screen.	
2	Menu bar <cwi link="" partner=""></cwi>	Displays the name of the tablet, that is stored in the CWI.	
		When tapped: Deletes the name saved in the CWI.	
3	Menu bar <device link="" partner=""></device>	Displays the name of the CWI that is stored in the tablet.	
		When tapped: Deletes the name stored in the tablet.	
4	Menu bar <cwi factory="" settings=""></cwi>	When tapped: Resets the CWI to factory settings.	
5	Menu bar <reset app="" setup=""></reset>	When tapped: Deletes all settings in the tablet.	
6	Menu bar <can filter=""></can>	Displays the status of the CAN filter.	
		When tapped: Switch CAN filter on or off.	




5 Technical data

5.1 CLAAS Wireless Interface (CWI)

5.1.1 Specification

184351-001



288868-001

	Designation		
Α	Length	125.7	mm
В	Width	114.4	mm
С	Height	34	mm
	Weight	160	g
	Protection class	IP5k4	_
	Operating temperature	-40 to +70	°C
	Storage temperature	-30 to +80	°C
	Operating voltage	12 - 24	V
	Maximum current consumption	120 - 1000	mA
	Maximum electrical power (without USB charging function)	3	W
	Maximum electrical power (with USB charging function)	11	W
	USB charge current	500 - 1500	mA



184363-002

184365-002

6 Preparing product

6.1 Installing product

6.1.1 Installing CWI Setup App



302402-001

▶ Connect tablet to the Internet.

Connection to the Internet can be established via the wireless network (with SIM card) or via WLAN (with Access Point). Tablet operator's manual.

- ▶ Log on in the Apple App Store.
- ▶ Searching according to the <CWI Setup>.
- ▶ Download and install CWI Setup App.

Symbol <CWI Setup App> (1) is displayed on the tablet.

16

6.1.2 Installing EASY on board App



Connection to the Internet can be established via the wireless network (with SIM card) or via WLAN (with Access Point). Tablet operator's manual.

- ▶ Log on in the Apple App Store.
- Search using the keyword <EASY on board>.
- ▶ Download and install EASY on board App.

Symbol <EASY on board App> (1) is displayed on the tablet.



288902-001




2021-001 184366-001

6.1.3 Connecting tablet

287131-002



287132-001



287133-002

Requirement:

- Bracket for CWI and tablet is mounted in the tractor cab.
 - <EASY on board App> installation instructions
- ► Insert tablet in bracket.

18

▶ Plug in ISOBUS cable.

19

▶ Plug USB charging cable into the tablet.



► Connect USB charging cable to CWI.



287134-002

7 Operation

7.1 Initial commissioning

184372-001

7.1.1 Creating WLAN connection for the first time

Requirement:

- Tablet mounted and connected in the holder.
 Page 29
- · Blue LED on the CWI is flashing.

184474-001

NOTICE


The initial commissioning must be performed within 10 Min. of plugging in the ISOBUS cable.

If this time frame is exceeded, the blue LED slowly flashes and the CWI switches off reception for the WLAN.

- Unplug the ISOBUS cable of the CWI, then plug it back in.
- ► Tap <Settings> (1) symbol.







➤ Switch on WLAN (1).

▶ Switch off CWI (2).

The preset name of the CWI consists of "CWI" and the serial number, which is also shown on the identification plate (3).

288940-001

23



24 288945-001

1 т z 0 Ü E R o s D G H K Ă L C × 8 N M 8

25



26

▶ During the initial commissioning, enter the following password (1):

claas-cwi

The preset password is indicated in the cover of the CWI. Page 18, Factory settings

WLAN connection to the CWI (1) is created.

▶ Next steps: [™] Page 33, Changing factory setting



2021-001 184376-001

7.1.2 Changing factory setting

Requirement:

· Blue LED on the CWI is flashing.

184474-001

NOTICE

The initial commissioning must be performed within 10 Min. of plugging in the ISOBUS cable.

If this time frame is exceeded, the blue LED slowly flashes and the CWI switches off reception for the WLAN.

- Unplug the ISOBUS cable of the CWI, then plug it back in.
- ► Tap <CWI Setup App> (1) symbol.



288901-001



288949-001

Automatic sequence is started.

<CWI Setup - Initial setup> screen is displayed.

► Tap <Assign device identifier> (1) menu bar.

28





288950-001



288954-001



288955-001

31

<Device identifier> screen is displayed.

► Enter name (1) for tablet.

Tap <OK> button.

Name is saved.

29

<CWI Setup - Initial setup> screen is displayed.

► Tap <Change SSID> (1) menu bar.

30

<CWI SSID> screen is displayed.

- ► Enter name (1) for CWI.
- Tap <OK> button.

Name is saved.

The (SSID) name is composed as follows:

- Stationary component: "CWIxxxxxx" ("xxxxxx" corresponds to the serial number)
 Page 17
- 5 23 characters definable by the user
- A-Z, a-z, 0-9
- Period
- Underscore



<CWI Setup - Initial setup> screen is displayed.

► Tap <Change WLAN password> (1) menu bar.

288956-001

32

33



288957-001



288958-001



288959-001

<CWI password> screen is displayed.

- ► Enter password (1)
- Tap <OK> button.

Password is saved.

The password must meet the following requirements:

- 6 63 characters definable by the user
- A-Z, a-z, 0-9
- · Blank spaces
- !"#\$%&'()*+,-./:;<=>?@[\]^_`{|}

<CWI password> screen is displayed.

- ► Repeat password (1).
- Tap <OK> button.

Password is saved.

<CWI Setup - Initial setup> screen is displayed.

Blue LED on the CWI comes on.

Next steps: Page 36, Creating WLAN connection

35



2021-001 184481-001

7.1.3 Creating WLAN connection

288942-001



288963-001



38

288964-001

Requirement:

- Blue LED on the CWI comes on.
 This means that the initial commissioning was successfully performed.
- ► Tap <Settings> (1) symbol.

36

37

► Under <Select network>: tap CWI (1).

_





WLAN connection is established.

Name of the CWI (1) is displayed.

▶ Next steps: [™] Page 39, Creating safe data link



189641-001


7.2 CWI Setup App

7.2.1 Calling up menus



40

288901-001



Main menu <CWI Setup> is displayed.

► Tap <CWI Setup App> (1) symbol.

Call up <CWI Setup - Settings> menu:

► Tap <Settings> (1) menu bar.

289111-001



41

<CWI Setup - Settings> menu is displayed.

Call up <CWI Setup - Advanced settings> submenu:

► Tap <Advanced settings> (1) menu bar.

Return to the main menu:

<

Tap <Back> button.





301514-001

43

Submenu < CWI Setup - Advanced settings> is displayed.

Return to the<CWI Setup - Settings> menu:

<

Tap <Back> button.

184382-001

7.2.2 Creating safe data link



288968-001



288969-001

Requirement:

- Blue LED on the CWI comes on.
 This means that the initial commissioning was successfully performed.
- ► Call up <CWI Setup> main menu.

Main menu <CWI Setup> is displayed.

- (1) = <connected> : CWI link available, safe data link not present.
- (2) = Name of CWI, for which a WLAN connection exists.
- ► Tap <Safety link> (3) menu bar.

Depending on the operating state of the CWI, the following screens appear:

44

Case A:

- CWI has no information about the last connection or
- · CWI was last connected to this tablet.
- <Create safety link> screen is displayed.
- ► Tap <Yes> (1) menu bar.





46 289062-001



302306-001



288970-001



289002-001

Case B:

- · CWI was last connected to a different tablet or
- · Name of the tablet or password was changed.
- <Create safety link> screen is displayed.
- ► Tap <Yes> (1) menu bar.

Case C:

- CWI has an active connection with another tablet.
- <CWI Setup Note> screen is displayed.
- ▶ Terminate active connection to a different tablet or
- Reset CWI to factory setting: press button on the CWI for 15 seconds.
- Tap <Back> button.
- ► Repeat process.

<CWI Setup - Safety-Link> screen is displayed.

Green LED flashes.

Monitoring of the time period until a press of the button on the CWI is started (30 s).

If there is no press of a button within a time frame of 30 seconds, on the CWI in question, the main menu is displayed and the process must be repeated.

48

47

► Press button (1) on the CWI.

Message indicates that the EASY on board App is automatically started.



301258-001

50



301260-001



301269-001

<Safety note> screen is displayed.

- ► Read safety instructions (1).
- Move confirmation slide (2) in the direction of the arrow.

Note: Display position of the confirmation slide

Next steps: Page 52, Calling up operator's manual

51

52

184400-001

7.2.3 Delete safe data link

Requirement:

- · Green LED on the CWI comes on.
- · Blue LED on the CWI comes on.





289038-001



289039-001



289042-001

► Call up <CWI Setup> main menu.

Main menu <CWI Setup> is displayed.

- (1) = <Safe linked> : Safe data link present.
- (2) = Name of CWI, for which a WLAN connection exists.
- (3) = <Safe linked> : Safe data link present.
- ► Tap <Safety Link> (4) menu bar.

53

54

<Delete Safety Link> screen is displayed.

► Tap <Yes> (1) menu bar.

Main menu <CWI Setup> is displayed.

Safe data link is deleted.

- (1) = <connected> : CWI link available, safe data link not present.
- (2) = Name of CWI, for which a WLAN connection exists.
- (3) = <-> : CWI link available, safe data link not present.



2021-001 184500-001

7.2.4 Displaying software version



► Call up <CWI Setup> main menu. Main menu <CWI Setup> is displayed.

► Tap <Information> (1) symbol.

289408-001

56



<CWI Setup - Legal notice> screen is displayed.

- (1) = Software version of the CWI Setup App
- (2) = Hardware version of the CWI

184419-001

7.3 CWI Setup - Settings

7.3.1 Change settings



289116-001

58



288950-001



288955-001

► Call up <CWI Setup - Settings>.

<CWI Setup - Settings> menu is displayed.

► Tap menu bar (1) - (3) to change the desired settings.

The particular screens below are identical to those of the initial commissioning.

<CWI Setup - Device identifier> screen is displayed.

The changing of these settings results in the cancellation of the safe data link. The safe data link must thereafter be recreated. Page 39, Creating safe data link

Enter name (1) for tablet.

Tap <OK> button.

Name is saved.

59

<CWI SSID> screen is displayed.

The changing of these settings results in the cancellation of the WLAN connection. The WLAN connection must thereafter be recreated.

Page 36, Creating WLAN connection

- ► Enter name (1) for CWI.
- Tap <OK> button.

Name is saved.

The (SSID) name is composed as follows:

- Stationary component: "CWIxxxxxx" ("xxxxxx" corresponds to the serial number)
 Page 17
- 5 23 characters definable by the user
- A-Z, a-z, 0-9
- Period
- Underscore



288957-001

<CWI password> screen is displayed.

The changing of these settings results in the cancellation of the WLAN connection. The WLAN connection must thereafter be recreated.

Page 31, Creating WLAN connection for the first time


- ► Enter password (1).
- Tap <OK> button.

Password is saved.

- The password must meet the following requirements:
 - 6 63 characters long
 - A-Z, a-z, 0-9
 - Blank spaces
 - !"#\$%&'()*+,-./:;<=>?@[\]^_`{|} ~


184437-001

7.3.2 Switching LED on and off



289389-001

62



289400-001

- ► Call up <CWI Setup Settings>. <CWI Setup Settings> menu is displayed.
- ► Tap <Communication LED> (1) menu bar.

<CWI Setup - Communication LED> screen is displayed.

(1) = Indicates whether the LEDs are switched on or off.

Switch on LEDs:

► Tap <LED on> (2) menu bar LEDs on the CWI are switched on.

Switch off LEDs:

► Tap <LED off> (3) menu bar.

63 LEDs on the CWI are switched off.

Return without changes:

<

Tap <Back> button.

184488-001

7.4 CWI Setup - Advanced settings

7.4.1 Deleting connection partner in the CWI



289370-001



289137-001

65



66

289381-001

Call up <CWI Setup - Advanced settings> submenu.

Submenu < CWI Setup - Advanced settings> is displayed.

Both CWI as well as tablets save information about the respective data link partners. The display of a name in this screen does not mean that a secure data link actually exists.

- (1) = Name of the tablet, that is stored in the connected CWI.
- **64** (2) = Name of the CWI, that is stored in the tablet.
 - ► Tap <CWI Link partner> (3) menu bar to delete the names of the tablets in the connected CWI.

<Delete Safety Link> screen is displayed.

► Tap <Yes> menu bar.

Name of the tablet is deleted in the CWI.

Submenu < CWI Setup - Advanced settings > is displayed.

- (1) = <-> : No connection partner saved in the connected CWI.
- (2) = <-> : No connection partner saved in the tablet.

2021-001 184491-001

7.4.2 Deleting connection partner in the tablet



289385-001



289140-001



289381-001

Call up <CWI Setup - Advanced settings> submenu.

Submenu < CWI Setup - Advanced settings> is displayed.

Both CWI as well as tablets save information about the respective data link partners. The display of a name in this screen does not mean that a secure data link actually exists.

- (1) = Name of the tablet, that is stored in the connected CWI.
- (2) = Name of the CWI, that is stored in the tablet.
 Tap <Device Link partner> (3) menu bar to delete the names of the CWI in the tablet.

<Delete Safety Link> screen is displayed.

► Tap <Yes> menu bar.

Name of the CWI is deleted in the tablet.

68

Submenu < CWI Setup - Advanced settings> is displayed.

- (1) = <-> : No connection partner saved in the connected CWI.
- (2) = <-> : No connection partner saved in the tablet.

69


184495-001

7.4.3 Reset CWI to factory settings

In order to reset the CWI to factory settings, there are the following possibilities:

- Press button on the CWI for 15 seconds.
- Disconnect CWI from ISOBUS socket and plug it back in.
- With CWI Setup App, as described below.





► Call up <CWI Setup - Advanced settings> submenu.

Submenu <CWI Setup - Advanced settings> is displayed.

► Tap <CWI Factory settings> (1) menu bar.

289145-001


70

71

<Reset CWI> screen is displayed.

► Tap <Yes> menu bar.

289144-001



<CWI Setup - Note> screen is displayed.

CWI is reset to factory setting.

Tap <Back> button.

72



<CWI Setup - Initial setup> screen is displayed.

Automatic sequence is started.

► Additional procedure: Page 33, Changing factory setting

2021-001 184496-001

7.4.4 Reset tablet to factory settings



► Call up <CWI Setup - Advanced settings> submenu.

Submenu < CWI Setup - Advanced settings> is displayed.

► Tap <Reset Setup App> (1) menu bar.

289388-001



74

<Reset Setup App> screen is displayed.

► Tap <Yes> menu bar.

All settings in the tablet are deleted.




75

<CWI Setup - Note> screen is displayed.

CWI Setup App is reset.

Tap

Tap <Back> button.



301439-001

77

Submenu <CWI Setup - Advanced settings> is displayed.

- (1) = <->: No connection partner saved in the tablet.
- ► Next steps: [™] Page 39, Creating safe data link


189642-001

7.4.5 Switch CAN filter on and off

CWW26010 AXION950

301516-001

78



301517-001

In the normal case, the CAN filter is switched off.

When the CAN filter is switched on, the machine control transmits only relevant news to the tablet. The data traffic is thereby reduced.

Call up <CWI Setup - Advanced settings> submenu.

Submenu <CWI Setup - Advanced settings> is displayed.

- (1) = displays the status of the CAN filter.
- ▶ Tap <CAN filter> (2) menu bar.

<CWI Setup - CAN filter> screen is displayed.

(1) = Indicates whether the CAN filter is switched on or switched off.

Switch on CAN filter:

► Tap the <CAN filter on> (2) menu bar.

Machine controller transmits only relevant messages to the tablet.

Switch off CAN filter:

► Tap <CAN filter off> (3) menu bar.

79 Machine controller transmits all messages to the tablet.

Return without change:

Tap <Back> button.



Submenu <CWI Setup - Advanced settings> is displayed.

(1) = displays the status of the CAN filter.



184438-001

7.5 EASY on board App

7.5.1 Calling up operator's manual



► Tap <EASY on board App> (1) symbol.



81



Last active screen is displayed.

► Tap <Menu bar> (1) button.





Menu bar is displayed.

► Tap <Settings> (1) button.

83





<Settings> screen is displayed.

► Tap <Operator's manual> (1) menu bar.

301482-001

84

<Settings, Operator's manual> screen is displayed.

► Tap <Safety> (1) menu bar.



85




Chapter <Safety> is displayed.

Read text:

▶ Scroll through the text using the smart phone gestures wipe and zoom.

Return to the previous screen:

Tap <Back> button.



8 Fault and remedy

8.1 Overview of the problems

8.1.1 CWI faults

184392-001

2021-001

Regarding troubleshooting:

▶ Make sure that the LEDs are switched on. Page 45

Fault	Possible cause / remedy
Factory settings cannot be changed. Blue LED slowly flashes.	Time span of 10 minutes to change the factory settings is overwritten.
Bide LEB Glowly hadries.	Unplug the ISOBUS cable and plug it back in. Page 29
No connection after restart.	Error in the initialization of the CWI.
All LEDs flash.	Unplug the ISOBUS cable and plug it back in. Page 29
	Temperature too high.
	► Allow to cool down.
	Hardware error.
	Replace CWI.Notify CLAAS dealer.
Tablet connects to the wrong CWI.	Located within the WLAN reception range of the table are multiple CWIs. The tablet automatically produces an WLAN connection to the CWI with which was already connected once.
	Automatic WLAN connection establishment.Tablet operator's manual
Safety Link is always deleted again.	Safe data link was not used for 4 hours.
	► Re-establish safe data link. ு Page 39
Reaction time to function inputs is too slow.	Non-relevant CAN messages increase communication traffic.
	➤ Switch on CAN filter. [™] Page 50
CWI automatically switches off.	Temperature too high (>73°C).
All LEDs flash.	► Allow to cool down.
	► Mount CWI in a cooler place.
	Unplug the ISOBUS cable and plug it back in. Page 29
Power supply for USB charging function of the	Temperature too high (>65°C).
tablet is failed.	► Allow to cool down.
All LEDs flash.	 Mount CWI in a cooler place. Unplug the ISOBUS cable and plug it back in. Page 29
LEDs on the CWI do not light up.	LEDs are switched off.
	► Switch on LED. [™] Page 45



2021-001 189694-001

8.1.2 Fault message: USB charging connection was disconnected



301694-001



301695-001

88

87

If the tablet is removed from the bracket and is disconnected from the USB charging cable, the machine control requires two key operation. The prevents an inadvertent triggering of machine functions.

Fault message <Attention> is displayed.

► Follow displayed safety instructions.

184399-001

8.1.3 Fault message: Tablet outside of WLAN reception range



289033-001

89

If the tablet leaves the WLAN reception range of the CWI, the connected machine goes into the safety stop.

Fault message <Unexpected cutoff> is displayed.

Bring tablet into the vicinity of the CWI.

Upon reentry into the WLAN reception range, the safe connection is restored.



9 Maintenance

9.1 Maintenance tables

9.1.1 Daily

Maintenance work	
Check all plug connections for secure seating.	_
Check mounting of the tablet.	_
Clean tablet.	Page 57
Load software updates.	Page 57



184517-001

9.2 Tablet

9.2.1 Cleaning tablet



90

► Clean Tablet (1) with the suitable cloth.

9.2.2 Loading software updates

- ► Connect tablet to the Internet.
- ▶ Log on in the Apple App Store.
- ▶ If updates are available, perform software update.

10 Decommissioning and disposal

10.1 General information


10.1.1 Decommissioning and disposal

162163-002

If the machine or its components have reached the end of their useful service life and they are consigned as scrap, the components must be disposed of properly. In so doing, the regulations of the competent local authorities must be heeded.

Fuels/operating materials in the machine require special disposal and must not get into the environment. Additional information regarding the disposal is available from the competent local authorities, the qualified specialist workshop or CLAAS customer service.


▶ Do not dispose of products with the symbol (1) in domestic waste when they reach the end of their service life.




124657-002



91





- 92
- Recycle packaging materials, consign them for reuse and do not dispose of them in the domestic waste
- ▶ Plastics that are marked with the indication of the material, for example, PP TV 20 should be recycled, consigned for reuse and not disposed of in the domestic waste.
- ➤ Sort and recycle old metals, consign them for reuse and do not dispose of them in the domestic waste.



- Properly dispose of electrical and electronic components, or deposit them at a collection site.
 Do not dispose of electrical and electronic components in the domestic waste.
- ▶ Old batteries contain hazardous materials and must be accepted back by the distributor, properly disposed of or deposited at a collection site. Do not dispose of old batteries in the domestic waste.
- ► Treat operating materials, such as oils, hydraulic fluids, brake fluid or fuels like special waste and dispose of them properly. If fluids are drained, always use containers that do not leak. Do not allow any operating materials to flow onto the ground, into the sewer system or into water sources.
- ► Clean hydraulic components loaded with oil, for example, valves, pipes or hoses or treat them like special waste and dispose of them properly.
- ► Have refrigerants disposed of by professional companies with specialist personnel and the required technical equipment. Refrigerants must not end up in the atmosphere. Have refrigerants disposed of by a qualified specialist workshop. Heed country-specific regulations.
- Heed regulations of the competent local authorities.



11 Technical terms and abbreviations

11.1 Terms and explanations

11.1.1 Abbreviations

Α	Amperes
Арр	Application (application software for tablets and smartphones)
CAN	Controller Area Network (serial bus system)
CCN	CLAAS Component Number
CDS	CLAAS diagnostic system
CE	Conformité Européenne
cm	Centimeter
CUTT	CLAAS Universal Tablet based Terminal (combination of CWI and tablet with appropriate application programs)
CWI	CLAAS Wireless Interface (component for the connection of ISOBUS and tablet via WLAN)
db	Decibels
dB (A)	A-rated equivalent continuous sound pressure level
DIN	German Institute for Standardization
EG	European Community
EN	European Standard
Vehicle ID no.	Vehicle identification number
g	Gram
Ges.	Total
GPS	Satellite navigation system
h	Hours
ISO	Internationale Organisation for Standardization
kg	Kilograms
KGaA mbH	Kommanditgesellschaft auf Aktien mit beschränkter Haftung (private limited liability company)
kPa	Kilopascals
km	Kilometers
km/h	Kilometers per hour
kW	Kilowatts
[Liters
l/min	Liters per minute
LED	Light emitting diode
m	Meters
mA	Milliamperes



rpm	Revolutions per minute
mm	Millimeters
m/s	Meters per second
Nm	Newton meters
s	Seconds
SSID	Service set identifier (device in a WLAN wireless network)
StVZO	Road Traffic Licensing Law
UT-App	Universal Terminal App (application program for tables for the operation of CLAAS ISOBUS implements)
UТур	Subtype
V	Volts
W	Watts
WLAN	Wireless Local Area Network (local wireless network)
z. B.	For example
%	Percent
°C	Degrees Celsius (unit for temperature)

184522-001

11.1.2 Technical terms

Access Point (AP)	Access point for wireless networks (also: base station)
App Store	Sales portal for apps of the manufacturer Apple
CAN bus	Serial bus system
Data bus	Transfers data between the connected devices
iPad	Brand name for tablets of the manufacturer Apple
ISOBUS	Standardized communication log for the data exchange between individual components (according to ISO 11783)
Machine	Implement for attachment to the tractor
Recycles	Reuse of used, defective or no longer needed products
Safety link	Safe data link
Smart phone	Mobile telephone
Tablet	Portable, flat computer with touchscreen
Touchscreen	Touch-sensitive screen
WLAN	Local wireless network
Machine Recycles Safety link Smart phone Tablet Touchscreen	individual components (according to ISO 11783) Implement for attachment to the tractor Reuse of used, defective or no longer needed products Safe data link Mobile telephone Portable, flat computer with touchscreen Touch-sensitive screen



Index

A	
Abbreviations	60
Advanced settings	
CAN filter	50
CWI Factory settings	47
Deleting connection partner in the CWI	46
Deleting connection partner in the tablet	47
Menu	26
Table factory settings	49
n	
B Batteries	
	50
Disposal	
Button	
Back	• • •
Cancel	
EASY on board App	
Information	•
Left arrow	
OK	
Right arrow	22
Buttons	
Overview	22
С	
Calling up	
Menus	20
CAN filter	
Switching off	
Switching onCCN	50
	47
Identification plate	
Cleaning	F-7
Tablet	
Communication LED	25
Compliance statement	
FCC	9
Connecting	
Tablet	29
Connection	
Creating safe data link	
Creating WLAN connection	
Delete Safety Link	
Initial commissioning	31
Controls	
CWI	
CWI Setup App	21
Current consumption	27
CWI	15
Controls	20
Faults	54
Identification plate	17
Mode of functioning	
Overview	
Seal	
Technical specifications	



	2021-001
Version	43
CWI Setup App	
Installing	
CWI connection	
CWI Factory settings	
CWI Link partner	26
CWI Setup App	0.0
Buttons	
CWI Setup menu - Advanced settings	
CWI Setup - Settings	
lcons	
Main menu	
Overview	
Software version	
Symbols CWI Setup - Advanced settings	
Calling up	20
CWI Setup - Settings Calling up	20
Calling up	38
D.	
D	
Damage	4.0
Tablet	
Dealer	
CLAAS	
Device identifier	
Device Link partner	
Dimensions	27
Disposal	50
Batteries	
Fuels/operating materials	
Machine	
Packing materials	
Refrigerant	
During operation Tablet, shutting down	1.4
rablet, Shutting down	14
E	
—	
EASY on board App	20
Installing	28
EASY on board App	EO
Operator's manual	
Electrical power	
Equipment Safety	4.4
Salety	1 1
F	
-	
Factory setting	
Changing	
Password	
WLAN name	18
Factory settings	
CWI	
Tablet	49
Fault	
CWI	54



	2021-001
Fault message	
Tablet outside of WLAN reception range	
USB charging connection was disconnected	55
FCC	
Compliance statement	9
Fuels/operating materials	
Disposal	58
H	
Hardware	40
Version, displaying	
Height	27
ı	
lcon	21
Icons	21
CWI Setup App	22
Identification number	
Position	
Identification plate	17
CWI	17
	17
Improper use Reasonably foreseeable	7
Information	
	1
Operator's Manual	
<u> </u>	
Changing factory setting Creating WLAN connection	
Installing	
CWI Setup App	20
EASY on board App	
Intended use	
ISOBUS cable	
ISOBUS cableISOBUS socket	
ISODOS SUCREL	13
K	
Key	15 20
10y	
L	
 LED	
blue	15 20
green	,
orange	
red	
Legal notice	
Length	
M	
Machine	
Disposal	58
Operation	
Main menu	
CWI Setup App	23
Maintenance	20
Notes	5
Maintenance tables	
Daily	56
Dully	



Validity 4 Menu Calling up menus 38 CWI_Setup 23 CWI Setup - Advanced settings 26, 46, 47, 47, 49, 50 CWI Setup - Settings 25, 44, 45 Heading 21 Main menu 23 Menu bar 21 Menu name 21 Status field 21 Menu bar 25 Advanced settings 25 CAN filter 26 Communication LED 25 CWI connection 23 CWI Factory settings 26 CWI Link partner 26 Device identifier 25 Device Link partner 26 Network name / SSID 25 Password 25 Resetting Setup App 26 Safety link 24 WLAN name 23 Mode of functioning 24 CWI 16 Modification 16 Product 11 Network name / SSID 25		2021-001
Menu 38 CWI Setup - Advanced settings. 26, 46, 47, 47, 49, 50 CWI Setup - Settings. 25, 44, 45 Heading. 21 Main menu. 23 Menu bar 21 Menu bar 21 Menu bar 21 Menu bar 21 Advanced settings. 25 CAN filter. 26 COmmunication LED. 25 CWI Connection. 23 CWI Factory settings. 26 CWI Link partner. 26 Device identifier. 25 Device Link partner. 26 Network name / SSID. 25 Password. 25 Resetting Setup App. 26 Safety link. 24 Settings. 24 WLAN name 23 Mode of functioning 26 CWI. 16 Modification 27 Properating temperature. 27 Operating temperature. 27 Operating temperature. 27 Operating temperature. <th>Manual</th> <th></th>	Manual	
Calling up menus. 38 CWI Setup - Advanced settings. 26, 46, 47, 47, 49, 50 CWI Setup - Settings. 25, 44, 45 Heading. 21 Main menu. 23 Menu bar 21 Menu bar 21 Status field. 21 Menu bar 25 Advanced settings. 25 CAN filter 26 Communication LED. 28 CWI connection. 23 CWI Factory settings. 26 CWI Link partner 26 Device identifier. 25 Device identifier. 26 Device identifier. 26 Settings. 26 Network name / SSID. 25 Resetting Setup App. 26 Safety link. 24 Settings. 24 WILAN name. 23 Mode of functioning 23 Will. 16 Modification 25 Product. 11 Network name / SSID. 25 Notes 11	,	4
CWI Setup - Advanced settings		
CWI Setup - Settings 26, 46, 47, 47, 49, 50 CWI Setup - Settings 25, 44, 45 Heading 21 Main menu 23 Menu bar 21 Status field 21 Menu bar 21 Advanced settings 25 CAN filter 26 Communication LED 25 CWI Connection 23 CWI Factory settings 26 CWI Link partner 26 Device identifier 25 Device identifier 25 Pescetting Setup App 25 Resetting Setup App 26 Safety link 24 Settings 24 WLAN name 23 Model of functioning 23 CWI 16 Modification 10 Product 11 Notes 27 In this manual 4 O 27 Operating temperature 27 Operating voltage 27 Operating voltage 27 Op		
CWI Setup - Settings 25, 44, 45 Heading 21 Main menu 23 Menu bar 21 Menu name 21 Status field 21 Menu bar 21 Advanced settings 25 CAN filter 26 Communication LED 25 CWI Connection 23 CWI Link partner 26 Device identifier 25 Device Link partner 26 Network name / SSID 25 Password 25 Resetting Setup App 26 Safety link 24 Settings 24 WLAN name 23 Mode of functioning 23 CWI 16 Modification 16 Product 11 N 10 Network name / SSID 25 Notes 25 In this manual 4 O 27 Operating temperature 27 Operating voltage 27		
Heading		
Main menu 23 Menu bar. 21 Menu name. 21 Status field. 21 Menu bar 21 Menu bar 21 Advanced settings. 25 CAN filter 26 Communication LED. 25 CW connection. 23 CWI Link partner. 26 Device lentifier 25 Device lentifier 25 Device Link partner. 26 Network name / SSID. 25 Password. 25 Resetting Setup App. 26 Safety link. 24 Settings. 24 WLAN name. 23 Mode of functioning 23 CWI. 16 Modification 16 Product. 11 Network name / SSID. 25 Notes 1 In this manual. 4 Qperating temperature. 27 Operating tom parture. 27 Operation observed. 27 Overview	·	
Menu bar. 21 Menu bar 21 Advanced settings. 25 CAN filter. 26 Communication LED. 25 CWI Connection. 23 CWI Factory settings. 26 CWI Link partner. 26 CWI Link partner. 26 Device Ink partner. 26 Network name / SSID. 25 Password. 25 Resetting Setup App. 26 Safety link. 24 Settings. 24 WAN name. 23 Mod of functioning 16 CWI 16 Modification 16 Product. 11 N 11 Network name / SSID. 25 Notes 1 In this manual. 4 O 27 Operating temperature. 27 Operating voltage. 27 Operating to hoard App. 52 Information 4 Meaning. 21 OW Setup App. 21		
Menu name. 21 Status field 21 Menu bar 25 Advanced settings 25 CAN filter 26 Communication LED. 25 CWI connection 23 CWI particle 26 Device lentifier 26 Device lentifier 25 Device Link partner 26 Network name / SSID 25 Password 25 Resetting Setup App 26 Safety link 24 Settings 24 WLAN name 23 Mod of functioning 23 CWI 16 Modification 16 Product 11 N V Network name / SSID 25 Notes 1 In this manual 4 Operating by oltage 27 Operator's manual 2 EASY on board App 52 Information 4 Meaning 11 Overview 21	Main menu	23
Status field 21 Menu bar 25 Advanced settings 25 CAN filter 26 Communication LED 25 CWI connection 23 CWI Factory settings 26 CWU Link partner 26 Device identifier 25 Device ink partner 26 Network name / SSID 25 Password 25 Resetting Setup App 26 Safety link 24 Settings 24 WLAN name 23 Mode of functioning 24 CWI 16 Modification 1 Product 11 N 1 Metwork name / SSID 25 Notes 1 In this manual 4 O 2 Operating temperature 27 Operating voltage 27 Operating to board App 52 Information 4 Meaning 11 OWI Setup App 21	Menu bar	21
Menu bar 25 Advanced settings 25 CAN filter 26 Communication LED 25 CWI Connection 23 CWI Factory settings 26 CWI Link partner 26 Device ledentifier 25 Device Link partner 26 Network name / SSID 25 Password 25 Resetting Setup App 26 Safety link 24 Settings 24 WLAN name 23 Mod of functioning 23 CWI 16 Modification 16 Product 11 N 25 Network name / SSID 25 Notes 25 In this manual 4 O 20 Operating temperature 27 Operating voltage 27 Operating voltage 27 Operating voltage 27 Operating voltage 25 Information 4 Meaning 1	Menu name	21
Advanced settings. 25 CAN filter. 26 Communication LED. 25 CWI connection. 23 CWI Factory settings. 26 CWI Link partner. 26 Device identifier. 25 Device Link partner. 26 Network name / SSID. 25 Password. 25 Resetting Setup App. 26 Safety link. 24 Settings. 24 WLAN name. 23 Mode of functioning 20 CWI. 16 Modification 16 Product. 11 N 10 Network name / SSID. 25 Notes 1 In this manual. 4 4 27 Operating temperature. 27 Operating voltage. 27 Operator's manual 28 EASY on board App. 5 EASY on board App. 25 CWI. 15 CWI. 15 CWI. 15 </td <td>Status field</td> <td>21</td>	Status field	21
CAN filter. 26 Communication LED. 25 CWI connection. 23 CWI Factory settings. 26 CWI Link partner. 26 Device identifier. 25 Device Link partner. 26 Network name / SSID 25 Password. 25 Resetting Setup App. 26 Safety link. 24 Settings. 24 WLAN name. 23 Mode of functioning 3 CWI. 16 Modification 16 Product. 11 N 11 Notes 1 In this manual. 4 O 25 Notes in this manual. 4 Operating temperature. 27 Operating voltage. 27 Operator's manual 27 EASY on board App. 52 Information. 4 Meaning. 11 Overview 21 CWI. 25 CWI Setup App. 21	Menu bar	
CAN filter. 26 Communication LED. 25 CWI connection. 23 CWI Factory settings. 26 CWI Link partner. 26 Device identifier. 25 Device Link partner. 26 Network name / SSID 25 Password. 25 Resetting Setup App. 26 Safety link. 24 Settings. 24 WLAN name. 23 Mode of functioning 3 CWI. 16 Modification 16 Product. 11 N 11 Notes 1 In this manual. 4 O 25 Notes in this manual. 4 Operating temperature. 27 Operating voltage. 27 Operator's manual 27 EASY on board App. 52 Information. 4 Meaning. 11 Overview 21 CWI. 25 CWI Setup App. 21	Advanced settings	25
CWI connection. 23 CWI Factory settings 26 CWI Link partner 26 Device identifier. 25 Device Link partner. 26 Network name / SSID. 25 Password. 25 Resetting Setup App. 26 Safety link. 24 Settings. 24 WLAN name. 23 Mode of functioning 16 CWI. 16 Modification 11 Product. 11 Network name / SSID. 25 Notes 1 In this manual. 4 O 27 Operating temperature. 27 Operating voltage. 27 Operating voltage. 27 Operating voltage. 27 Operating temperature. 27 Operating voltage. 27 Operating temperature. 4 Meaning. 11 Overview 11 CWI. 15 CWI. 15 CWI.	CAN filter	26
CWI connection. 23 CWI Factory settings 26 CWI Link partner 26 Device identifier. 25 Device Link partner. 26 Network name / SSID. 25 Password. 25 Resetting Setup App. 26 Safety link. 24 Settings. 24 WLAN name. 23 Mode of functioning 16 CWI. 16 Modification 11 Product. 11 Network name / SSID. 25 Notes 1 In this manual. 4 O 27 Operating temperature. 27 Operating voltage. 27 Operating voltage. 27 Operating voltage. 27 Operating temperature. 27 Operating voltage. 27 Operating temperature. 4 Owerview 27 CWI. 15 CWI. 15 CWI. 15 CWI. <	Communication LED	25
CWI Factory settings. 26 CWI Link partner. 26 Device identifier. 25 Device Link partner. 26 Network name / SSID. 25 Password. 25 Resetting Setup App. 26 Safety link. 24 Settings. 24 WLAN name. 23 Mode of functioning 16 CWI. 16 Modification 11 Product. 11 N 11 Network name / SSID. 25 Notes 2 In this manual. 4 O 2 Operating temperature. 27 Operator's manual 2 EASY on board App. 2 EASY on board App. 2 Information. 4 Meaning. 11 Overview 21 CWI. 15 CWI. 21 P 22 Packing materials 58 Disposal. 58		
CWI Link partner. 26 Device Identifier 25 Device Link partner 26 Network name / SSID 25 Password 25 Resetting Setup App. 26 Safety link 24 Settings. 24 WLAN name. 23 Mod of functioning 16 CWI. 11 N 11 Network name / SSID. 25 Notes 1 In this manual. 4 Operating temperature. 27 Operating voltage. 27 Operator's manual 2 EASY on board App. 52 Information. 4 Meaning. 52 Overview 11 CWI. 15 CWI Setup App. 21 P 21 P 25 Packing materials 58 Disposal. 58 Part number 6 Identification plate 17 Password. 25		
Device identifier 25 Device Link partner 26 Network name / SSID 25 Password 25 Resetting Setup App 26 Safety link 24 Settings 24 WLAN name 23 Mode of functioning 16 CWI 16 Modification 11 Product 11 N 25 Network name / SSID 25 Notes 1 In this manual 4 O 20 Operating temperature 27 Operator's manual 27 EASY on board App 52 Information 4 Meaning 11 Overview 21 CWI 15 CWI Setup App 21 Per number 6 Identification plate 17 Password 25 Factory setting 18		
Device Link partner 26 Network name / SSID 25 Password 25 Resetting Setup App 26 Safety link 24 Settings 24 WLAN name 23 Mode of functioning 16 CWI 16 Modification 11 Product 11 Network name / SSID 25 Notes 1 In this manual 4 Operating temperature 27 Operating voltage 27 Operator's manual 27 EASY on board App 52 Information 4 Meaning 52 UNI 1 Overview 1 CWI 15 CWI Setup App 21 P 25 Packing materials 58 Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 25		
Network name / SSID 25 Password 25 Resetting Setup App 26 Safety link 24 Settings 24 WLAN name 23 Mode of functioning 16 CWI 16 Modification 11 Product 11 Network name / SSID 25 Notes 25 In this manual 4 O 27 Operating temperature 27 Operating voltage 27 Operator's manual 27 EASY on board App 52 Information 4 Meaning 11 Overview 11 CWI 15 CWI Setup App 21 P 21 Per Packing materials Disposal 58 Part number 6 6 Identification plate 17 Password 25 Factory setting 18		
Password. 25 Resetting Setup App. 26 Safety link. 24 Settings. 24 WLAN name. 23 Mode of functioning 16 CWI. 16 Modification 11 Product. 11 N 1 Network name / SSID. 25 Notes 1 In this manual. 4 O 27 Operating temperature. 27 Operator's manual 27 EASY on board App. 52 Information. 4 Meaning. 52 Information. 4 Meaning. 11 Overview 15 CWI. 15 CWI Setup App. 21 Packing materials 58 Disposal. 58 Part number. 6 Identification plate. 6 Identification plate. 17 Password. 25 Factory setting. 18		
Resetting Setup App. 26 Safety link 24 Settings 24 WLAN name 23 Mode of functioning 16 CWI 16 Modification 11 Product 11 Network name / SSID 25 Notes 1 In this manual 4 O 27 Operating temperature 27 Operating voltage 27 Operator's manual 24 EASY on board App 52 Information 4 Meaning 11 Overview 25 CWI 15 CWI Setup App 21 P 25 Packing materials 58 Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18		
Safety link 24 Settings 24 WLAN name 23 Mode of functioning 16 CWI 16 Modification 11 Product 11 N 25 Network name / SSID 25 Notes 1 In this manual 4 O 27 Operating temperature 27 Operating voltage 27 Operating voltage 27 Operating voltage 27 Operating voltage 27 Operating temperature 27 Operating voltage 27 Operating voltage 27 Operating voltage 27 Operating temperature 27 <td></td> <td></td>		
Settings 24 WLAN name 23 Mode of functioning 16 CWI 16 Modification 11 Product 11 Network name / SSID 25 Notes 1 In this manual 4 O 27 Operating temperature 27 Operator's manual 27 EASY on board App. 52 Information 4 Meaning 11 Overview 11 CWI 15 CWI Setup App. 21 P Packing materials 58 Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18		
WLAN name 23 Mode of functioning 16 CWI 16 Modification 11 Product 11 Network name / SSID 25 Notes 1n this manual 4 O 20 Operating temperature 27 Operator's manual 27 EASY on board App 52 Information 4 Meaning 11 Overview 11 CWI 15 CWI Setup App 21 P Packing materials Disposal 58 Part number 6 I dentification plate 17 Password 25 Factory setting 18		
Mode of functioning 16 CWI 16 Modification 11 Product 11 Network name / SSID 25 Notes 1 In this manual 4 O 27 Operating temperature 27 Operating voltage 27 Operator's manual 28 EASY on board App 52 Information 4 Meaning 11 Overview 11 CWI 15 CWI Setup App 21 P Packing materials Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18	•	
CWI 16 Modification 11 Product 11 N 25 Notes 25 In this manual 4 O 27 Operating temperature 27 Operating voltage 27 Operator's manual 27 EASY on board App 52 Information 4 Meaning 11 Overview 11 CWI 15 CWI Setup App 21 P Packing materials Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18		23
Modification 11 N Network name / SSID 25 Notes In this manual 4 O Operating temperature 27 Operating voltage 27 Operator's manual 25 EASY on board App 52 Information 4 Meaning 11 Overview 11 CWI 15 CWI Setup App 21 P Packing materials 58 Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18	5	16
Product 11 N Network name / SSID 25 Notes 1n this manual 4 O Operating temperature 27 Operating voltage 27 Operator's manual 27 EASY on board App 52 Information 4 Meaning 11 Overview 15 CWI 15 CWI Setup App 21 P Packing materials 0isposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18		10
N Network name / SSID. 25 Notes		4.4
Network name / SSID 25 Notes 4 In this manual 4 O 27 Operating temperature 27 Operator's manual 27 EASY on board App. 52 Information 4 Meaning. 11 Overview 11 CWI. 15 CWI Setup App. 21 P Packing materials 58 Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18	Product	TI
Network name / SSID 25 Notes 4 In this manual 4 O 27 Operating temperature 27 Operator's manual 27 EASY on board App. 52 Information 4 Meaning. 11 Overview 11 CWI. 15 CWI Setup App. 21 P Packing materials 58 Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18		
Notes In this manual 4 O O Operating temperature 27 Operating voltage 27 Operator's manual 8 EASY on board App 52 Information 4 Meaning 11 Overview 15 CWI 15 CWI Setup App 21 P Packing materials 58 Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18		
In this manual 4 O 20 Operating temperature 27 Operator's manual 27 EASY on board App 52 Information 4 Meaning 11 Overview 15 CWI 15 CWI Setup App 21 P Packing materials Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18	Network name / SSID	25
O Operating temperature 27 Operating voltage 27 Operator's manual 52 EASY on board App 52 Information 4 Meaning 11 Overview 20 CWI 15 CWI Setup App 21 P Packing materials Disposal Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18	Notes	
Operating temperature. 27 Operating voltage. 27 Operator's manual 52 EASY on board App. 52 Information. 4 Meaning. 11 Overview 52 CWI. 15 CWI Setup App. 21 P Packing materials 58 Disposal. 58 Part number. 6 Identification plate. 17 Password. 25 Factory setting. 18	In this manual	4
Operating temperature. 27 Operating voltage. 27 Operator's manual 52 EASY on board App. 52 Information. 4 Meaning. 11 Overview 52 CWI. 15 CWI Setup App. 21 P Packing materials 58 Disposal. 58 Part number. 6 Identification plate. 17 Password. 25 Factory setting. 18		
Operating voltage. 27 Operator's manual 52 EASY on board App. 52 Information. 4 Meaning. 11 Overview 52 CWI. 15 CWI Setup App. 21 P Packing materials Disposal. 58 Part number. 6 Identification plate. 17 Password. 25 Factory setting. 18	0	
Operating voltage. 27 Operator's manual 52 EASY on board App. 52 Information. 4 Meaning. 11 Overview 52 CWI. 15 CWI Setup App. 21 P Packing materials Disposal. 58 Part number. 6 Identification plate. 17 Password. 25 Factory setting. 18	Operating temperature	27
Operator's manual 52 EASY on board App. 52 Information. 4 Meaning. 11 Overview 50 CWI. 15 CWI Setup App. 21 P Packing materials Disposal. 58 Part number. 6 Identification plate. 17 Password. 25 Factory setting. 18	Operating voltage	27
EASY on board App 52 Information 4 Meaning 11 Overview 15 CWI 15 CWI Setup App 21 Packing materials 58 Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18		
Information 4 Meaning 11 Overview 21 CWI 15 CWI Setup App 21 Packing materials 58 Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18	·	
Meaning	··	
Overview CWI 15 CWI Setup App. 21 P Packing materials 58 Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18		
CWI 15 CWI Setup App 21 P Packing materials Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18	· · · · · · · · · · · · · · · · · · ·	
CWI Setup App. 21 P Packing materials Disposal. 58 Part number. 6 Identification plate. 17 Password. 25 Factory setting. 18		15
Packing materials 58 Disposal 58 Part number 6 Identification plate 17 Password 25 Factory setting 18		
Packing materials 58 Disposal	Οννι Θειαρ Αρρ	21
Packing materials 58 Disposal	n	
Disposal		
Part number 6 Identification plate 17 Password 25 Factory setting 18		
Identification plate 17 Password 25 Factory setting 18	•	
Password		
Factory setting18	•	
, ,		
Power supply	, ,	
	Power supply	



	2021-001
Program	40
Version, displaying	
Protection class	27
Q	
Qualification	
Users	11
05615	11
R	
Reasonably foreseeable improper use	7
Refrigerant	
Disposal	58
Replacement part	
Ordering or technical question	6
Safety	
Requirements	
Users	11
Resetting Setup App	
Road travel	
S	
Safe data link	
Deleting	41
Safety	
Control of self-propelled machines / tractors	13
Design modifications	
Follow safety instructions	
Foreseeable improper use	7
Glare and reflections	12
Hazard arising from damage to the tablet	12
Inadvertent activation of functions	12
Intended use	
Optional equipment	
Replacement parts	
Requirements of users	
Road travel	
Shutting down the tablet during operation	
Significance of the operator's manual	
Unauthorized operation	
Use of the tablet outside of the cab	
View of work area	12
Safety alert symbol Safety messages	10
Safety Link	
Creating	30
Deleting	
Safety messages	······································
Safety alert symbol	10
Signal word	
Safety link	
Safety link partner	
CWI, deleting in	46
Deleting in the tablet	
Seal	
CWI	19
Self-propelled machines / tractors	
Controlling	13



	2021-001
Serial number	
Identification plate	17
Settings	4.4
Changing	
LED, switching offLED, switching on	
Signal word	40
Safety messages	10
Software	
Version, displaying	18
Software update	
Tablet	57
Software version	6
CWI Setup App	
Validity of the manual	4
Specification	
CWI	
Storage temperature	27
Symbol	0.4
ButtonCWI	
Symbols	∠۱
CWI Setup App	22
In this manual	
T	
Tablet	15
Cleaning	
Connecting	
Loading software updates	
Technical specifications	
CWI	
Technical terms	61
U	
USB charge current	27
Use _	_
Foreseeable improper use	
Intended use	
V	
Validity Manual	4
Version	4
CWI	13
CWI Setup App	
Hardware	
Software	
W	
Warranty	5
Weight	
Width	
WLAN	
Connection, creating	
Creating safe data link	
Delete safe data link	
First time connection, creating	31



	2021-001
Tablet outside of reception range	55
WLAN name	
Factory setting	
Workshop	

CLAAS KGaA mbH works to improve its products continuously as part of further technical development. Therefore, we must reserve the right to revisions compared to the figures and descriptions in this manual without this resulting in any claim to modifications to already delivered machines.

Technical data, dimensions, and weights are non-binding. Subject to error.

Reproduction or translation, in whole or in part, requires the express written consent of CLAAS KGaA mbH.

All rights according to copyright law reserved. CLAAS KGaA mbH

33416 HARSEWINKEL

Germany



CLAAS protects the environment. The paper for this manual was produced from 100% total chlorine free cellulose.

CLAAS KGaA mbH Postfach 1163 33416 Harsewinkel Tel. +49 (0)5247 12-0 www.claas.com

00 0018 585 0 BA EASY on board App EN-US - 09/2016 Printed in Germany

