



Over-Ear Bluetooth Wireless Headset Casque Bluetooth sans Fil avec Oreillettes

Over-Ear Bluetooth-Funk-Headset Auricolare Senza Fili Bluetooth Over-Ear Auriculares Inalámbricos Bluetooth Circumaurales オーバーイヤー Bluetooth ヘッドセット B07LBYLM7B, B07LBX3K5F




日本語 Español Italiano Deutsch Français English

English3
Français13
Deutsch22
Italiano 31
Español40
日本語49

Welcome Guide • English

Contents:

Before getting started, ensure the package contains the following components:



IMPORTANT SAFEGUARDS



Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons including the following:

- Read all instructions.
- Only use this product for its intended use.
- This product is only suitable for use in moderate climates. Do not use it in tropic or in particularly humid climates.
- Keep the product away from sources of heat (e.g. direct sunlight), dust and water.



To prevent possible hearing damage, do not listen at high volume levels for long periods. Do not use the headphones while driving or cycling, or in any situation where you should be able to hear other sound.

Battery Warnings

▲ NOTICE Products with lithium batteries may be subject to transport restrictions. Check with your travel operator before you travel.

- The battery contained in this product is non-replaceable. Do not throw the product into a fire.
- Do not leave the battery charging for a prolonged period of time when the product is not in use.
- If the product appears to be bulging or shows other undesirable phenomena (e.g. excess noise), stop using it immediately and contact customer services.
- · Do not drop or impact this product.
- Do not cover while charging. Charge in a well-ventilated environment.
- Batteries produce heat when charging and discharging. If the product becomes too hot to touch, turn it off and unplug it immediately.
- Charge this product only with a compatible power source from reputable manufacturers e.g. a power adapter or USB port on a PC.
- Charge this product once every 3 months to avoid shortening its battery life.

Intended Use

- The product is intended for wireless or wired audio playback. The product also can be used for hands-free calling via a paired Bluetooth® device.
- This product is intended to be used in dry areas only.
- No liability will be accepted for damages resulting from improper use or non-compliance with


Before First Use

Check for transport damages.

⚠ DANGER Risk of suffocation! Keep any packaging materials away from children – these materials are a potential source of danger, e.g. suffocation.


Product Overview





- 3.5 mm audio socket
- (increase volume)
- (decrease volume)

Right earcup



- Micro USB charging port
- 6 Microphone
- On/off button
- 8 LED

Operation

Adapting and wearing

- On the inside of the headband, there are markings for left (L) and right (R) side above the earcups.
- The length of the headband can be adjusted on both sides.

LED

		<u>a</u>
LED (8)	Status	añol
Off	Off / connected	
Steady white	Battery empty / charging	
Flashing blue	Waiting for connection to a previously paired device	
Flashing white and blue	Ready for pairing	Ш
Flashing white	Waiting for connection to a previously paired device at low battery status	本語
Rapidly flashing white	Ready for pairing at low battery status	

Charging

- Connect the USB cable (C) to the micro USB charging port (5).
- Connect the other end of the USB cable to a USB power source with a minimum output current of 200 mA.
- While charging: The LED (1) lights white.
- When fully charged: The LED lights blue.

▲ NOTICE While charging, the Bluetooth® function is disabled.

Switching on/off

- On: Press and hold the on/off button (7) for 2 seconds. A signal sounds and the LED (8) starts to flash blue.
- Off: Press and hold the on/off button for 3 seconds. A signal sounds and the LED lights up white before going off.

Pairing

- Activate Bluetooth® on the device you wish to pair and search for a new device.
- While the product is off, press and hold the on/off button for 5 seconds. After the switching on signal another short signal sounds and the LED starts to flash rapidly in white and blue.
- Select "AmazonBasics Bluetooth Headphone" from the list on your device.
- Once the devices are paired, you will hear a short sound. The LED goes off.

Italiano

▲ NOTICE The headphones will automatically switch off if they are not paired within

▲ NOTICE The headset will continuously attempt to re-establish a lost Bluetooth® connection. If unsuccessful, you need to reconnect manually via the device's Bluetooth® menu.

Adjusting volume

Single-tap + / - to increase / decrease volume.

Playing music

During standby: Single-tap Single-tap again to pause/resume playback.

Español

Switch tracks

Next track: Press and hold **+**. Previous track: Press and hold -.

Answering incoming calls

Single-tap . Tap again to end the call.

Rejecting incoming calls

Press and hold .

Three-party-calls

- To end the current call and pick up the new incoming call, press and hold
- To keep the current call and pick up the new incoming call, press
 The first call is on hold.
- To switch between the call on hold and the active call, double-click
- To end the current call, press . The call on hold will become active.

Voice assistant

Double-tap > II to activate the voice assistant (e.g. Siri, S-voice etc.).

Using as wired headphones

Use the audio cable (B) to connect the 3.5 mm audio socket (1) to a mobile device or the headphone output of a sound system or TV.

NOTICE When the headphones are connected via an audio cable, the Bluetooth®-function and all buttons are disabled.

Low battery level

An indication tone sounds once per minute. Charge the headphones as described in the chapter "Charging".

Cleaning and Maintenance

A NOTICE Switch off the product and disconnect it from the power source before cleaning.

▲ NOTICE Do not immerse the product in water or other liquids. Never hold the product under running water.

Cleaning

- To clean, wipe with a soft, slightly moist cloth.Dry the product after cleaning.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to

- Store in a cool and dry place away from children and pets, ideally in original packaging.
- Avoid any vibrations and shocks.

Troubleshooting

2	
눒	
≕	
Ġ	
=	

Problem	Solution	
The product cannot be switched on.	The battery is flat. Fully charge the battery.	
No sound.	The volume is set to the minimum.	
	The wireless range (approx. 10 m) has been exceeded.	
	The device is no longer paired. Repeat the pairing process.	
There are drop outs in playback.	The wireless range (approx. 10 m) has been exceeded.	
	Other devices are interfering with radio transmission. Move away from other wireless devices or devices that may cause high interference (e.g. powerful electric motors, fluorescent lamps and microwaves).	



FCC – Supplier's Declaration of Conformity

Unique Identifier	B07LBYLM7B, B07LBX3K5F - Over-Ear Bluetooth Wireless Headset
Responsible Party	Amazon.com Services, Inc
U.S. Contact Information	410 Terry Ave N. Seattle, WA 98109, United States
Telephone Number	(206) 266-1000

FCC Compliance Statement

- This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
 - (1) this device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Canada IC Notice

- This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:
 - (1) this device may not cause interference, and
 - (2) this device must accept any interference, including interference that may cause undesired operation of the device.
- This Class B digital apparatus complies with Canadian CAN ICES-3(B) / NMB-3(B) standard.

rançais

Trademarks

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and anv use of such marks by Amazon.com, Inc. or its affiliates is under license.

100100

Bluetooth°

Simplified EU Declaration of Conformity

- Hereby, Amazon EU Sarl declares that the radio equipment type B07LBYLM7B, B07LBX3K5F is in compliance with Directive 2014/53/EU.
- The full text of the EU declaration of conformity is available at the following internet address: https://www.amazon.co.uk/amazon_private_brand_EU_compliance

Italiano

Disposal



The Waste Electrical and Electronic Equipment (WEEE) Directive aims to minimize the impact of electrical and electronic goods on the environment, by increasing re-use and recycling and by reducing the amount of WEEE going to landfill. The symbol on this product or its packaging signifies that this product must be disposed separately from ordinary household wastes at its end of life. Be aware that this is your responsibility to dispose of electronic equipment at recycling centers in order to conserve natural resources. Each country should have its collection centers for electrical and electronic equipment recycling. For information about your recycling drop off area, please contact your related electrical and electronic equipment waste management authority, your local city office, or your house hold waste disposal service.

Es



Battery Disposal

Do not dispose of used batteries with your household waste. Take them to an appropriate disposal/collection site.

Specifications

Rated input:	5 V
Battery type:	Li-lon, 3.7 V, 240 mAh
Charging time:	<3 h
Operation time:	11 h
Standby time:	76 h
Radio frequency:	2.402 – 2.480 GHz
Transmitting power:	2.5 mW
Wireless range:	max. 32.8 ft (10 m)
Sensitivity:	118 dB
Impedance:	32 Ohm
Frequency range:	20 Hz – 20 kHz
Net weight:	approx. 9.84 oz (279 g