# Clip Mini Bluetooth® Speaker

Instruction Manual XO-9401



- Power Button · Micro-USB Charging Port
- LED Indicator
- · Mic (speaker base)

#### What's included:

1 x Mini Speaker

- 1 x USB to Micro-USB charging cable
- 1 x Carrying Strap
- 1 x Instruction Manual

## **Tech Specifications**

- Input: DC 5V/500mA
- Product Dimensions: 35\*35 \*35 mm
- · Paring name: mini SPEAKER
- Bluetooth version: 4.2 · output power: 5.5dBm
- Frequency response:2.4-2.48G
- · Battery type: Li-Polymer
- Battery Capacity:200MAH

### Instructions:

- 1. Charging the speaker:
- a Using a regulated USB adapter. Connect a USB cable to a USB adapter. Using the Micro-USB connector, connect the other end of the USB cable to the charging port on the speaker. Plug the USB adapter into the outlet to begin charging.

### Instructions (continued):

- b. Using your computer. Connect a USB cable to a USB outlet on your computer. Using the Micro-USB connector, connect the other end of the USB cable to an charging port on the speaker. Make sure the computer is on to begin charging the speaker.
- 2. Connecting a Media Device:
- a. Press and hold the Power Button for approx. 2 seconds to turn speaker ON/OFF.
- b. The Blue LED Indicator will flash to indicate pairing mode.
- c. Select "Mini Speaker" on your media device.

### 3. Power Button Function:

- a Audio volume and track selection can be
- made by using the media source device. b. Single, short press the power button to play/ nause audio.

# 4. When receiving an incoming call:

- a. Single, short press the power button to answer an incoming call.
- b. Single press again to hang up. c. Use the mic located on the speaker base
- during a call.

### SAFETY PRECAUTIONS:

- · WARNING-When using this product, basic precautions should always be followed, including the following:
- 1. Read all the instructions before using the product.
- 2. Charge the speaker completely before initial use to ensure longevity.
- 3. If the device does not respond once it is powered on, the battery capacity may be low.
- 4. Do not over charge the internal battery.

### SAFETY PRECAUTIONS (continued):

- 5. Do not immerse in water or expose to moisture or damp weather conditions.
- 6. Do not drop, knock, or shake. Rough handling can damage the internal precision component and its boards.
- 7. Do not insert any objects into the speaker/
- 8. Keep away from children. Device is not a toy.
- 9. Keep away from fire or other sources of heat. Exposure to high temperatures may cause it to explode.
- 10. Do not short-circuit as this may cause damage to the unit.
- 11. Do not pull the charging cable or over-extend it's reach.
- 12. Unauthorized changes or modifications may void your right to use this product.
- 13. While using, always comply with any special regulations that may apply to the area you are in and always turn off your mobile device when its use is prohibited.

### FCC Statement:

- This device complies with Part 15 of the ECC. Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

# ★ Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement.

