TheSteakAger is a WIFI enabled device and can operate in either of two modes:

# Your SteakAger does <u>NOT</u> have a display, the WiFi chip acts as a display interface to ANY WiFi enabled device.

- A. **Direct Connect Mode:** Your WiFi enabled device (Smartphone/iPad/Laptop) connects to the SteakAger and you get the status to your device. Your device needs to be within range of SteakAger WiFi Signal.
- B. **Internet Connect Mode:** The SteakAger connects to your home WiFi to get access of Internet. You get status from the Internet via our server, so you can check your SteakAger status from anywhere in the world. The SteakAger should be within your home WiFi coverage area.

•0000 429-01 ❤

Settings

Wi-Fi

TheSteakAger

CHOOSE A NETWORK

private

### **Steps for Direct Connect Mode:**

- Power up the SteakAger outside of your refrigerator.
- Wait until the SteakAger LED (underneath the control panel) flashes Yellow 10 times to indicate it is ready for 'Direct Connect Mode'. It takes maximum 45 seconds.
- Use your WiFi enabled device (Smartphone/iPad/Laptop) to search for WiFi signal coming from the SteakAger.
- 4. Choose the SSID "TheSteakAger" as your WiFi source and connect to it with the password "ilovesteak".
- 5. Open up a Web-browser.

Ask to Join Networks

Known networks will be joined automatically. If no known networks are available, you will have to manually select a network.

Drowser address bar and you are Direct

11:32 PM

Wi-Fi

@ 1 0 76% D

**a** ≈ (i)

- 6. Put "<a href="http://thesteakager.com">http://thesteakager.com</a>" into the web browser address bar and you are Direct Connected to the SteakAger Status Page where you can see the temperature and humidity.
- 7. You CAN NOT have <a href="https://thesteakager.com">https://thesteakager.com</a> it will NOT connect.
- 8. Bookmark <a href="http://thesteakager.com">http://thesteakager.com</a> address and thats all you need to do if you don't have a WiFi modem. Just look for the "TheSteakAger" WiFi SSID anytime you want to check in.

#### Note:

The SteakAger flashes Yellow 10 times on every power up. This indicates, the SteakAger is ready for Direct Connect using your WiFi device. If you do not connect your WiFi device to your SteakAger within 5 minutes then it goes to power saving disabling WiFi signal for 30 seconds. Again, it awakens after 30 seconds and keeps repeating this ON/OFF of WiFi signal. However, if you connected within 30 seconds of awakening then it keeps WiFi signal for another 5 minutes.

## **To Connect Your SteakAger to the Internet:**

1. Tap "Connect My SteakAger to the Internet" button from the Direct Connect SteakAger Status Page (shown beside).



- Your Steakager will search for all available WiFi signals.
- Find your home WiFi signal and connect to it.
- Enter your WiFi password if you have one.
- Enter your Email Address.



Tap the "Connect" button and wait for 10 blue blinks. Unplug your SteakAger and replug it.

Then reconnect your WiFi device to your home WiFi network. Wait for SteakAger registration confirmation email from us. and click the LOGIN button on that email.

If either the password is incorrect or you are out of range from the signal it will flash Red 10 times and go back to direct connect mode. From here you MUST start over from the beginning by finding the SteakAger WiFi and direct connecting to it.

Now you can check in on your SteakAger from anywhere on Earth with an internet connection. To check in:

- 1. Go to <a href="https://www.TheSteakAger.com">https://www.TheSteakAger.com</a>
- 2. Tap on the "MYSTEAKAGER" button on the home page

ABOUT / ASSEMBLY / BLOG / REVIEWS / HOW TO VIDEOS / FORUM / CONTACT US MYSTEAKAGER CART

- 3. Enter your email and SteakAger password and you will be taken to your SteakAger Status Page.
- 4. Bookmark us and that's it!

#### **LED Indicators:**

A continuous soft white light = Indicates power is ON

A single Blue Flash = Status sent to web-server.

A single Yellow Flash = SteakAger is in Direct Connect Mode.

A single Red Flash = SteakAger failed sending status to web-server.

At power up, LED pulses yellow 10 times to indicate Direct Connect Mode. The LED will pulses blue 10 times to indicate Internet Connect Mode.

If you do not have a wifi signal where your SteakAger is located you will have to stay in Direct Connect Mode to check your Status Page. If SteakAger is unable to find your home WiFi signal or Internet is not available then it automatically goes back to Direct Connect Mode and keeps checking internet availability, if available then it again locks to Internet Connect Mode.

## **Warning Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.