


PRODUCT MANUAL

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmfu / interference & (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: changes or modifications not expressly approved which could void the user's authority to operate this equipment.



Party PUG bluetooth speaker Modell: 74769 Voltage: 5VDC FCC-ID: 2AM7T-CB-D01 GOOD EVER TRADING LIMITED

SPECIFICATIONS:

Maximum Output: 3W S/N ratio: >80db Frequency Range: 20Hz-20 KHz Battery Voltage: 3.7V DC Distortion THD: <1% Nominal Voltage: 3.7V DC Battery: Built-In Lithium Battery, 3V DC/300mAh

Charge Voltage/Current: 5V +0.25V/1A Working Time: 2-3 hours (depending on volume)

BLUETOOTH® PAIRING:

- Press and hold the power button to turn ON the speaker until the LED flashes blue. It is ready to pair.
- Place the speaker and Bluetooth® device so that they are no further than 6 feet apart.
- Activate the Bluetooth® fnuictno on your device. Please re efr to the manufacturer's instruction manual to enable Bluetooth® on your
- Select the speaker "Party Pug Speaker" from the list of available devices.

BLUETOOTH® PAIRING:

- 5, If required, enter the password "0000",
- Once paired successfully, you will hear the confirmation of indication tone.
- 7. If pairing is unsuccessful, turn OFF the speaker and then repeat the previous steps.
- Once you have paired the speaker with device, the speaker will remember this device and will pair automatically when the device's Bluetooth® is activated within range.

FUNCTIONS:

The Speaker includes a built-in rechargeable The Speaker includes a built-in rechargeable battery. It is recommended to charge the battery fully prior to first use. Connect the USB cable to a USB charging source and the mini USB plug into the charging port of the speaker. The LED indicator turns RED and turns OFF once charging is completed.

FUNCTIONS:

The ON/OFF button is used to turn the speaker ON/OFF, play, pause music. It can also be used to answer and end phone calls.

IMPORTANT NOTES:

*This product is not a toy.

*Do not drop or damage the speaker.

*Do not use in humid or extreme temperatures. *Do not place the speaker near an open flame.

*Do not block the sound of the speaker while it is in

*Do not use the unit if it has been dropped or

*If damaged, do not attempt to repair or disassemble the speaker.

FCC STATEMENT

1. The device complex with Part 15 of the FCC Plates. Operation is subject to the following complex or control territories or control territories or control territories or control territories. On the following control control territories or control territories or control territories.

2. Changes or modification not expensibly approved by the party responsible for complication of control control territories.

connected.

— Consult the dealer or an experienced radio/ TV technician for help.