# 1. Nexto-CF Multi1 Introduction

- Nexto-CF Multi1 (Nexto-M1) backs up data from widely used memory card such as CF, MD, SD, SDHC, MS, MMC Memory Stick or MMS into its internal HDD with the fastest back up speed yet.

- Nexto-M1 is integrated with patent technology known as X-Copy and optimized algorithm for back up known as Ultra-X. So the back up speed of Nexto-M1 is more than 6 times faster than conventional devices.

- Nexto-M1 is also integrated with OTG technology so that you can connect USB devices directly to Nexto-M1 without aid of PC. So you can even connect your digital camera directly to Nexto-M1 for back up.

- With current method, CPU reads data from memory card and then stores the data in internal memory of CPU. Then CPU reads data from its own internal memory to write the data into HDD

Pic 1-1

- However, with X-Copy technology, CPU reads data while writing them into HDD at the same time. So the speed of read°Êwirte process in in dependent of internal memory of CPU(both size and speed) hence result is much faster backup speed

Pic 1-2

2. Thing to Remember Before Using Nexto-M1

The Features

- Nexto-M1 can back up data from CF, MD, SD, SDHC, MemoryStick or MMC into HDD. The back up speed is fastest in the world so far. (With help of OTG feature you can back up data from any kind of memory cards)
- With maximum speed of 20MB/sec and average speed of 14MB/sec, it only takes about 1 minute for Nexto-M1 to back up 1G bytes of data.
- Nexto-M1 has verification feature that you can double check the integrity of your data.
- You can install large sized HDD into Nexto-M1. Most of legacy devices can only manage HDD size less than 120G, but you can install maximum of 2000G bytes HDD into Nexto-M1.

Things to be careful

- For Nexto-M1 to work properly, 2.5" PATA type HDD must be installed. Without HDD, Nexto-M1 will not work properly.
  (※ Nexto-M1 doesn't match with SATA type HDD
- HDD is fragile to magnetic field and impact. So be careful not to drop Nexto-M1 or place it near magnetic devices such as TV, radio or speaker. The company will not be responsible for loss of data stored in HDD under any conditions.
- Nexto-M1 has many slots for variety of cables and memory card. Do not let dust or foreign objects get into those slots.
- Nexto-M1 has internal slots for CF, MD, SD, SDHC, MemoryStick and MMC memory cards. However you can back up other kinds of memory cards with USB card readers using OTG feature of Nexto-M1.

3. Contents and Part Name

Contents

Nexto-M1, USB Cable, Power DC Adapter, Pouch, Screw Driver and Screws, User Manual

USB 케이블

파우치

아답터

본체

설명서

조립용 나사,
조립용 십자 드라이버

Optional Items

External Battery   Leather Case

● 외장 배터리   ● 가죽 케이스

Part Name

CF/MD Card 슬롯

CF / MD

NE**X**TO DI

SD 카드 슬롯

지시등
스위치

COPY

158.4G

X-Copy Ready

S Meun L Off

LCD 화면

NEXTO OTG
ND-2300

BAT PC OTG DC IN

외부전원잭(배터리)

외부전원잭(아답터)

리셋 스위치

PC USB
연결단자

주변기기 연결단자

4. HDD Installation

Nexto-M1 requires 2.5" laptop HDD to work properly. However, Nexto-M1 does not support SATA type HDD. To install HDD into Nexto-M1;

	Remove lower aluminum case of Nexto-M1
	Connect HDD to 50-pin connector. Align the pins on PCB with connector on HDD and insert gently. Make sure all the pins are firmly inserted and place insulator between PCB and HDD.
	Replace the lower case and screw it to the main frame.

5. Button and LCD Screen

Turn On and Off

Nexto-M1 is single button operating device. You can control all the features with the button.

To turn on Nexto-M1, press the button for more than 2 seconds. Nexto-M1 will turn itself off 30 seconds after the last button press.

To turn off Nexto-M1 when error occurs, press the reset button at the bottom of Nexto-M1 with sharp object such as screw driver in Nexto-M1's package.

Button Operation

There are 3 ways to control the button.

Screen Display	Operation Method
S	Press the button once like mouse click. ('Short')
L	Press down the button for more than a second. ('Long')
D	Click the button twice like mouse double click. ('Double Click')

LCD Screen Display

On LCD screen of Nexto-M1 shows status commands and how to execute the commands as well as the status of the device.

158.4G 🔋 X-Copy Ready S Meun L Off Ꮝ✕	Internal battery status and remain HDD capacity is displayed at the top of the screen. Current status of commands to confirm is displayed at the middle of the screen., The ways to execute command are displayed at the bottom of the screen.

More details on operating Nexto-M1 will be explained in later chapters.

6. Data Backup

The basic function of Nexto-M1 is to backup data from memory card to HDD. Executing the function is easy and is done through the single button.

Nexto-M1 has built-in slot for CF, MD, SD, SDHC, MemoryStick and MMC card. Or you can use USB card readers to back up data from other kinds of memory cards. Refer to chapter 11 for more information on USB card reader connection.

[Caution] For MS Duo, MS Duo MagicGate, MS Pro Duo, or MS Pro Duo MagicGate use the MemoryStick transform adapter. Do not insert these cards into Nexto-M1 directly. Also use SD card transform adapter for mini SD, TransFlash, MMC mobile or RSMMC.

To backup data;

COPY 158.4G ▪▪▪ X-Copy Ready S Meun L Off Sx	Turn on Nexto-M1. (You can insert memory card before turn on Nexto-M1) If screen displays other messages than the screen shown here, refer to "Error Messages" at the end of this chapter.
CF 카드 COPY 158.4G ▪▪▪ X-Copy Ready S Meun L Off Sx SD 카드 Nexto M1	Insert memory card. For CF or Md use the slot at the top and for SD, SDHC, MemoryStick or MMC use the slot at the side. If you insert 2 cards at the same time, Nexto-M1 will only back up from the card inserted first. [Caution] If any device or cable is connected to USB connector at the bottom the backup process will not work properly so remove any device of cable from the USB connector before inserting the cards.

 9.3G ▪▪ **Cpy or Move** 0/ 10 **S** Cpy **L** Move ⚡	"CF Detected" or "Mem Detected" will be displayed on the screen depend on the card you inserted. There are 2 ways you can backup. ● Copy: With copy method, Nexto-M1 only copies data from memory card to HDD. So all the data in memory card remains. ● Move: With move method, Nexto-M1 copies data from memory card to HDD and verifies the integrity then deletes all data in memory card. If however verification fails, Nexto-M1 will not delete the data in memory card. As seen at the bottom of the screen; ● Press the button once for copy. ● Press down the button for more than 1 second for move The number on the screen indicates the number of files to be copied and number of files copied to HDD.
9.3G ▪▪ **C** CF → HDD 1/10 **L** Cancel ⚡	As the backup proceeds, the number of files copied is displayed on the screen. During the process you can press down the button to cancel the job as indicated at the bottom of the screen.
9.3G ▪▪ Copy Done! 10 sec Remove CF ⚡	The total time for the backup is displayed when backup is completed. Remove the memory card to end the process. Even if you do not remove the card, Nexto-M1 will turn itself off after 15 seconds.

Other Features

When backup is completed, if you do not remove the card for next 15 seconds, Nexto-M1 will turn itself off.

In this case when you turn on Nexto-M1 next time, it will show you the result of last process.

9.3G 🔋 **Prev Copy** **Success** 🆂 Continue ⑆	This message tells you the last backup process was successful. Press the button once to go back to the initial state.
9.3G 🔋 **Prev Copy** **Fail** 🆂 Continue ⑆	This message tells you the last backup process was failure. Backup the same card again or check for other possible reason for failure such as shortage of power.

Error Messages

Nexto-M1 may display other messages than explained above.

⑆	If nothing comes on the screen, check the battery status. Refer to chapter 8 for power management.

🔋
 	
X-Copy Not
Available
 	
🄻 P_OFF
 	
⑆
	If you see the message shown on the picture you will need to;
	
	  1. Install HDD. Refer to chapter 2 for installing HDD.
	  2. Format the HDD. Refer to chapter 10 for formatting HDD.

Disc Format **Error** 🆂 Continue 🄻 Format ⑆	If you see the message show on the picture, you need to format the HDD. Refer to chapter 10 for more information on HDD format.

|	
9.3G **Same CF** **Verify?** S vfy L more	This is not the error message. This message tells you that same data is already backed up. Refer to chapter 9 for verification of backup data.

7. Connecting to PC

Nexto-M1 can be connected to PC through USB connection.

- **There are 2 USB ports at the bottom of Nexto-M1. When connecting to PC use the USB connector of Nexto-M1 marked "PC" which is smaller USB port.**
- Use USB port at the back of PC when connecting Nexto-M1. Sometimes the PC will not recognize Nexto-M1 when USB port at the front of PC is used.
- Nexto-M1 will not work as card reader when connected to PC.

	Use the USB cable to connect Nexto-M1 to PC. Windows 2000, XP or Vista will recognize Nexto-M1 without extra device driver. However you will need driver in Windows 98 which you can download from www.nextodi.com.

| |
|---|
| |
| Open MyComputer folder after connecting Nexto-M1 to the PC. You will see new driver added.

Nexto-M1 will be name NEXTODI in the MyComputer folder. |

Nexto-M1 will copy the exact structure and files from the memory card inserted.

Every time you backup data, a new folder is created under NEXTOM1 folder. The new folder will have name like YYYYMMDD.XXX. Nexto-M1 checks the files and extracts the latest creation date among the files and use to name the folder. The 3 letters of suffix is version number of the folder in case same date comes up more than once among the backup files.

For example, if the latest file creation date is 2007-10-25 then new folder 200071025.000 is created for backup.

[Caution] Every time you backup, even for the very same data more than once, new folder is created and no data is over written.

When backup fail.

When Nexto-M1 fails backup data properly, Tmp folder is created. In the Tmp folder, it appears all the files are backed up properly, however the files in the Tmp folder are garbage. So you will need to back up again.

8. Battery Recharge and Power Management

Battery Recharge

To recharge internal or external battery of Nexto-M1;

- Connect DC adapter to Nexto-M1. To recharge external battery, connect the battery to Nexto-M1 and connect DC adapter to the device. It takes 4 hours for internal battery and 5 hours for external battery to be fully recharged.
- Connect Nexto-M1 to PC through USB connection. Internal and external batteries will be recharged simultaneously. Remember to turn off Nexto-M1 for recharging.

The red light in right side of the button will lit while recharging. When battery is fully recharged, the light will be turned off.

You can backup up to 60G bytes with fully charged battery and 140G bytes with external battery.

Power Management

When Nexto-M1 is connected to PC through USB connection, Nexto-M1 will only use the power from USB bus not from internal or external battery.

9. Verification of Backup Data

You can compare data in the memory card and data in the HDD to verify safe backup.

9.3G (battery icon) **Same CF** **Verify?** **S** vfy **L** more	If you insert the same card after backup, Nexto-M1 will show message shown in the picture. Press the button once to choose "vfy" to verify the data or if you want to backup same data once more press down the button to choose "more" command. Here, press the button once to verify the data.
9.3G (battery icon) **Select Mode** **L** Sampling **S** Full	There are 2 types of verification. Press the button once for Sampling Verification or press down the button for Full Verification. With full verification, Nexto-M1 compares every bit of original data and backup data, so it takes longer time to verify. With sampling verification, Nexto-M1 compares only sampled bits, so it takes less time to verify.
9.3G (battery icon) **V** CF → HDD 1/10 **L** Cancel	Once verification starts, you will see the number of verified files and number of to be verified files.
9.3G (battery icon) **Verify Done !** 10 sec Remove CF	When done, you will see the message shown in the picture. Remove the memory card to end the process.

Backup the same card more than once.

When you insert the same card more than once, you can choose to backup the same data again.

Even if you back up the same data, Nexto-M1 will not overwrite the existing data, instead it creates new folder and backup the data in the new folder.

 9.3G Same CF Verify? S vfy L more	Insert the same memory card, here press down the button to choose "more" command.
9.3G Same CF Copy Again? S cpy L Exit	Here you can backup the same card once more. However you can only choose "copy" method. "move" method is the option in this process. You can always go back to initial screen by press down the button for more than a second.
9.3G C CF → HDD 1/10 L Cancel	You can see the number of files copied and number of files to be copied.

When you backup the same data more than once, Nexto-M1 creates new folder every time. First it

creates folder named 20070421.000 then 20070421.001 and so on.

So existing data remains in the different folder.

10. HDD Format

Nexto-M1 has format function so you do not need PC to format the HDD installed in Nexto-M1.

[Caution] All the data in HDD will be erased after formatting the HDD. Remember to back up important data to some other media before formatting your HDD.

Formatting New HDD
When you install brand new HDD to Nexto-M1, you must first format the HDD.

Nexto-M1 does not support partitioning of HDD, so if you need to create partitions connect Nexto-M1 to PC and do it in Windows environment.

Nexto-M1 formats HDD in FAT32 file system. For more information on file systems please refer to OS guide books or web sites.

|	
Disc Format Error S Continue L Format	Install HDD into Nexto-M1 (refer to chapter 2 for installing HDD) and turn on the power and you will see the message as shown in the picture. Press down the button to choose "Format" command. If you choose "Continue" menu, Nexo-M1 will display error message.
20061009.000 Delete dir ? Lose date ? S No L Yes	Nexto-M1 will ask you twice for confirmation. Press down the button to choose "Yes" command. This will be the first confirmation.
9.3G Confirm HDD Format S Exit L OK	Press down the button for second and final confirmation to proceed formatting. Press down the button to choose "Yes" command and format will proceed.

 158.4G 🔋 **X-Copy Ready** ⧉ Meun ⧉ Off ⚡	When format is completed, Nexto-M1 will display the initial screen.

Formatting HDD in Use

You can format the HDD in use. All the data in the HDD will be erased after formatting so be careful not to lose important data.

Even you have partitions in your HDD Nexto-M1 will format the HDD as single partition in FAT32 file system.

 158.4G 🔋 **X-Copy Ready** ⧉ Meun ⧉ Off ⚡	Turn on Nexto-M1 and at the initial screen press the button to choose "Menu" command.
 * **Exit** **Browse** **Format** ⧉ Next ⧉ Sel ⚡	At the menu screen you can choose one of three menus displayed. Move the cursor (*) by press the button and place it next to "Format" command then press down the button. You can always go back to initial screen by choosing "Exit" menu.
 9.3G 🔋 **Format HDD&** **loose data?** ⧉ No ⧉ Yes ⚡	Again Nexto-M1 will ask you for confirmation twice before proceed to format. Select "Yes" command by pressing down the button.

9.3G 🔋 **Confirm HDD Format** **S** Exit **L** OK ℭ✕	This is second and last confirmation. Press down the button to choose "Yes" command.
158.4G 🔋 **X-Copy Ready** **S** Meun **L** Off ℭ✕	After formatting, Nexto-M1 will display the initial screen.

Partition and File Systems

The file system and portioning is somewhat too technical for some users. So if you do not have the proper knowledge on the subjects use the format function of Nexto-M1 to set up the HDD.

Nexto-M1 will only use HDD formatted in FAT32 file system. If you have more than one partition in your HDD, Nexto-M1 will backup data in the first partition formatted in FAT32 file system.

If no partition is formatted in FAT 32 file system, Nexto-M1 will try to format entire HDD in FAT32 file system and you may lose all data in the HDD. So check the file system and partition before installing used HDD into Nexto-M1.

11. Connecting USB Devices

Nexto-M1 has OTG feature that you can connect USB devices such as card reader, USB storage or digital camera directly to Nexto-M1.

[Caution] Not all USB devices can be connected to Nexto-M1. Nexto-M1 may not support devices that consume more power than Nexto-M1 can supply. And Nexto-M1 does not support MP3 Player.

	Turn on Nexto-M1 and connect USB device to the USB port at the bottom of Nexto-M1 marked "OTG" using USB cable.
	Nexto-M1 automatically detects the USB device. You can copy data from/to USB devices or delete data in USB devices. Refer to chapter 12 for more information. If the USB device consumes more power than Nexto-M1 can supply or USB device that does not support common USB protocols Nexto-M1 will turn itself off.
	You can copy data from USB device the same way as you copy data from memory card.

12. Browsing HDD and Memory Cards

You can check the store data in HDD of Nexto-M1 without connecting to PC. You can even browse through the data in connected memory card or storage of USB devices.

You can also copy file or folder to/from HDD from/to memory card or USB devices and delete file or folder in HDD or memory card.

Browse or delete file/folder in HDD or Memory Card

158.4G X-Copy Ready S Meun L Off	At the initial screen press down the button to choose "Menu" command. At this time no memory card or USB device should be connected to Nexto-M1
* Exit Browse Format S Next L Sel	Move the cursor (*) by pressing button next to "Browse" command and press down the button for more than 1 second.
Exit * HDD CF/USB S Next L Sel	On next screen move the cursor next to HDD and press down the button to choose "HDD" command.
9.3G [c:\] Info 2 Dirs 10 Files 190 KBytes S Continue	Nexto-M1 shows you the summary information of root directory of HDD. As shown in the picture, the root directory has 10 files total size of 190Ksbytes and 2 folders. Press button once to continue.
HDD 9.3G [C:/] EXIT ├ [NEXTODI] └ [My Folder] S Next D Prev L Sel	Next, you can see the actual structures of folders and files in root directory of HDD. To move the cursor; ● [S]: Press the button once to move the cursor down. ● [D]: Double click the button to move the cursor up. [L]: Press down the button for more than one second to select the file or folder. Move the cursor to NESXODI folder and select it by pressing down the button.

| ```
9.3G  [battery]
[NEXTODI] Info
21    Dirs
5    Files
256 KBytes
  S Continue
       ✂
``` | When you select a folder, first you can see the summary information of the folder.<br><br>When you select a file you will first see the summary of the file. |
| ```
HDD 9.3G  [battery]
[ NEXTODI]        EXIT
├                Copy
├                 Del
├─[...]
└─[20060325.000]
 S Next  D Prev  L Sel
       ✂
``` | At the top of the screen there are 3 menus you can choose from; "Exit", "Copy" and "Del"<br><br>● "Exit": Go back to initial screen.<br>● "Copy" Copy the file or entire folder, sub structure and files in the folders to memory card or connected USB device.<br>● "Del": Delete the selected file or folder and entire sub hierarchy folders and files<br><br>[Caution] Be careful when you choose delete a folder. It deletes not only the selected folder but also all sub folders in the selected folder. |
| ```
HDD 9.3G  [battery]
[ NEXTODI]        EXIT
├                Copy
├                 Del
├─[...]
└─[20060325.000]
 S Next  D Prev  L Sel
       ✂
``` | You can browse through sub folder by moving the cursor to the folder you wish to browse and press down the button to select.<br><br>Choose one of the menus to copy or delete the folder.<br><br>You can also select a file to copy or delete. |
| ```
HDD 73.4G
[myimage.jpg]
4.86 MBytes
Delete?
 S Cancel L Yes
       ✂
``` | When you select delete menu, Nexto-M1 ask you twice for confirmation.<br><br>Press down the button to select "Yes" command to delete the selected folder. |
| ```
HDD 73.4G
[myimage.jpg]
Copy to CF
     or USB
 S Cancel L Yes
       ✂
``` | If you choose to copy a folder or a file, Nexto-M1 will ask you to insert memory card of connect USB device.<br><br>You can then browse through memory card of USB device in the same way as browsing HDD to choose the destination folder to copy the data from HDD.<br><br>Press down the button to select "Yes" command to copy the file or folder. |

Browse or delete file/folder in HDD or Memory Card

Exit **HDD** *** CF/USB** S Next L Sel	You can browse through memory card or connected USB device the same way as browsing through HDD. Select "CF/USB" command at the menu screen. Remember you should not insert memory card or connect USB device before Nexto-M1 asks to do so.
Insert CF or **Connect USB** L Cancel	Insert memory card or connect USB device when Nexto-M1 asks to do so.
9.3G [c:\] Info 2 Dirs 10 Files 190 KBytes S Continue	Nexto steps will be same as browsing HDD. But when you choose to copy, the data will be transferred into HDD from memory card or USB device.

13. Sync

You can sync data between two Nexto series devices. It is useful when you deal with important photo data.

The professionals may want carry two Nexto devices to ensure the safety of their data.

You can sync data between Nexto-M1 and;

- Nexto-M1
- Nexto-Ultra
- Nexto-OTG And Nexto Xpress
- Nexto-CF

Nexto-M1   Nexto-XX

Connect Nexto-M1 to Nexto-XXX using USB cable. Remember use the port marked "OTG" on Nexto-M1 and "PC" on Nexto-XXX.

Connect DC adapter to the Nexto-XXX (the target)

Nexto-M1 will search the target for folder named "NEXTODI" and compare the data with its own and

copies new data from the target.	
9.3G USB Detected [L] Cancel	When target is connected to Nexto-M1, it automatically detects the target and search through data to compare. It may take some time depend on the size of target's data.
Sync Nexto? [S] No [L] Yes	Press down the button to sync. The number of files to be copied and number of files copied will be displayed on the screen during the process.

14. Specification

Memory Card	CF/MD Slot	CF Type 1/2, MD (MicroDrive)
	SD/MS/MMC Slot	SD / SDHC / MMC /MMC Plus / MS / MS MagicGate / MS Pro / MS Pro MagicGate ※ Use SD transform adapter for mini SD / TransFlash / MMC mobile /RSMMC ※ Use MemoryStick transform adapter for MS Duo / MS Duo MagicGate / MS Pro Duo / MS Pro Duo MagicGate
	OTG Port	Digital Camera, HDD type camcoder ※ Some products may not be compatible.
Power	Rechargeable internal battery / Rechargeable external battery (Option) DC Adapter (5V DC, 2A) / BUS Power from USB	
Battery / Backup Capacity	Internal battery : Li-Poly (3.7V, 1550mAh, 60GG Backup capable) External battery : Li-Ion (3.7V, 2200mAh, 80GB backup capable, Option)	
Compatible HDD	2.5" PATA Type HDD Big volume HDD(more than 128GB) support	
Interface	USB 2.0/1.1 (USB Slave), OTG (USB Host) Interface	
Backup Speed	By CF Slot : MAX 20MB/s, Sustained 14MB/s By SD/SDHC/MS/MMC Slot : MAX 24MB/s, Sustained 19MB/s	
Compatible OS	WINDOW 98SE/Me/2000/XP/Vista Mac OS 9.2 or above, Linux 2.4.18 or above	
Files System	HDD: FAT32 Memory Card: FAT12/16/32	
Dimension	128mm x 77mm x 23mm (D x W x H)	
Weight	130g (without HDD)	
Accessories	USB Cable / Power DC Adapter / Pouch / Screw Driver / Screws / User Manual	

15. Error Codes

The common error messages are;

Error Code	Error Name	Symptom and Solution
0x0001	ERR_FAIL	Low level error. HDD failure or USB communication failure
0x000E	ERR_UNEXPECTED	USB communication failure. Check the cable.
0x0015	ERR_INVALID_FAT	Format error. Reformat the memory card.
0x003B	ERR_UNEXPECTED_ZERO	FAT error
0x0051	ERR_12_NOT_IMPL	Unable to write to FAT12 Memory.
0x0063	ERR_CLUSTER_CHAIN	FAT error
0x0080	ERR_NO_FREE_CLUSTER	No more space in HDD
0x00A0	ERR_BUSY_TOO_LONG	ATA I/F error, possible HDD error.
0x00A4	ERR_READ	ATA I/F error, possible HDD error.
0x00A5	ERR_IDE_ERR	ATA I/F error, possible HDD error.

Nexto-CF Multi1 User Manual Index

FCC NOTE

:This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which
   the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.

OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND

(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED,

INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.