www.glo-e.com

For Questions and Comments please call: 1 800 225 9319

Complies with

Standard

WARNING:

All rubber bands and wire ties, as well as tags, are not parts of this toy, and should be discarded for your child's safety. Colors and contents may vary from those shown on package.





© 2005 Cepia LLC. Saint Louis Missouri 63124 Made in China U.S. and foreign patents pending







274 mm

glo-e® MAGIC WAND

TO OPERATE THE PLUSH

TURN ON THE PLUSH, REMOVE THE BATTERY CASE FROM THE BATTERY POUCH. SLIDE THE ON/OFF SWITCH TO THE ON POSITION. REINSERT THE BATTERY BOX INTO THE POUCH.





FOR CLEANING: SPOT CLEAN ONLY

MAGICALLY TURN ON THE PLUSH AND SWITCH FROM LIGHT SHOW TO LIGHT SHOW WITH EACH PUSH OF THE BUTTON. AFTER THE SHOW THE PLUSH WILL TURN OFF.
THE LIGHT IN THE WAND WILL TURN OFF

www.glo-e.com

Printed in China

AFTER A FEW SECONDS.

BATTERY INFORMATION

TO REPLACE THE BATTERIES, REMOVE THE SMALL SCREW FROM THE BACK OF THE WAND. REMOVE THE END CAP. REPLACE THE BATTERIES WITH 2 FRESH CR2032 BATTERIES.







Always replace used batteries with fresh Lithium batteries. Do not mix old batteries with new, do not mix Alkaline with standard carbonzinc or rechargeable nickel cadmium batteries. This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. To comply with the FCC RF exposure compliance requirements, this device and its antenna must not be co-located or operating to conjunction with any other antenna or transmitter.





© 2005 Cepia LLC. Saint Louis Missouri 63124 U.S. and foreign patents pending