The CatCaller **Transmitter**


FRONT BACK






DIMENSIONS: (WITHOUT OPTION HOOK) 1.825"W x 1.9"H x .52"D


Instructions





Ideal for locating your favorite lost pet in your home, garage, yard or neighborhood. The wireless transmitter works through walls, closets, under beds and all those places they like Red "ALL CALL" button calls all receivers at once.





Cat Caller Key Chain Transmitter: Insert screwdriver into back stot and carefully remove the back cover. With screwdriver slide and carefully remove the back cover. With screwdriver slide and buckle ring. Slide the old battery out of the battery holder as shown.

Transmitter requires one Lithium CR2032 3V battery. Be sure to insert the battery so the positive (+) side faces up. Holding the key chain in place, replace cover and snap together.

Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Remove batteries when not in use or discharged.

The Cat Caller. Distributed by ElectroStar®, a division of Buztronics, Inc. ©2010 Indianapolis, Indiana 46268

MADE IN CHINA

Declaration Of Conformity: This device complies with part 15 of the FCC Rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.







DIMENSIONS: 4"W x 3"H