PREPARATION For ages 3+
Twist dome cover counterclockwise to open. Slide battery cover/attached car off of controller. 040-09-0826 '03 SM-6738

Use a Phillips head screwdriver to detach the car from the battery cover screw and pedestal.

Place two "AA" alkaline batteries into controller and replace battery cover.

Place antenna into hole at the top of controller, Turn clockwise to secure antenna to controller.

DO NOT OVER-TIGHTEN. Pull tip of antenna to extend.

Antenna

OPERATING

To charge the car, open cover at the bottom of controller. Align metal nodes on controller with the nodes on the car and place act onto controller. The charging indicator light will come on when car is changing, After a full charge (approx 45 seconds) the light will turn off. Take car off of controller.

Nodes INSTRUCTIONS



D. D.

Do Not Mix Old and New Batteries.

Do Not Mix Alkaline, Standard (Carbon-Zing),

Or Rechargeable (Nickel Cadmium) batteries.

The controller is full function. To make the car go, push the forward or reverse button. The car will turn left and right when the left or right button is pushed. The car will only turn left and right when it is moving in forward or reverse direction. The operating light will come on when car is in use. When indicator light becomes faint, it is time to replace batteries. While operating controller, make sure antenna is fully extended.



Occasionally the car will sway left or right while moving in forward or reverse direction. To correct this, adjust the directional guide on the bottom of car as shown in the illustration below. This may need to be done a few times while operating car.



For best results operate on a smooth dry surface. Radio waves control this toy and can easily be intempted. Avoid using near phones, electrical lines or CB's.

The manufacturer is not responsible for radio or TV interference caused by unauthorized modification of this equipment. Such modifications could void the users authority to operate the equipment.