RSF720. PCB			
Part	Used	PartType	Desi gnators
1		1k	R21 R25 R30 R34
2		1k2	R1
3		1p	C24
4		2k2	R2 R18
5		2u2	E1 E2 E8
6		3. 3uH	L1 L2 L3
7		3T5	L5 L6 L7
8		3k3	R10
9		4T5	L4
10		4u7 5k6	E3 E4 E6 E9 R5 R16 R27
12			BATT
13	<u>1</u> 1		R29
14			R7 R11 R13 R17 R20 R24 R33
15		10p	C21 C26
16		18k	R32
17		20MHz	XAL
18		20WITZ	VC1 VC2 VC3 C2 C5
19		22k	R3 R4 R6 R14
20		22p	C17
21			C11 C13 C25
22			R8 R9 R19 R23
23			C12
24	1		T02
25	1		T03
26	1		R12
27	1		R15
28	1	47u	E5
29	3	50p	C6 C10 C18
30		68p	C14
31	1	78L05	IC2
32	1		E7
33	1	101	
34	10		C4 C7 C19 C20 C22 C23 C27 C30 C31 C32
35	6		C3 C9 C15 C16 C28 C29
36	2		C8 VR1
37			R31
38	1	470	
39	1	618	
40	2		R22 R26
41	1	2638	
42	1	4558	
43		C1815 C1906	05 Q6 01 Q2 Q3 Q4
44		K2X4	SW1
45		LED	D2
47			MI C
47	103	m I O	IIII V
	103		
frequency	C13	C17	C12
174. 1MHz-213. 5MHz			
	47p	40p	60p
214MHz-227.62MHz	35p	22p	42p